

# The Amstrad CPC Firmware Guide

By Bob Taylor and Thomas Defoe, 1992

Electronic version by David Cantrell, 1994

HTML Version, 1996/97

<http://www.cantrell.org.uk/david/tech/cpc/>

Transferred to Acrobat PDF format

By John Kavanagh, 2002

PDF version in association with

CPC Oxygen

<http://www.cpcoxygen.pro.ie>

PDF Version 1.0 (2002)



# Introduction

Fortunately, when Amstrad developed the CPC and CPC+ computers, they let the user access many of the computer's internal routines (the firmware) and use them in their own programs. Experienced coders will no doubt write faster or more versatile code, yet these can easily be patched in using the Firmware Jumpblock.

For many years, Amstrad produced the definitive guide to the insides of the CPC but sale of this was stopped in 1989. Since then the Firmware Manual has been a much sought-after item by programmers. Nevertheless, the original guide had some omissions, notably the absence of information on the system variables and the Z80 microprocessor inside every CPC and CPC+.

This guide is not intended to explain how to program in machine code, but we hope that it will supply the information needed to make the most of the Amstrad's capabilities when writing your own programs.

**Bob Taylor and Thomas Defoe, 1992**



# Contents

<b>Use of Memory by the Operating System</b>	<b>7</b>
Overview of the CPC	7
System Variables	8
<b>Firmware Guide</b>	<b>33</b>
<b>Kernel</b>	<b>35</b>
Low Jumpblock	38
High Jumpblock	40
<b>The Key Manager</b>	<b>43</b>
<b>The Text VDU</b>	<b>47</b>
<b>The Graphics VDU</b>	<b>53</b>
<b>The Screen Pack</b>	<b>57</b>
<b>Cassette / AMSDOS</b>	<b>63</b>
AMSDOS / BIOS	66
<b>The Sound Manager</b>	<b>69</b>
<b>The Machine Pack</b>	<b>71</b>
<b>664 / 6128 only</b>	<b>73</b>
<b>The Firmware Indirections</b>	<b>75</b>
<b>The Maths Firmware</b>	<b>77</b>
Maths Subroutines for the 464 only	80
Maths Subroutines for the 664 and 6128 only	81
<b>The Z80 Instruction Set</b>	<b>83</b>
The Opcodes and T States	83
The Flag Register	83
<b>The CRTC Registers</b>	<b>105</b>



# Use of memory by the Operating System

The following list of memory addresses and their uses has been compiled over a number of years, mainly from personal investigation. It does not claim to be definitive, since no accurate source seems to be available to the average computer user, and so may be inaccurate or deficient at certain points; also, some of the areas described have uses additional to those listed. We have tried to make it as accurate as possible, to enable others to use to the full those facilities which present themselves via this information.

- Addresses and values are present in memory with the low byte first. The Z80 processor represents all 16-bit values in the order lo-byte hi-byte.
- The term `above' means higher in memory.
- Areas with numbers of bytes of either &00 or &FF given in brackets, may be safe to use for machine code routines etc, as may the tape area, and the Sound ENT and ENT areas if these are unused.
- The first column given is the address (for the 6128) of the memory being considered, while the second column gives the equivalent 464 address - unfortunately the 464 differs from the 6128 for most addresses, so if one address is omitted, the system variable is not available for that machine.
- The next column gives the size allocated in bytes. Addresses on the right hand side enclosed in brackets are of System Variables which hold the address of the bytes being explained. With addresses or values anywhere in the text, the value shown is for the 6128; a value in italics is for the 464 only.

## *Overview of the CPC's memory*

In the following tables, the following symbols are used:

<> - not the value or bit which follows  
\* - this applies to all machine with a disk drive fitted  
b0 - bit 0  
b1 - bit 1  
...  
b15 - bit 15  
HB - most significant byte, hi-byte  
LB - least significant byte, lo-byte

When addresses are given in the comments, they apply to the 6128. When the 464's address is different, it is given in brackets, such as at the comment for &B763.

Please note that this section of the guide has been set out with all the addresses in the leftmost column in the correct order for the 6128.

## The System Variables

6128	464	Size	Comments on the memory locations
&0000	&0000	&40	Restart block:
&0000	&0000		RST 0: complete machine reset
&0008	&0008		RST 1: LOWJUMP: in-line two byte address: b0 to b13=address; b14=Low ROM disabled; b15=Upper ROM disabled
&000B	&000B		LOW PCHL: HL has address as RST 1
&000E	&000E		`JMP BC': BC has address to jump to
&0010	&0010		RST 2: SIDE CALL: inline two byte address: b0 to b13=address-&C000; b14 to b15=offset to required ROM (used between sequenced Foreground ROMs)
&0013	&0013		SIDE PCHL: HL has address as RST 2
&0016	&0016		`JMP DE': DE has address to jump to
&0018	&0018		RST 3: FAR CALL: inline three byte address block: bytes 1 and 2 hold the address; byte 3 holds the ROM select address
&001B	&001B		FAR PCHL: as RST 3, but HL has address; C has ROM select
&001E	&001E		`JMP HL': HL has address to jump to
&0020	&0020		RST 4: RAM LAM: LD A,(HL) from RAM with ROMs disabled
&0023	&0023		FAR CALL: as RST 3, but HL has address of three byte address block
&0028	&0028		RST 5: FIRM JUMP: inline two byte address to jump to
&0030	&0030		RST 6: User restart; default to RST 0
&0038	&0038		RST 7: Interrupt entry (KB/Time etc)
&003B	&003B		External interrupt (default to RET)
&0040	&0040	&130	ROM lower foreground area: BASIC input area (tokenised)
&016F	&016F		end of BASIC input area.
&0170	&0170		BASIC working area for program, variables, etc...
&0170	&0170		Program area; Variables and DEF FNs area; Arrays area; Free space; end of free space; Strings area; end of Strings area (=HIMEM); Space for user machine code routines; end of user space, byte before user; defined graphics area; User defined graphics area; end of UDG area; ROM Upper reserved area, expandible during;  KL ROM WALK, including:
		r*4	ROM chaining blocks (arranged as follows):



6128	464	Size	Comments on the memory locations
&A6FC	&A6FC	4	AMSDOS chain,ing block:
&A6FC	&A6FC	2	address of next ROM block in chain (or &0000 if the last in chain)
&A6FE	&A6FE	1	ROM Select address
&A6FF	&A6FF	1	&00
&A700	&A700	&500	AMSDOS reserved area. This area is moved down if any ROMs have numbers greater than eight (6128 only)
&A700	&A700	1	Current drive number (0=A; 1=B)
&A701	&A701	1	Current USER number
&A702	&A702	1	flag?
&A703	&A703	2	address?
&A705	&A705	1	flag?
&A706	&A706	2	address?
&A708	&A708	1	OPENIN flag (&FF=closed; <>&FF=opened)
&A709	&A709	&20	Copy of current or last Disc Directory entry for OPENIN/LOAD:
&A709	&A709	1	USER number
&A70A	&A70A	8	filename (padded with spaces)
&A712	&A712	3	file extension (BAS, BIN, BAK, etc) including:
&A712	&A712	1	b7 set = Read Only
&A713	&A713	1	b7 set = System (ie not listed by CAT or DIR)
&A715	&A715	1	16K block sequence number for this directory entry (0 for first block; if <>0 part of a larger file)
&A716	&A716	2	unused
&A718	&A718	1	length of this block in 128 byte records
&A719	&A719	16	sequence of Disc Block numbers containing file - &00 as end marker
&A729	&A729	1	number of 128 byte records loaded so far; before loading proper: &00 for ASCII (ie nothing loaded yet); &01 for BIN or BAS files (ie header record loaded)
&A72A	&A72A	1	
&A72B	&A72B	1	
&A72C	&A72C	1	OPENOUT flag (&FF=closed; <>&FF=opened)
&A72D	&A72D	&20	Copy of current or last Disc Directory entry for OPENOUT/SAVE:
&A72D	&A72D	1	USER number
&A72E	&A72E	8	filename (padded with spaces)
&A736	&A736	3	file extension (\$\$\$ while open; correct extension when finished)
&A739	&A739	1	flag (&00=open; &FF=closed, ie finished)
&A73A	&A73A	1	
&A73B	&A73B	1	flag (&00=open; &FF=closed)
&A73C	&A73C	1	number of 128 byte records saved so far
&A73D	&A73D	16	sequence of Disc Block numbers containing file - &00 as end marker

6128	464	Size	Comments on the memory locations
&A74D	&A74D	1	number of 128 byte records saved so far
&A74E	&A74E	1	
&A74F	&A74F	1	
&A750	&A750	1	flag (&00=OPENIN; &01=In Char; &02=In Direct (whole file))
&A751	&A751	2	address of 2K buffer for ASCII, or of start of current/last block if BIN or BAS file
&A753	&A753	2	address of next byte to read for ASCII, or of 2K buffer for BAS or BIN file
&A755	&A755	&45	first &45 bytes of BAS/BIN file (extended header) or of extended header made for ASCII file
&A755	&A755	1	USER number
&A756	&A756	8	filename (padded)
&A75E	&A75E	3	extension
&A761	&A761	6	unused
&A767	&A767	1	file type (&00=BASIC; &01=protected BASIC; &02=Binary; &16=ASCII)
&A768	&A768	2	unused
&A76A	&A76A	2	address to load file into (=actual destination), or buffer for an ASCII file
&A76C	&A76C	1	unused for disc
&A76D	&A76D	2	length of file in bytes (&0000 for ASCII files)
&A76F	&A76F	2	execution address for a BIN file
&A770	&A770	&25	unused
&A795	&A795	3	length of actual file in bytes (as &A76D) -BAS and BIN only
&A798	&A798	2	simple checksum of first 67 bytes of header (LB first) - BAS and BIN only
&A79A	&A79A	1	flag (&00=OPENOUT; &01=Out Char; &02=Out Direct(whole file))
&A79B	&A79B	2	address of 2K block if an ASCII file, or of current/last block saved if a BAS or BIN file
&A79D	&A79D	2	address of next byte to write for ASCII files, or of 2K buffer for BAS and BIN files
&A79F	&A79F	&45	first &45 bytes of BAS/BIN file (ie extended header)
&A79F	&A79F	1	USER number
&A7A0	&A7A0	8	filename (padded)
&A7A8	&A7A8	3	extension
&A7AB	&A7AB	1	flag (&00=Open)
&A7AC	&A7AC	1	
&A7AD	&A7AD	1	flag (&00=Open)
&A7AE	&A7AE	3	unused
&A7B1	&A7B1	1	file type (&00=BASIC; &01=protected BASIC; &02=Binary; &16=ASCII)
&A7B2	&A7B2	2	unused
&A7B4	&A7B4	2	address to save file from (for BAS or BIN files), or of buffer for ASCII files

6128	464	Size	Comments on the memory locations
&A7B6	&A7B6	1	unused for disc
&A7B7	&A7B7	2	length of file in bytes
&A7B9	&A7B9	2	execution address for BIN files
&A7BB	&A7BB	&25	unused
&A7DF	&A7DF	3	length of actual file in bytes (as at &A7B7) - BAS and BIN only
&A7E2	&A7E2	2	simple checksum of first 67 bytes of header (LB first) - BAS and BIN only
&A7E4	&A7E4	&80	buffer area for records sent to or loaded from Disc, or used in forming filename and extension
&A864	&A864	14*3	Tape Jumpblock is stored here by AMSDOS - is moved to &BC77 etc after  TAPE
&A88B	&A88B	3	far address used by AMSDOS RST 3s at &BC77 etc (&CD30,&07)
&A890	&A890	&19	Drive A Extended Disc Parameter Block (XDPB):
&A890	&A890	2	number of 128 byte records per track
&A892	&A892	1	$\log_2(\text{Block size})-7$ (&03=1024 bytes; &04=2048 bytes)
&A893	&A893	1	$(\text{Block size})/128-1$ (&07=1024 bytes;
&A894	&A894	1	$(\text{Block size})/1024$ (if total of blocks <256, else /2048)-1
&A895	&A895	2	number of blocks per disc side (excluding reserved tracks)
&A897	&A897	2	number of (directory entries)-1
&A899	&A899	2	bit significant value of number of blocks for directory (&0080=1; &00C0=2)
&A89B	&A89B	2	number of bits in checksum $=((\&A894)+ 1)/4$
&A89D	&A89D	2	number of reserved tracks (&00=Data; &01=IBM; &02=System)
&A89F	&A89F	1	number of first sector (&01=IBM; &41=System; &C1=Data)
&A8A0	&A8A0	1	number of sectors per track (Data=9; System=9; IBM=8)
&A8A1	&A8A1	1	gap length (Read/Write)
&A8A2	&A8A2	1	gap length (Format)
&A8A3	&A8A3	1	format filler byte (&E5)
&A8A4	&A8A4	1	$\log_2(\text{sector size})-7$ (&02=512; &03=1024)
&A8A5	&A8A5	1	records per sector
&A8A6	&A8A6	1	current track (not for use)
&A8A7	&A8A7	1	0=not aligned (not for use)
&A8A8	&A8A8	1	Auto select flag (&00=Auto select; &FF= don't alter)
&A8A9	&A8A9		
&A8B9	&A8B9		
&A8D0	&A8D0	&19	Drive B Extended Disc Parameter Block (arranged as at &A890)
&A8E9	&A8E9		(&17 bytes of &FF)
&A8F9	&A8F9		
&A900	&A900		(&12 bytes of &00)
&A910	&A910		
&A918	&A918	2	address of area for reading directory entries for Drive A

6128	464	Size	Comments on the memory locations
&A91A	&A91A	2	address of Drive A XDPB
&A91C	&A91C	2	address of the byte after the end of Drive A XDPB
&A91E	&A91E	2	
&A920	&A920		(8bytes of &00)
&A928	&A928	2	address of area for reading directory entries for Drive B
&A92A	&A92A	2	address of Drive B XDPB
&A92C	&A92C	2	address of the byte after the end of Drive B XDPB
&A92E	&A92E	2	
&A930	&A930	&80	block of directory entries, including last file loaded
&A9B0	&A9B0	&200	buffer for loading; usually contains last sector loaded
&ABB0	&ABB0		(&50 bytes of &00)
&AC00	&AC00		Start of BASIC Operating System reserved area:
&AC00	&AC00	1	program line redundant spaces flag (0=keep extra spaces; <>0=remove)
	&AC01	9*3	groups of 3 RET bytes (&C9) called by the Upper ROM
&AC01	&AC1C	1	AUTO flag (0=off; <>0=on)
&AC02	&AC1D	2	number of the next line (6128) or of the current line (464) for AUTO
&AC04	&AC1F	2	step distance for AUTO
&AC06	&AC21	1	
&AC07	&AC22	1	
&AC08		1	
	&AC23	1	
&AC09	&AC24	1	WIDTH (&84=132)
&AC0A	&AC25		
&AC0B			
&AC0C	&AC26	1	FOR/NEXT flag (0=NEXT not yet used; <>0=used)
&ACOD	&AC27	5	FOR start value (real). Only 2 bytes are used if % or DEFINT variable
&AC12	&AC2C	2	address of `:` or of the end of program line byte after a NEXT command
&AC14	&AC2E	2	address of LB of the line number containing WEND
&AC16	&AC30	1	WHILE/WEND flag (&41=WEND not yet used; &04=used)
&AC17	&AC31		
&AC18	&AC32	2	
&ACIA	&AC34	2	
&AC1C	&AC36	2	address of location holding ROM routine address for KB event block
&AC1E	&AC38	&0C	Event Block for ON SQ(I):
&AC1E	&AC38	2	chain address to next event block; &0000 if last in chain, but &FFFF if unused
&AC20	&AC3A	1	count
&AC21	&AC3B	1	class: Far address, highest (ON SQ) priority, Normal & Synchronous event

6128	464	Size	Comments on the memory locations
&AC22	&AC3C	2	routine address (in BASIC ROM)
&AC24	&AC3E	1	ROM Select number (&FD ie ROM 0 enabled, Lower ROM disabled)
&AC25	&AC3F	1	(first byte of user field)
&AC26	&AC40	2	address of the end of program line byte or `:` after `ON SQ(x) GOSUB line number` statement
&AC28	&AC42	2	address of the end of program line byte of the line before the GOSUB routine
&AC2A	&AC44	&0C	Event block for ON SQ(2), arranged as &AC1E onwards - second ON SQ priority
&AC36	&AC50	&0C	Event block for ON SQ(4), arranged as &AC1E onwards - lowest ON SQ priority
&AC42	&AC5C	&12	Ticker and Event Block for AFTER/EVERY Timer 0
&AC42	&AC5C	2	chain address to next event block (usually to another timer or &00FF)
&AC44	&AC5E	2	`count down` count
&AC46	&AC60	2	recharge count (for EVERY only - &0000 if AFTER)
&AC48	&AC62	2	chain address to next ticker block
&AC4A	&AC64	1	count
&AC4B	&AC65	1	class: Far address, lowest (timer) priority, Normal and Synchronous event
&AC4C	&AC66	2	Routine address (in BASIC ROM)
&AC4E	&AC68	1	ROM Select No (&FD ie ROM 0 enabled, Lower ROM disabled)
&AC4F	&AC69	1	(first byte of user field)
&AC50	&AC6A	2	address of the end of program line byte or `:` after statement in use when the timer `timed-out`
&AC52	&AC6C	2	address of the end of program line byte of the line before the GOSUB routine
&AC54	&AC6E	&12	Ticker and Event Block for AFTER/EVERY Timer 1 (3rd Timer priority) arranged as at &AC42
&AC66	&AC80	&12	Ticker and Event Block for AFTER/EVERY Timer 2 (2nd Timer priority) arranged as at &AC42
&AC78	&AC92	&12	Ticker and Event Block for AFTER/EVERY Timer 3 (highest priority) arranged as at &AC42
&AC8A	&ACA4	&100	BASIC input area for lines (as typed in and not tokenised) or for INPUT
&AD8C	&ADA6	2	address of line number LB in line containing error
&AD8E	&ADA8	2	address of byte before statement containing error - ie of `:` or of HB of Line No
&AD90	&ADAA	1	ERR (Error No)
&AD91		1	DERR (Disc Error No)
&AD92	&ADAB	2	as &AD8E if error is in a program (ie not if in Direct Command Mode)
&AD94	&ADAD	2	as &AD8C if error is in a program (ie not if in Direct Command Mode)
&AD96	&ADAF	2	address of the length LB of line specified by the `ON ERROR GOTO` command
&AD98	&ADB1	1	

6128	464	Size	Comments on the memory locations
&AD99	&ADB2	&09	Current SOUND parameter block (see Firmware Jump &BCAA)
&AD99	&ADB2	1	channel andrendezvous status
&AD9A	&ADB3	1	amplitude envelope (ENV) number
&AD9B	&ADB4	1	tone envelope (ENT) number
&AD9C	&ADB5	2	tone period
&AD9E	&ADB7	1	noise period
&AD9F	&ADB8	1	initial amplitude
&ADA0	&ADB9	2	duration, or envelope repeat count
&ADA2	&ADBB	&10	Current Amplitude or Tone Envelope parameter bloc (see &BCBC or &BCBF)
&ADA2	&ADBB	1	number of sections (+&80 for a negative ENT number, ie the envelope is run until end of sound
&ADA3	&ADBC	3	first section of the envelope:
&ADA3	&ADBC	1	step count (if <&80) otherwise envelope shape (not tone envelope)
&ADA4	&ADBD	1	step size (if step count<&80) otherwise envelope period (not tone envelope)
&ADA5	&ADBE	1	pause time (if step count<&80) otherwise envelope period (not tone envelope)
&ADA6	&ADBF	3	second section of the envelope, as &ADA3
&ADA9	&ADC2	3	third section of the envelope, as &ADA3
&ADAC	&ADC5	3	fourth section of the envelope, as &ADA3
&ADAF	&ADC8	3	fifth section of the envelope, as &ADA3
&ADB2	&ADCB	5	
&ADB7	&ADD0	&36	
&ADEB	&AE04	2	
&ADED	&AE06	6	
&ADF3	&AE0C	26*1	table of DEFINT (&02), DEFSTR (&03) or DEFREAL default (&05), for variables `a' to `z'
&AE0D	&AE26		
&AE0E	&AE27	2	
&AE10	&AE29	2	
&AE12	&AE2B	2	
&AE14	&AE2D	1	
&AE15	&AE2E	2	address of line number LB of last BASIC line (or &FFFF)
&AE17	&AE30	2	address of byte before next DATA item (eg comma or space)
&AE19	&AE32	2	address of next space on GOSUB etc stack, (see also &B06F)
&AE1B	&AE34	2	address of byte before current statement (&003F if in Direct Command mode)
&AE1D	&AE36	2	address of line number LB of line of current statement (&0000 if in Direct Command mode)
&AE1F	&AE38	1	trace flag (0=TROFF; <>0=TRON)

6128	464	Size	Comments on the memory locations
&AE20	&AE39	1	flag used with Trace (&00 if in Direct Command mode; &01 if in a program)
&AE21	&AE3A		
&AE22	&AE3B	2	
&AE24	&AE3D	2	
&AE26	&AE3F	2	address to load cassette file to
&AE28	&AE41		
&AE29	&AE42	1	file type from cassette header
&AE2A	&AE43	2	file length from cassette header
&AE2C	&AE45	1	program protection flag (<>0 hides program as if protected)
&AE2D	&AE46	17	buffer used to form binary or hexadecimal numbers before printing etc
&AE3A	&AE53	5	start of buffer used to form hexadecimal numbers before printing etc
&AE3A	&AE53	1	Key Number used with INKEY (providing the Key Number is written as a decimal)
&AE3E	&AE57	1	last byte (usually &00 or &20) of the formed binary or hexadecimal number
&AE43	&AE5D	13	buffer used to form decimal numbers before printing etc
&AE4E	&AE68	1	last byte (usually &00 or &20) of the formed decimal number
	&AE6B	3	
&AE51		1	
&AE52	&AE6E	2	
&AE54		1	
	&AE70	2	temporary store for address after using (&AE68)
&AE55	&AE72	2	address of last used ROM or RSX JUMP instruction in its Jump Block
&AE57	&AE74	1	ROM Select number if address above is in ROM
&AE58	&AE75	2	BASIC Parser position, moved on to `:`, or the end of program line byte after a CALL or an RSX
&AE5A	&AE77	2	the resetting address for machine Stack Pointer after a CALL or an RSX
&AE5C	&AE79	2	ZONE value
&AE5D		1	
	&AE7A	1	
&AE5E	&AE7B	2	HIMEM (set by MEMORY)
	&AE7D	2	address of the byte before the UDG area (the end of the user M/C routine area or the Strings area) if the UDG area is still present, otherwise the highest byte of Program etc area
&AE60	2		address of highest byte of free RAM (ie last byte of UDG area)
&AE62	&AE7F	2	address of start of ROM lower reserved area (used for tokenised lines)
&AE64	&AE81	2	address of end of ROM lower reserved area (byte before Program area)
&AE66	&AE83	2	as &AE68

6128	464	Size	Comments on the memory locations
&AE68	&AE85	2	address of start of Variables and DEF FNs area
&AE6A	&AE87	2	address of start of Arrays area (where next Variable or DEF FN entry is placed)
&AE6C	&AE89	2	address of start of free space (where next Array entry is placed)
&AE6E		1	
&AE70	&AE8C	&1FF	GOSUB, FOR and WHILE stack. Entries are added above any existing ones in use (mixed as encountered) at address given by &B06F and must be used up in the opposite order. Completed entries are not deleted, just overwritten by the next new entry:
		1	(byte of &00)
		2	address of end of program line byte or `:` after GOSUB statement (the point to RETURN to)
		2	address of line number HB of line containing GOSUB
		1	byte of &06, ie the length of the GOSUB entry
		2	address of current value of control variable (in Variables area)
		5	value of limit (ie the TO value) - there are two bytes only for Integer FORs
		5	value of STEP - two bytes for Integer FORs
		1	sign byte (&00 for positive; &01 for negative)
		2	address of the end of program line byte, or `:` after the FOR statement (ie the address for the NEXT loop to restart at)
		2	address of line number LB of line containing FOR
		2	address of byte after NEXT statement (ie the address to continue at when the limit is exceeded)
		2	address of byte after NEXT statement again
		1	length byte (&16 for Real FORs; &10 for Integer FORs)
WHILE (66 max capacity):		2	address of line number LB of line containing WHILE
		2	address of the end of program line byte or `:` after WEND statement (ie the address to continue at when the condition is false)
		2	address of condition after the WHILE command
		1	length byte of &07 - end of WHILE entry proper but:
		+5	value of condition (0 or -1 as a floating point value) only while the WHILE entry is the last on the stack
&B06F	&B08B	2	address of the next space on the GOSUB etc stack (see also &AE19) NB: The free space on the stack is also used as a workspace by various routines for values and addresses and for Variable names
&B071	&B08D	2	address of end of free space (the byte before the Strings area)
&B073	&B08F	2	address of end of Strings area (=HIMEM)
&B075		1	
	&B091	1	



6128	464	Size	Comments on the memory locations
	&B092	2	
&B076	&B094	2	
&B078	&B096	2	address of the highest byte of free RAM disregarding UDGs (usually &A6FB)
&B07A	&B098	2	
&B07C	&B09A	2	address for the next entry in the String Concatenation area
&B07E	&B09C	10*3	concatenation area holding descriptors of strings being used
&B09C	&B0BA	1	length of last String used
&B09D	&B0BB	2	address of last String used
	&B0BD	2	
	&B0BF	2	
&B09F	&BOC1	1	type byte used with the Virtual Accumulator (&02=Integer; &03=String; &05=Real)
&B0A0	&B0C2	5	Virtual Accumulator used by the maths routines (two bytes for an Integer value; three bytes for a String Descriptor; five bytes for a Real value)
&B0A0	&B0C2	2	
&B0A2	&B0C4	1	
&B0A3	&B0C5	2	
&B0A5	&B0C7	&5B	(&39 bytes on 464) bytes of &FF
&B100	&B8E4	2	&07, &C6
&B102	&B8E6	2	&65, &89
&B104	&B8E8	5	
&B109	&B8ED	5	
&B10E	&B8F2	5	
&B113	&B8F7	1	DEG/RAD flag (&00=RAD; &FF=DEG)
&B114	&B8DC	1	
&B115	&B8DD	1	
&B116	&B8DE	1	
&B117	&B8DF	1	
&B118	&B800	&D2	Area used for Cassette handling:
&B118	&B800	1	cassette handling messages flag (0=enabled; <>0=disabled)
&B119	&B801	1	
&B11A	&B802	1	file IN flag (&00=closed; &02=IN file; &03=opened; &05=IN char)
&B11B	&B803	2	address of 2K buffer for directories
&B11D	&B805	2	address of 2K buffer for loading blocks of files - often as &B11B
&B11F	&B807	&40	IN Channel header
&B11F	&B807	&10	filename (padded with NULs)
&B12F	&B817	1	number of block being loaded, or next to be loaded
&B130	&B818	1	last block flag (&FF=last block; &00=not)

6128	464	Size	Comments on the memory locations
&B131	&B819	1	file type (&00=BASIC; &01=Protected BASIC; &02=Binary; &08=Screen; &16=ASCII)
&B132	&B81A	2	length of this block
&B134	&B81C	2	address to load this or the next block at, or the address of the byte after last one loaded
&B136	&B81E	1	first block flag (&FF=first block; &00=not)
&B137	&B81F	2	total length of file (all blocks)
&B139	&B821	2	execution address for BIN files (&0000 if not saved as such)
&B13B	&B823	&24	not allocated
&B15F	&B847	1	file OUT flag (&00=closed; &02=IN file; &03=opened; &05=IN char)
&B160	&B848	2	address to start the next block save from, or the address of the buffer if it is OPENOUT
&B162	&B84A	2	address of start of the last block saved, or the address of the buffer if it is OPENOUT
&B164	&B84C	&40	OUT Channel Header (details as IN Channel Header):
&B164	&B84C	&10	filename
&B174	&B85C	1	number of the block being saved, or next to be saved
&B175	&B85D	1	last block flag (&FF=last block; &00=not)
&B176	&B85E	1	file type (as at &B131)
&B177	&B85F	2	length saved so far
&B179	&B861	2	address of start of area to save, or address of buffer if it is an OPENOUT instruction
&B17B	&B863	1	first block flag (&FF=first block; &00=not)
&B17C	&B864	2	total length of file to be saved
&B17E	&B866	2	execution address for BIN files (&0000 if parameter not supplied)
&B180	&B868	&24	not allocated
&B1A4	&B88C	&40	used to construct IN Channel header:
&B1B5	&B89D	1	
&B1B7	&B89F	2	
&B1B8	&B8A3	1	
&B1BE	&B8A6	1	
&B1B9	&B51D		base address for calculating relevant Sound Channel block
&B1BC	&B520		base address for calculating relevant Sound Channel ?
&B1BE	&B522		base address for calculating relevant Sound Channel ?
&B1D5	&B539		base address for calculating relevant Sound Channel ?
&B1E4	&B8CC	1	
&B1E5	&B8CD	1	synchronisation byte
&B1E6	&B8CE	2	&55, &62
&B1E8	&B8D0	1	
&B1E9	&B8D1	1	cassette precompensation (default &06; SPEED WRITE 1 &0C @4microseconds)
&B1EA	&B8D2	1	cassette 'Half a Zero' duration (default &53; SPEED WRITE 1 &29 @ 4microseconds)

6128	464	Size	Comments on the memory locations
&B1EB	&B8D3	2	
	&B550	1	used by sound routines
	&B551	1	used by sound routines
&B1ED		1	used by sound routines
&B1EE	&B552	1	used by sound routines
&B1F0	&BB54	1	used by sound routines
	&BB55	7	used by sound and cassette routines
&B1F8	&B55C	&3F	Sound Channel A (1) data:
&B212	&B576	1	number of sounds still queuing
&B213	&B577	1	number of sounds originally queuing
&B217	&B57B	8	first or fifth sound in Channel 1 (A) queue:
&B217	&B57B	1	status: b0 to b2 = rendezvous with channel 1, 2 or 4; b3 = Hold; b4 = Flush
&B218	&B57C	1	b0 to b3 = tone envelope number; b4 to b7 = volume envelope number (ie ENV number*16)
&B219	&B57D	2	pitch
&B21B	&B57F	1	noise
&B21C	&B580	1	volume
&B21D	&B581	2	duration (in 0.01 seconds)
&B21F	&B583	8	second sound in Channel 1 queue (as &B217)
&B227	&B58B	8	third sound in Channel 1 queue (as &B217)
&B22F	&B593	8	fourth sound in Channel 1 queue (as &B217)
&B237	&B59B	&3F	Sound Channel B (2) data - as described at &B1F8
&B256	&B5BA	8	first or fifth sound in Channel 2 queue (as &B217)
&B25E	&B5C2	8	second sound in Channel 2 queue (as &B217)
&B266	&B5CA	8	third sound in Channel 2 queue (as &B217)
&B26E	&B5D2	8	fourth sound in Channel 2 queue (as &B217)
&B276	&B5DA	&3F	Sound Channel C (4) data - as described at &B1F8
&B295	&B5F9	8	first or fifth sound in Channel 4 queue (as &B217)
&B29D	&B601	8	2nd sound in Channel 4 queue (as &B217)
&B2A5	&B609	8	3rd sound in Channel 4 queue (as &B217)
&B2AD	&B611	8	4th sound in Channel 4 queue (as &B217)
&B2A6	&B60A		base address for calculating relevant ENV parameter block
&B2B6	&B61A	15*16	ENV parameter block area (each arranged as &ADA2):
&B2B6	&B61A	&10	ENV 1
&B2C6	&B62A	&10	ENV 2
&B2D6	&B63A	&10	ENV 3
&B2E6	&B64A	&10	ENV 4
&B2F6	&B65A	&10	ENV 5
&B306	&B66A	&10	ENV 6
&B316	&B67A	&10	ENV 7
&B326	&B68A	&10	ENV 8

6128	464	Size	Comments on the memory locations
&B336	&B69A	&10	ENV 9
&B346	&B6AA	&10	ENV 10
&B356	&B6BA	&10	ENV 11
&B366	&B6CA	&10	ENV 12
&B376	&B6DA	&10	ENV 13
&B386	&B6EA	&10	ENV 14
&B396	&B6FA	&10	ENV 15
&B396	&B6FA		base address for calculating relevant ENT parameter block
&B3A6	&B70A	15*16	ENT parameter block area (each arranged as &ADA2):
&B3A6	&B70A	&10	ENT 1
&B3B6	&B71A	&10	ENT 2
&B3C6	&B72A	&10	ENT 3
&B3D6	&B73A	&10	ENT 4
&B3E6	&B74A	&10	ENT 5
&B3F6	&B75A	&10	ENT 6
&B406	&B76A	&10	ENT 7
&B416	&B77A	&10	ENT 8
&B426	&B78A	&10	ENT 9
&B436	&B79A	&10	ENT 10
&B446	&B7AA	&10	ENT 11
&B456	&B7BA	&10	ENT 12
&B466	&B7CA	&10	ENT 13
&B476	&B7DA	&10	ENT 14
&B486	&B7EA	&10	ENT 15
&B496	&B34C	&50	Normal Key Table:

Cur U	Cur R	Cur D	f9	f6	f3	Enter	f.
Cur L	Copy	f7	f8	f5	f1	f2	f0
Clr	[	Ret	]	f4		\	
^	-	@	p	;	:	/	.
0	9	o	i	l	k	m	j
8	7	u	y	h	j	n	Space
6	5	r	t	g	f	b	v
4	3	e	w	s	d	c	x
1	2	Esc	q	Tab	a	Caps	z
[VT]	[LF]	[BS]	[TAB]	Fire2	Fire1		Del

&B4E6    &B39C    &50    Shifted Key Table:

Cur U	Cur R	Cur D	f9	f6	f3	Enter	f.
Cur L	Copy	f7	f8	f5	f1	f2	f0
Clr	{	Ret	}	f4		`	
£	=		P	+	*	?	>
_	)	O	I	L	K	M	<
(	'	U	Y	H	J	N	Space
&	%	R	T	G	F	B	V
\$	#	E	W	S	D	C	X

**6128      464      Size                      Comments on the memory locations**

!	"	Esc	Q	->	A	Caps	Z
[	[VT]	[LF]	[BS]	[TAB]	Fire2	Fire1	Del

&B536      &B3EC      &50

Control Key Table:

Cur U	Cur R	Cur D	f9	f6	f3	Enter	f.
Cur L	Copy	f7	f8	f5	f1	f2	f0
Clr	(ESC)	Ret	(GS)	f4		(FS)	
(RS)		(NUL)	(DLE)				
(US)		(SI)	(HT)	(FF)	(VT)	(CR)	
		(NAK)	(EM)	(BS)	(LF)	(SO)	
		(DC2)	(DC4)	(BEL)	(ACK)	(STX)	(SYN)
		(ENQ)	(ETB)	(DC3)	(EOT)	(ETX)	(CAN)
	~	Esc	(DC1)	Ins/Ovrt	(SOH)	S-Ick	(SUB)
						Del	

&B586      &B43C      10

KB repeats table (each byte/bit applies to all three key tables): 1 byte is used per line of the tables; b0 to b7 give the columns (left to right), repeat if set

&B590      &B446      &98

DEF KEY's definition area (for Keys &80 to &9F in sequence): each definition has either a single byte of &00 if it is unused/unaltered, or: byte 1: length of definition bytes 2 to x: definition, either a single key or a string of keys

&B628      &B4DE      1

Byte after end of DEF KEY area

&B629      &B4DF      1

&B62A      &B4E0      1

&B62B      &B4E1      2

address of DEF KEY area

&B62D      &B4E3      2

address of byte after end of DEF KEY area

&B62F      &B4E5      1

&B630      &B4E6      1

&B631      &B4E7      1

Shift lock flag (&00=off; &FF=on)

&B632      &B4E8      1

Caps lock flag (&00=off; &FF=on)

&B633      &B4E9      1

KB repeat period (SPEED KEY - default &02 @ 0.02 seconds)

&B634      &B4EA      1

KB delay period (SPEED KEY - default &1E @ 0.02 seconds)

&B635      &B4EB      2\*10

Tables used for key scanning; bits 0 to 7 give the table columns (from left to right):

&B635      &B4EB      1

Cur U	Cur R	Cur D	f9	f6	f3	Enter	f.
-------	-------	-------	----	----	----	-------	----

&B636      &B4EC      1

Cur L	Copy	f7	f8	f5	f1	f2	f0
-------	------	----	----	----	----	----	----

&B637      &B4ED      1

Clr	[	Ret	]	f4	Shift	\	Ctrl
-----	---	-----	---	----	-------	---	------

&B638      &B4EE      1

^	-	@	p	:	/	.
---	---	---	---	---	---	---

&B639      &B4EF      1

0	9	o	i	l	k	m	j
---	---	---	---	---	---	---	---

&B63A      &B4F0      1

8	7	u	y	h	j	n	Space
---	---	---	---	---	---	---	-------

6128	464	Size	Comments on the memory locations														
&B63B	&B4F1	1	<table border="1"> <tr> <td>Down</td><td>Up</td><td>Left</td><td>Right</td><td>Fire2</td><td>Fire1</td><td>(Joystick 1)</td> </tr> <tr> <td>6</td><td>5</td><td>r</td><td>t</td><td>g</td><td>f</td><td>b v</td> </tr> </table>	Down	Up	Left	Right	Fire2	Fire1	(Joystick 1)	6	5	r	t	g	f	b v
Down	Up	Left	Right	Fire2	Fire1	(Joystick 1)											
6	5	r	t	g	f	b v											
&B63C	&B4F2	1	<table border="1"> <tr> <td>4</td><td>3</td><td>e</td><td>w</td><td>s</td><td>d</td><td>c</td><td>x</td> </tr> </table>	4	3	e	w	s	d	c	x						
4	3	e	w	s	d	c	x										
&B63D	&B4F3	1	<table border="1"> <tr> <td>1</td><td>2</td><td>Esc</td><td>q</td><td>Tab</td><td>a</td><td>Caps</td><td>z</td> </tr> </table>	1	2	Esc	q	Tab	a	Caps	z						
1	2	Esc	q	Tab	a	Caps	z										
&B63E	&B4F4	1	<table border="1"> <tr> <td>Down</td><td>Up</td><td>Left</td><td>Right</td><td>Fire2</td><td>Fire1</td><td>(Joystick 2)</td> </tr> <tr> <td></td><td></td><td></td><td></td><td></td><td></td><td>Del</td> </tr> </table>	Down	Up	Left	Right	Fire2	Fire1	(Joystick 2)							Del
Down	Up	Left	Right	Fire2	Fire1	(Joystick 2)											
						Del											
&B63F	&B4F5	1	complement of &B635														
&B640	&B4F6	1	complement of &B636														
&B641	&B4F7	1	complement of &B637														
&B642	&B4F8	1	complement of &B638														
&B643	&B4F9	1	complement of &B639														
&B644	&B4FA	1	complement of &B63A														
&B645	&B4FB	1	complement of &B63B														
&B646	&B4FC	1	complement of &B63C														
&B647	&B4FD	1	complement of &B63D														
&B648	&B4FE	1	complement of &B63E														
&B64B	&B501																
&B653	&B509	1															
&B654	&B50A	1															
&B655	&B50B	1															
&B656	&B50C	1															
&B657	&B50D	7	event block for Keyboard handling, comprises:														
&B657	&B50D	2	chain address														
&B659	&B50F	1	count														
&B65A	&B510	1	class: express event														
&B65B	&B511	2	ROM routine address: &C492														
&B65D	&B513	1	ROM select number: &FD														
&B65E	&B514	20*2	store for last keys pressed and each entry is as follows: byte 1: +0 to +10=key tables' line number; if bit 5 is set then Shift is pressed; bit 7=Control is pressed byte 2: b0 to b7=key tables' column number - see &B496 etc														
&B67F	&B67F	2	vestige from the 464?														
&B686	&B53C	1															
&B687	&B53D	1	accumulated count of the number of keys pressed (MOD 20)														
&B688	&B53E	1	number of keys left in key buffer														
&B689	&B53F	1	accumulated count of the number of keys removed from the buffer (MOD 20)														
&B68A	&B540	1															
&B68B	&B541	2	address of the normal key table														
&B68D	&B543	2	address of the shifted key table														
&B68F	&B545	2	address of the control key table														

6128	464	Size	Comments on the memory locations
&B691	&B547	2	address of the KB repeats table
&B692		1	
&B693	&B328	2	ORIGIN x
&B695	&B32A	2	ORIGIN y
&B697	&B32C	2	graphics text x position (pixel)
&B699	&B32E	2	graphics text y position(pixel)
&B69B	&B330	2	graphics window x of one edge (pixel)
&B69D	&B332	2	graphics window x of other edge (pixel)
&B69F	&B334	2	graphics window y of one side (pixel)
&B6A1	&B336	2	graphics window y of other side (pixel)
&B6A3	&B338	1	GRAPHICS PEN
&B6A4	&B339	1	GRAPHICS PAPER
&B6A5	&B33A	8/14	(This area is 14 bytes on the 464) Used by line drawing (and other) routines, as follows:
&B6A7	&B33A	2	x+1()
&B6A9	&B33C	2	y/2+1()
&B6AB	&B33E	2	y/2-x()
&B6AD	&B340	2	
	&B342	2	
&B6AF	&B344	1	
&B6B0	&B345	1	
&B6B1	&B346	1	
&B6B2		1	first point on drawn line flag (<>0=to be plotted; 0=don't plot)
&B6B3		1	line MASK
&B6B4		1	
	&B207	2	
&B6B5	&B20C	1	current stream number
&B6B6	&B20D	14/15	(These areas are 15 bytes on the 464) Stream (window) 0 parameter block. These areas are arranged as &B726
&B6C4	&B21C	14/15	stream (window) 1 parameter block
&B6D2	&B22B	14/15	stream (window) 2 parameter block
&B6E0	&B23A	14/15	stream (window) 3 parameter block
&B6EE	&B249	14/15	stream (window) 4 parameter block
&B6FC	&B258	14/15	stream (window) 5 parameter block
&B70A	&B267	14/15	stream (window) 6 parameter block
&B718	&B276	14/15	stream (window) 7 parameter block
&B726	&B285	14/15	Current Stream (Window) parameter block:
&B726	&B285	1	cursor y position (line) with respect to the whole screen (starting from 0)
&B727	&B286	1	cursor x position (column) with respect to the whole screen (starting from 0)
&B728	&B287		

6128	464	Size	Comments on the memory locations
&B729	&B288	1	window top line (y) with respect to the whole screen (starting from 0)
&B72A	&B289	1	window left column (x) with respect to the whole screen (starting from 0)
&B72B	&B28A	1	window bottom line (y) with respect to the whole screen (starting from 0)
&B72C	&B28B	1	window right column (x) with respect to the whole screen (starting from 0)
&B72D	&B28C	1	scroll count
&B72E	&B28D	1	cursor flag (&01=disable; &02=off; &FD=on; &FE=enable)
	&B28E	1	
&B72F	&B28F	1	current PEN number (encoded, not its INK number)
&B730	&B290	1	current PAPER number (encoded, not its INK number)
&B731	&B291	2	address of text background routine: opaque=&1392; transparent=&13A0
&B733	&B293	1	graphics character writing flag (0=off; <>0=on)
&B734	&B294	1	ASCII number of the first character in User Defined Graphic (UDG) matrix table
&B735	&B295	1	UDG matrix table flag (&00=non-existent; &FF=present)
&B736	&B296	2	address of UDG matrix table
&B738	&B298	2	
&B758	&B2B8	1	
&B759	&B2B9	1	
&B763	&B2C3	32*3	Control Code handling routine table - each code's entry comprises: byte 1: +0 to +9=number of parameters; +&80=re-run routine at a System Reset bytes 2 and 3: address of the control code's handling routine
&B763	&B2C3	3	ASC 0: &80,&1513: NUL
&B766	&B2C6	3	ASC 1: &81,&1335: Print control code character [,char]
&B769	&B2C9	3	ASC 2: &80,&1297: Disable cursor
&B76C	&B2CC	3	ASC 3: &80,&1286: Enable cursor
&B76F	&B2CF	3	ASC 4: &81,&0AE9: Set mode [,mode]
&B772	&B2D2	3	ASC 5: &81,&1940: Print character using graphics mode [,char]
&B775	&B2D5	3	ASC 6: &80,&1459: Enable VDU
&B778	&B2D8	3	ASC 7: &80,&14E1: Beep
&B77B	&B2DB	3	ASC 8: &80,&1519: Back-space
&B77E	&B2DE	3	ASC 9: &80,&151E: Step-right
&B781	&B2E1	3	ASC 10: &80,&1523: Linefeed
&B784	&B2E4	3	ASC 11: &80,&1528: Previous line
&B787	&B2E7	3	ASC 12: &80,&154F: Clear window and locate the cursor at position 1,1
&B78A	&B2EA	3	ASC 13: &80,&153F: RETURN
&B78D	&B2ED	3	ASC 14: &81,&12AB: Set paper [,pen]
&B790	&B2F0	3	ASC 15: &81,&12A6: Set pen [,pen]



6128	464	Size	Comments on the memory locations
&B793	&B2F3	3	ASC 16: &80,&155E: Delete the character at the cursor position
&B796	&B2F6	3	ASC 17: &80,&1599: Clear the line up to the current cursor position
&B799	&B2F9	3	ASC 18: &80,&158F: Clear from the cursor position to the end of the line
&B79C	&B2FC	3	ASC 19: &80,&1578: Clear from start of the window to the cursor position
&B79F	&B2FF	3	ASC 20: &80,&1565: Clear from the cursor position to the end of a window
&B7A2	&B302	3	ASC 21: &80,&1452: Disable VDU
&B7A5	&B305	3	ASC 22: &81,&14EC: Set text write mode [,mode]
&B7A8	&B308	3	ASC 23: &81,&0C55: Set graphics draw mode [,mode]
&B7AB	&B30B	3	ASC 24: &80,&12C6: Exchange pen and paper
&B7AE	&B30E	3	ASC 25: &89,&150D: Define user defined character [,char,8 rows of char]
&B7B1	&B311	3	ASC 26: &84,&1501: Define window [,left,right,top,bottom]
&B7B4	&B314	3	ASC 27: &00,&14EB: ESC (=user)
&B7B7	&B317	3	ASC 28: &83,&14F1: Set the pen inks [,pen,ink 1,ink 2]
&B7BA	&B31A	3	ASC 29: &82,&14FA: Set border colours [,ink,ink2]
&B7BD	&B31D	3	ASC 30: &80,&1539: Locate the text cursor at position 1,1
&B7C0	&B320	3	ASC 31: &82,&1547: Locate the text cursor at [,column,line]
&B7C3	&B1C8	1	MODE number
&B7C4	&B1C9	2	screen offset
&B7C6	&B1CB	1	screen base HB (LB taken as &00)
&B7C7	&B1CC	3	graphics VDU write mode indirection - JP &0C74
	&B1CF	8	list of bytes having only one bit set, from b7 down to b0
&B7D2	&B1D7	1	first flash period (SPEED INK - default &0A @ 0.02 seconds)
&B7D3	&B1D8	1	second flash period (SPEED INK - default &0A @ 0.02 seconds)
&B7D4	&B1D9	1+16	Border and Pens' First Inks (as hardware numbers):
&B7D4	&B1D9	1	hw &04 = sw 1 (blue) border
&B7D5	&B1DA	1	hw &04 = sw 1 (blue) pen 0
&B7D6	&B1DB	1	hw &0A = sw 24 (bright yellow) pen 1
&B7D7	&B1DC	1	hw &13 = sw 20 (bright cyan) pen 2
&B7D8	&B1DD	1	hw &0C = sw 6 (bright red) pen 3
&B7D9	&B1DE	1	hw &0B = sw 26 (bright white) pen 4
&B7DA	&B1DF	1	hw &14 = sw 0 (black) pen 5
&B7DB	&B1E0	1	hw &15 = sw 2 (bright blue) pen 6
&B7DC	&B1E1	1	hw &0D = sw 8 (bright magenta) pen 7
&B7DD	&B1E2	1	hw &06 = sw 10 (cyan) pen 8
&B7DE	&B1E3	1	hw &1E = sw 12 (yellow) pen 9
&B7DF	&B1E4	1	hw &1F = sw 14 (pale blue) pen 10

6128	464	Size	Comments on the memory locations
&B7E0	&B1E5	1	hw &07 = sw 16 (pink) pen 11
&B7E1	&B1E6	1	hw &12 = sw 18 (bright green) pen 12
&B7E2	&B1E7	1	hw &19 = sw 22 (pale green) pen 13
&B7E3	&B1E8	1	hw &04 = sw 1 (blue) pen 14
&B7E4	&B1E9	1	hw &17 = sw 11 (sky blue) pen 15
&B7E5	&B1EA	1+16	Border and Pens' Second Inks (as hardware numbers):
&B7E5	&B1EA	1	hw &04 = sw 1 (blue) border
&B7E6	&B1EB	1	hw &04 = sw 1 (blue) pen 0
&B7E7	&B1EC	1	hw &0A = sw 24 (bright yellow) pen 1
&B7E8	&B1ED	1	hw &13 = sw 20 (bright cyan) pen 2
&B7E9	&B1EE	1	hw &0C = sw 6 (bright red) pen 3
&B7EA	&B1FF	1	hw &0B = sw 26 (bright white) pen 4
&B7EB	&B1F0	1	hw &14 = sw 0 (black) pen 5
&B7EC	&B1F1	1	hw &15 = sw 2 (bright blue) pen 6
&B7ED	&B1F2	1	hw &0D = sw 8 (bright magenta) pen 7
&B7EE	&B1F3	1	hw &06 = sw 10 (cyan) pen 8
&B7EF	&B1F4	1	hw &1E = sw 12 (yellow) pen 9
&B7F0	&B1F5	1	hw &1F = sw 14 (pale blue) pen 10
&B7F1	&B1F6	1	hw &07 = sw 16 (pink) pen 11
&B7F2	&B1F7	1	hw &12 = sw 18 (bright green) pen 12
&B7F3	&B1F8	1	hw &19 = sw 22 (pale green) pen 13
&B7F4	&B1F9	1	hw &04 = sw 1 (bright yellow) pen 14
&B7F5	&B1FA	1	hw &17 = sw 11 (pink) pen 15
&B7F6	&B1FB	1	
&B7F7	&B1FC	1	
&B7F8	&B1FD	1	
&B7F9	&B1FE	2	
&B7FB	&B200	2	
&B7FD			
&B802		1+1	
&B804		1	number of entries in the Printer Translation Table (normally 10)
&B805		20*2	Printer Translation Table; each entry comprises: byte 1: screen code byte 2: printer code
&B805		2	screen &A0 printer &5E (acute accent)
&B807		2	screen &A1 printer &5C (\)
&B809		2	screen &A2 printer &7B ({)
&B80B		2	screen &A3 printer &23 (#)
&B80D		2	screen &A6 printer &40 (@)
&B80F		2	screen &AB printer &7C ( )
&B811		2	screen &AC printer &7D (})
&B813		2	screen &AD printer &7E (~)

6128	464	Size	Comments on the memory locations
&B815		2	screen &AE printer &5D (I)
&B817		2	screen &AF printer &SE (I)
&B819		20	room for ten more translations
&B82D	&B100	1	
&B82E	&B101	1	
&B82F	&B102	2	
&B831	&B104	1	
&B832	&B105	2	temporary store for stack pointer (SP) during interrupt handling
&B834	&B107	&70	temporary machine stack (from &B8B3 downwards) during interrupt handling
&B8B4	&B187	4	TIME (stored with the LB first - four bytes give >166 days; three bytes give >15 hours)
&B8B8	&B18B	1	
&B8B9	&B18C	2	
&B8BB	&B18E	2	
&B8BD	&B190	2	address of the first ticker block in chain (if any)
&B8BF	&B192	1	Keyboard scan flag (&00=scan not needed; &01=scan needed)
&B8C0	&B193	2	address of the first event block in chain (if any)
&B8C2	&B195	1	
&B8C3	&B196	&10	buffer for last RSX or RSX command name (last character has bit 7 set)
&B8D3	&B1A6	2	address of first ROM or RSX chaining block in chain
&B8D5		1	RAM bank number
&B8D6	&B1A8	1	Upper ROM status (eg select number)
&B8D7	&B1A9	2	entry point of foreground ROM in use (eg &C006 for BASIC ROM)
&B8D9	&B1AB	1	foreground ROM select address (0 for the BASIC ROM)
&B8DA		16*2	ROM entry IY value (ie the address table) - the 6128 has ROMs numbered from 0 to 15:
	&B1AC	7*2	ROM entry IY value (ie the address table)
&B8DA		2	ROM 0 IY (not for the 464)
&B8DC	&B1AC	2	ROM 1 IY
&B8DE	&B1AE	2	ROM 2 IY
&B8E0	&B1B0	2	ROM 3 IY
&B8E2	&B1B2	2	ROM 4 IY
&B8E4	&B1B4	2	ROM 5 IY
&B8E6	&B1B6	2	ROM 6 IY
&B8E8	&B1B8	2	ROM 7 IY (usually &A700 for AMSDOS/CPM ROM)
&B8EA		2	ROM 8 IY (not 464)
&B8EC		2	ROM 9 IY (not 464)
&B8EE		2	ROM 10 IY (not 464)
&B8F0		2	ROM 11 IY (not 464)

6128	464	Size	Comments on the memory locations
&B8F2		2	ROM 12 IY (not 464)
&B8F4		2	ROM 13 IY (not 464)
&B8F6		2	ROM 14 IY (not 464)
&B8F8		2	ROM 15 IY (not 464)
&B8FA		6	6 bytes of &FF
	&B1BA	14	14 bytes of &00
&B900	&B900	12*3	High Kernel Jumpblock (on the 464 this block is 11*3 bytes in size)
&B924	&B921	&1C0	routines used by the High Kernel Jumpblock (on the 464 this is &1C8 bytes in size)
&BAE4	&BAE9		bytes of &FF (&1C bytes on 6128, &17 bytes on 464)
&BB00	&BB00	26*3	Key Manager Jumpblock
&BB4E	&BB4E	36*3	Text VDU Jumpblock
&BBBA	&BBBA	23*3	Graphics VDU Jumpblock
&BBFF	&BBFF	34*3	Screen Pack Jumpblock
&BC65	&BC65	22*3	Cassette (and Disc if fitted) Manager Jumpblock
&BCA7	&BCA7	11*3	Sound Manager Jumpblock
&BCC8	&BCC8	25*3	Kernel Jumpblock
&BD13	&BD13	26*3	Machine Pack Jumpblock (on the 464 this block is 14*3 bytes in size)
&BD61	&BD3D	32*3	Maths Jumpblock (on the 464 this block is 48*3 bytes in size)
&BDCC	&BDCC	14*3	Firmware Indirections (on the 464 this block is 13*3 bytes in size)
&BDF7	&BDF4		bytes of &00 (&09 bytes on 6128, &0C bytes on the 464) the lower limit of Machine Stack if no Disc Drive
&BE00	&BE00	&40	&40 bytes of &FF
&BE40	&BE40	&4x	used by the AMSDOS ROM if a disc drive is fitted (otherwise &4x bytes of &FF)
&BE40	&BE40	2	(address &A910)
&BE42	&BE42	2	address of drive A XDPB
&BE44	&BE44	9	Disc Set Up timing block:
&BE44	&BE44	2	motor on period (default &0032; fastest &0023 @ 20mS)
&BE46	&BE46	2	motor off period (default &00FA; fastest &00C8 @ 20mS)
&BE48	&BE48	1	write current off period (default &AF @ 10æS)
&BE49	&BE49	1	head settle time (default &0F @ 1mS)
&BE4A	&BE4A	1	step rate period (default &0C; fastest &0A @ 1mS)
&BE4B	&BE4B	1	head unload delay (default &01)
&BE4C	&BE4C	1	b0=non DMA mode; b1 to b7=head load delay (default &03)
&BE4D	&BE4D	2	
&BE4F	&BE4F	1	Drive Header Information Block:
&BE4F	&BE4F	1	last track used
&BE50	&BE50	1	head number (&00)
&BE51	&BE51	1	last sector used

6128	464	Size	Comments on the memory locations
&BE52	&BE52	1	log2(sector size)-7
&BE53	&BE53	1	
&BE54	&BE54	1	
&BE55	&BE55	1	
&BE56	&BE56	1	
&BE58	&BE58	1	
&BE59	&BE59	1	
&BE5D	&BE5D	1	
&BE5E	&BE5E	1	
&BE5F	&BE5F	1	disc motor flag (&00=off;&01=on - strangely reversed)
&BE60	&BE60	2	address of buffer for directory entries block (&A930)
&BE62	&BE62	2	as &BE76 (ie&A9B0)
&BE64	&BE64	2	
&BE66	&BE66	1	disc retries (default &10)
&BE67	&BE67	&11	AMSDOS Ticker and Event Block:
&BE67	&BE67	2	ticker chaining address
&BE69	&BE69	2	tick count
&BE6B	&BE6B	2	recharge count
&BE6D	&BE6D	2	event chaining address
&BE6F	&BE6F	1	count
&BE70	&BE70	1	class (asynchronous event)
&BE71	&BE71	2	ROM routine address (&C9D6)
&BE73	&BE73	1	ROM select number (&07 ie the AMSDOS/CPM ROM)
&BE74	&BE74	1	last sector number used
&BE75	&BE75	1	
&BE76	&BE76	2	address of «K buffer, or of header info block (for WRITE SECTOR etc)
&BE78	&BE78	1	disc error message flag (&00=on; &FF=off - reversed again)
&BE7D	&BE7D	2	address of AMSDOS reserved area (&A700)
&BE7F	&BE7F	x	area used by AMSDOS to copy routines into RAM for running
&BE80	&BE80	&80	&80 bytes of &FF (limit of machine stack if disc drive fitted)
&BF00	&BF00	xy	&xy bytes of &00)
&BFxy			machine stack (in theory this stack could extend down much further)
&BFFF	&BFFF		upper limit of machine stack

The area from &C000 to &FFFF is taken up by the screen memory - the layout of which is illustrated below. Printed below are diagrams which show how the CPC uses the bytes of screen memory in the different MODEs. For each byte:

- in MODE 2 (where there are two colours only, each pixel needs only one bit - either on or off)

**bit7 bit6 bit5 bit4 bit3 bit2 bit1 bit0**  
 p0 p1 p2 p3 p4 p5 p6 p7

- (the pixels are arranged with p0 being the leftmost one, etc)
- in MODE 1 (where four colours are available and so two bits are needed for each pixel - 1 byte represents 4 pixels)

**bit7 bit6 bit5 bit4 bit3 bit2 bit1 bit0**  
 p0(1) p1(1) p2(1) p3(1) p0(0) p1(0) p2(0) p3(0)

- (each pixel is twice as wide as in MODE 2)
- in MODE 0 (where sixteen colours are possible and four bits are needed for each pixel - 1 byte represents 2 pixels)

**bit7 bit6 bit5 bit4 bit3 bit2 bit1 bit0**  
 p0(0) p1(0) p0(2) p1(2) p0(1) p1(1) p0(3) p1(3)

- (each pixel is four times as wide as in MODE 2)

**NB:** The numbers in brackets show which bit of the pixel's pen number the screen byte bit refers to. For example in MODE 1, the 4 most significant bits of the byte hold bit 1 of the pixel's pen value and the least significant bits hold bit 0 of the pen value.

LINE	R0W0	R0W1	R0W2	R0W3	R0W4	R0W5	R0W6	R0W7
1	C000	C800	D000	D800	E000	E800	F000	F800
2	C050	C850	D050	D850	E050	E850	F050	F850
3	C0A0	C8A0	D0A0	D8A0	E0A0	E8A0	F0A0	F8A0
4	C0F0	C8F0	D0F0	D8F0	E0F0	E8F0	F0F0	F8F0
5	C140	C940	D140	D940	E140	E940	F140	F940
6	C190	C990	D190	D990	E190	E990	F190	F990
7	C1E0	C9E0	D1E0	D9E0	E1E0	E9E0	F1E0	F9E0
8	C230	CA30	D230	DA30	E230	EA30	F230	FA30
9	C280	CA80	D280	DA80	E280	EA80	F280	FA80
10	C2D0	CAD0	D2D0	DAD0	E2D0	EAD0	F2D0	FAD0
11	C320	CB20	D320	DB20	E320	EB20	F320	FB20
12	C370	CB70	D370	DB70	E370	EB70	F370	FB70
13	C3C0	CBC0	D3C0	DBC0	E3C0	EBC0	F3C0	FBC0
14	C410	CC10	D410	DC10	E410	EC10	F410	FC10
15	C460	CC60	D460	DC60	E460	EC60	F460	FC60

<b>16</b>	C4B0	CCB0	D4B0	DCB0	E4B0	ECB0	F4B0	FCB0
<b>17</b>	C500	CD00	D500	DD00	E500	ED00	F500	FD00
<b>18</b>	C550	CD50	D550	DD50	E550	ED50	F550	FD50
<b>19</b>	C5A0	CDA0	D5A0	DDA0	E5A0	EDA0	F5A0	FDA0
<b>20</b>	C5F0	CDF0	D5F0	DDF0	E5F0	ED50	F550	FD50
<b>21</b>	C640	CE40	D640	DE40	E640	EE40	F640	FE40
<b>22</b>	C690	CE90	D690	DE90	E690	EE90	F690	FE90
<b>23</b>	C6E0	CEE0	D6E0	DEE0	E6E0	EEE0	F6E0	FEE0
<b>24</b>	C730	CF30	D730	DF30	E730	EF30	F730	FF30
<b>25</b>	C780	CF80	D780	DF80	E780	EF80	F780	FF80
<b>spare start</b>	C7D0	CFD0	D7D0	DFD0	E7D0	EFD0	F7D0	FFD0
<b>spare end</b>	C7FF	CFFF	D7FF	DFFF	E7FF	EFFF	F7FF	FFFF

Once the whole screen has been scrolled in any direction, the table will become incorrect. On scrolling, all the above addresses will have an offset (MOD &800) added, derived as follows:

- +&02 per scroll to the left (2, 1 or ½ character in MODE 2, MODE 1 or MODE 0 respectively)
- -&02 per scroll to the right (2, 1 or ½ character in MODE 2, MODE 1 or MODE 0 respectively)
- +&50 per scroll up one line
- -&50 per scroll down one line

If scrolled far enough, a screen row may sit across the boundaries of the screen memory area, whose bottom end will then wrap around to join up with the top (ie byte &FFFF will be followed by byte &C000 assuming the normal screen area). If before scrolling however, a window had been set up smaller than the whole screen then the table will remain accurate despite any scrolling. The `spare' areas of screen memory are filled with bytes of the relevant PAPER value each time there is a full screen CLS, and are not really available for other uses. After scrolling the spare areas may be used as screen with other bytes becoming spare.





# The Firmware Guide – Summary

The Firmware Jumpblock is the recommended method of communicating with the routines in the lower ROM - it is used by BASIC, and it should also be used by other programs. The reason for using the jumpblock is that the routines in the lower ROM are located at different positions on the different machines. The entries in the jumpblock, however, are all in the same place - the instructions in the jumpblock redirect the computer to the correct place in the lower ROM. Thus, providing a program uses the jumpblock, it should work on any CPC computer. By altering the firmware jumpblock it is possible to make the computer run a different routine from normal. This could either be a different routine in the lower or upper ROM, or a routine written by the user - this is known as 'patching the jumpblock'. It is worth noting that because BASIC uses the firmware jumpblock quite heavily, it is possible to alter the effect of BASIC commands. The following example will change the effect of calling SCR SET MODE (&BC0E) - instead of changing the mode, any calls to this location will print the letter 'A'. The first thing to do is to assemble the piece of code that will be used to print the letter - this is printed below and starts at &4000.

```
ORG &4000  
LD A,65 ; 65 is ASCII FOR 'A'  
CALL &BB5A ; TXT OUTPUT  
RET ; return from subroutine
```

The jumpblock entry for SCR SET MODE is now patched so that it reroutes all calls to &BC0E away from the lower ROM and to our custom routine at &4000. This is done by changing the bytes at &BC0E, &BC0F and &BC10 to &C3, &00, &40 respectively (ie JP &4000). Any calls to &BC0E or MODE commands will now print the letter A instead of changing mode. The indirections jumpblock contains a small number of routines which are called by the rest of the firmware. By altering this jumpblock, it is possible to alter the way in which the firmware operates on a large scale - thus it is not always necessary to patch large numbers of entries in the firmware jumpblock. There are two jumpblocks which are to do with the Kernel (ie the high and low Kernel jumpblocks). The high jumpblock allows ROM states and interrupts to be altered, and also controls the introduction of RSXs. The low jumpblock contains general routines and restart instructions which are used by the computer for its own purposes.



# The Kernel

## **&BCC8 KL CHOKE OFF**

Action	Clears all event queues and timer lists, with the exception of keyboard scanning and sound routines
Entry	No entry conditions
Exit	B contains the foreground ROM select address (if any), DE contains the ROM entry address, C holds the ROM select address for a RAM foreground program, AF and HL are corrupt, and all others are preserved

## **&BCCB KL ROM WALK**

Action	Finds and initialises all background ROMs
Entry	DE holds the address of the first usable byte of memory, HL holds the address of the last usable byte
Exit	DE holds the address of the new first usable byte of memory, HL holds the address of the new last usable byte, AF and BC are corrupt, and all other registers are preserved
Notes	This routine looks at the ROM select addresses from 0 to 15 (1 to 7 for the 464) and calls the initialisation routine of any ROMs present; these routines may reserve memory by adjusting DE and HL before returning control to KL ROM WALK, and the ROM is then added to the list of command handling routines

## **&BCCE KL INIT BACK**

Action	Finds and initialises a specific background ROM
Entry	C contains the ROM select address of the ROM, DE holds the address of the first usable byte of memory, HL holds the address of the last usable byte of memory
Exit	DE holds the address of the new first usable byte of memory, HL holds the address of the new last usable byte. AF and B are corrupt, and all other registers are preserved
Notes	The ROM select address must be in the range of 0 to 15 (or 1 to 7 for the 464) although address 7 is for the AMSDOS/CPM ROM if present. The ROM's initialisation routine is then called and some memory may be reserved for the ROM by adjusting the values of DE and HL before returning control to KL INIT BACK

## **&BCD1 KL LOG EXT**

Action	Logs on a new RSX to the firmware
Entry	BC contains the address of the RSX's command table, HL contains the address of four bytes exclusively for use by the firmware
Exit	DE is corrupt, and all other registers are preserved

## **&BCD4 KL FIND COMMAND**

Action	Searches an RSX, background ROM or foreground ROM, to find a command in its table
Entry	HL contains the address of the command name (in RAM only) which is being searched for
Exit	If the name was found in a RSX or background ROM then Carry is true, C contains the ROM select address, and HL contains the address of the routine; if the command was not found, then Carry is false, C and HL are corrupt; in either case, A, B and DE are corrupt, and all others are preserved
Notes	The command names should be in upper case and the last character should have &80 added to it; the sequence of searching is RSXs, then ROMs with lower numbers before ROMs with higher numbers

## **&BCD7 KL NEW FRAME FLY**

Action	Sets up a frame flyback event block which will be acted on whenever a frame flyback occurs
Entry	HL contains the address of the event block in the central 32K of RAM, B contains the event class. C contains the ROM select address (if any), and DE contains the address of the event routine
Exit	AF, DE and HL are corrupt, and all other registers are preserved

## **&BCDA KL ADD FRAME FLY**

Action	Adds an existing but deleted frame flyback event block to the list of routines run when a frame flyback occurs
Entry	HL contains the address of the event block (in the central 32K of RAM)

Exit AF, DE and HL are corrupt, and all others are preserved

#### **&BCDD KL DEL FRAME FLY**

Action Removes a frame flyback event block from the list of routines which are mn when a frame flyback occurs

Entry HL contains the address of the event block

Exit AF, DE and HL are corrupt, and all others are preserved

#### **&BCE0 KL NEW FAST TICKER**

Action Sets up a fast ticker event block which will be run whenever the 1/300th second ticker interrupt occurs

Entry HL contains the address of the event block (in the central 32K of RAM), B contains the event class, C contains the ROM select address (if any), and DE contains the address of the event routine

Exit AF, DE and HL are corrupt, and all other registers are preserved

#### **&BCE3 KL ADD FAST TICKER**

Action Adds an existing but deleted fast ticker event block to the list of routines which are run when the 1/300th sec ticker interrupt occurs

Entry HL contains the address of the event block

Exit AF, DE and HL are corrupt, and all the other registers are preserved

#### **&BCE6 KL DEL FAST TICKER**

Action Removes a fast ticker event block from the list of routines run when the 1/300th sec ticker interrupt occurs

Entry HL contains the address of the event block

Exit AF, DE and HL are corrupt, and all others are preserved

#### **&BCE9 KL ADD TICKER**

Action Sets up a ticker event block which will be run whenever a 1/50th second ticker interrupt occurs

Entry HL contains the address of the event block (in the central 32K of RAM), DE contains the initial value for the counter, and BC holds the value that the counter will be given whenever it reaches zero

Exit AF, BC, DE and HL are corrupt, and all the other registers are preserved

Notes Every 1/50th of a second all the tick blocks are looked at and their counter is decreased by 1; when the counter reaches zero, the event is 'kicked' and the counter is loaded with the value in BC; any tick block with a counter of 0 is ignored, and therefore if the value in BC is 0, the event will be kicked only once and ignored after that

#### **&BCEC KL DEL TICKER**

Action Removes a ticker event block from the list of routines that are run when a 1/50th sec ticker interrupt occurs

Entry HL contains the address of the event block

Exit If the event block was found, then Carry is true, and DE holds the value remaining of the counter; if the event block was not found, then Carry is false, and DE is corrupt; in both cases, A, HL and the other flags are corrupt, and all other registers are preserved

#### **&BCEF KL INIT EVENT**

Action Initialises an event block

Entry HL contains the address of the event block (in the central 32K of RAM), B contains the class of event, and C contains the ROM select address, and DE holds the address of the event routine

Exit HL holds the address of the event block+7, and all other registers are preserved

Notes The event class is derived as follows  
bit 0 - indicates a near address  
bits 1 to 4 - hold the synchronous event priority  
bit 5 - always zero  
bit 6 - if bit 6 is set, then it is an express event  
bit 7 - if bit 7 is set, then it is an asynchronous event.

Asynchronous events do not have priorities; if it is an express asynchronous event, then its event routine is called from the interrupt path; if it is a normal asynchronous event, then its event routine is called just before returning from the interrupt; if it is an express synchronous event, then it has a higher

priority than normal synchronous events, and it may not be disabled through use of KL EVENT DISABLE; if the near address bit is set, then the routine is located in the central 32K of RAM and is called directly, so saving time; no event may have a priority of zero

**&BCF2 KL EVENT**

Action Kicks an event block  
Entry HL contains the address of the event block  
Exit AF, BC, DE and HL are corrupt, and all other registers are preserved

**&BCF5 KL SYNC RESET**

Action Clears the synchronous event queue  
Entry No entry conditions  
Exit AF and HL are corrupt, and all other registers are preserved  
Notes When using this routine, all events that are waiting to be dealt with are simply discarded

**&BCF8 KL DEL SYNCHRONOUS**

Action Removes a synchronous event from the event queue  
Entry HL contains the address of the event block  
Exit AF, BC, DE and HL are corrupt, and all other registers are preserved

**&BCFB KL NEXT SYNC**

Action Finds out if there is a synchronous event with a higher priority  
Entry No entry conditions  
Exit If there is an event to be processed, then Carry is true, HL contains the address of the event block, and A contains the priority of the previous event; if there is no event to be processed, then Carry is false, and A and HL are corrupt; in either case, DE is corrupt, and all other registers are preserved

**&BCFE KL DO SYNC**

Action Runs a synchronous event routine  
Entry HL contains the address of the event block  
Exit AF, BC, DE and HL are corrupt, and all other registers are preserved  
Notes See KL DONE SYNC below

**&BD01 KL DONE SYNC**

Action Finishes running a synchronous event routine  
Entry A contains the priority of the previous event, and HL contains the address of the event block  
Exit AF, BC, DE and HL are corrupt, and all other registers are preserved  
Notes When an event that is waiting to be processed has been found by KL NEXT SYNC, the event routine should be run by KL DO SYNC; after this KL DONE SYNC should be called so that the event counter can be decreased - if the counter is greater than zero then the event is placed back on the synchronous event queue

**&BD04 KL EVENT DISABLE**

Action Disables normal synchronous events  
Entry No entry conditions  
Exit HL is corrupt, and all other registers are preserved

**&BD07 KL EVENT ENABLE**

Action Enables normal synchronous events  
Entry No entry conditions  
Exit HL is corrupt, and all other registers are preserved

**&BD0A KL DISARM EVENT**

Action Disarms a specific event and stops it from occurring

Entry HL contains the address of the event block  
Exit AF is corrupt, and all other registers are preserved  
Notes This routine should be used to disarm only asynchronous events; see also KL DEL SYNCHRONOUS

#### **&BD0D KL TIME PLEASE**

Action Returns the time that has elapsed since the computer was switched on or reset (in 1/300ths of a second)  
Entry No entry conditions  
Exit DEHL contains the four byte count of the time elapsed, and all other registers are preserved  
Notes D holds the most significant byte of the time elapsed, and L holds the least significant; the four byte count overflows after approximately 166 days have elapsed.

#### **&BD10 KL TIME SET**

Action Sets the elapsed time (in 1/300ths of a second)  
Entry DEHL contains the four byte count of the time to set  
Exit AF is corrupt, and all other registers are preserved

## Low Kernel Jumpblock

#### **&0000 RESET ENTRY (RST 0)**

Action Resets the computer as if it has just been switched on  
Entry No entry conditions  
Exit This routine is never returned from  
Notes After initialisation of the hardware and firmware, control is handed over to ROM 0 (usually BASIC)

#### **&0008 LOW JUMP (RST 1)**

Action Jumps to a routine in either the lower ROM or low RAM  
Entry No entry conditions - all the registers are passed to the destination routine unchanged  
Exit The registers are as set by the routine in the lower ROM or RAM or are returned unaltered  
Notes The RST 1 instruction is followed by a two byte low address, which is defined as follows  
if bit 15 is set, then the upper ROM is disabled  
if bit 14 is set, then the lower ROM is disabled  
bits 13 to 0 contain the address of the routine to jump to. This command is used by the majority of entries in the main firmware jumpblock

#### **&000B KL LOW PCHL**

Action Jumps to a routine in either the lower ROM or low RAM  
Entry HL contains the low address - all the registers are passed to the destination routine unchanged  
Exit The registers are as set by the routine in the lower ROM or RAM or are returned unaltered  
Notes The two byte low address in the HL register pair is defined as follows  
if bit 15 is set, then the upper ROM is disabled  
if bit 14 is set, then the lower ROM is disabled  
bits 13 to 0 contain the address of the routine to jump to

#### **&000E PCBC INSTRUCTION**

Action Jumps to the specified address  
Entry BC contains the address to jump to - all the registers are passed to the destination routine unaltered  
Exit The registers are as set by the destination routine or are returned unchanged

#### **&0010 SIDE CALL (RST 2)**

Action Calls a routine in ROM, in a group of up to four foreground ROMs  
Entry No entry conditions - all the registers apart from IY are passed to the destination routine unaltered

Exit	IY is corrupt, and the other registers are as set by the destination routine or are returned unchanged
Notes	The RST 2 instruction is followed by a two byte side address, which is defined as follows bits 14 and 15 give a number between 0 and 3, which is added to the main foreground ROM select address - this is then used as the ROM select address bits 0 to 13 contain the address to which is added &C000 - this gives the address of the routine to be called
<b>&amp;0013 KL SIDE PCHL</b>	
Action	Calls a routine in another ROM
Entry	HL contains the side address - all the registers apart from IY are passed to the destination routine unaltered
Exit	IY is corrupt, and the other registers are as set by the destination routine or are returned unchanged
Notes	The two byte side address is defined as follows bits 14 and 15 give a number between 0 and 3, which is added to the main foreground ROM select address - this is then used as the ROM select address bits 0 to 13 contain the address to which is added &C000 - this gives the address of the routine to be called
<b>&amp;0016 PCDE INSTRUCTION</b>	
Action	Jumps to the specified address
Entry	DE contains the address to jump to - all the registers are passed to the destination routine unaltered
Exit	The registers are as set by the destination routine or are returned unchanged
<b>&amp;0018 FAR CALL (RST 3)</b>	
Action	Calls a routine anywhere in ROM or ROM
Entry	No entry conditions - all the registers apart from IY are passed to the destination routine unaltered
Exit	IY is preserved, and the other registers are as set by the destination routine or are returned unchanged
Notes	The RST 3 instruction is followed by a two byte in-line address. At this address, there is a three byte far address, which is defined as follows bytes 0 and 1 give the address of the routine to be called byte 2 is the ROM select byte which has values as follows &00 to &FB-- select the given upper ROM, enable the upper ROM and disable the lower ROM &FC - no change to the ROM selection, enable the upper and lower ROMs &FD - no change to the ROM selection, enable the upper ROM and disable the lower ROM &FE - no change to the ROM selection, disable the upper ROM and enable the lower ROM &FF - no change to the ROM selection, disable the upper and lower ROMs When it is returned from, the ROM selection and state are restored to their settings before the RST 3 command
<b>&amp;001B KL FAR PCHL</b>	
Action	Calls a routine, given by the far address in HL & C, anywhere in RAM or ROM
Entry	HL holds the address of the routine to be called, and C holds the ROM select byte - all the registers apart from IY are passed to the destination routine unaltered
Exit	IY is preserved, and the other registers are as set by the destination routine or are returned unchanged
Notes	See FAR CALL (RST 3) above for more details on the ROM select byte
<b>&amp;001E PCHL INSTRUCTION</b>	
Action	Jumps to the specified address
Entry	HL contains the address to jump to - all the registers are passed to the destination routine unaltered
Exit	The registers are as set by the destination routine or are returned unchanged
<b>&amp;0020 RAM LAM</b>	
Action	Puts the contents of a RAM memory location into the A register
Entry	HL contains the address of the memory location
Exit	A holds the contents of the memory location, and all other registers are preserved
Notes	This routine always reads from RAM, even if the upper or lower ROM is enabled
<b>&amp;0023 KL FAR CALL</b>	
Action	Calls a routine anywhere in RAM or ROM

Entry HL holds the address of the three byte far address that is to be used - all the registers apart from IY are passed to the destination routine unaltered

Exit IY is preserved, and the other registers are as set by the destination routine or are returned unchanged

Notes See FAR CALL above for more details on the three byte far address

#### **&0028 FIRM JUMP (RST 5)**

Action Jumps to a routine in either the lower ROM or the central 32K of RAM

Entry No entry conditions - all the registers are passed to the destination routine unchanged

Exit The registers are as set by the routine in the lower ROM or RAM or are returned unaltered

Notes The RST 5 instruction is followed by a two byte address, which is the address to jump to; before the jump is made, the lower ROM is enabled, and is disabled when the destination routine is returned from

#### **&0030 USER RESTART (RST 6)**

Action This is an RST instruction that may be set aside by the user for any purpose

Entry Defined by the user

Exit Defined by the user

Notes The bytes from &0030 to &0037 are available for the user to put their own code in if they wish

#### **&0038 INTERRUPT ENTRY (RST 7)**

Action Deals with normal interrupts

Entry No entry conditions

Exit All registers are preserved

Notes The RST 7 instruction must not be used by the user; any external interrupts that are generated by hardware on the expansion port will be dealt with by the EXT INTERRUPT routine (see Low Kernel Jumpblock)

#### **&003B EXT INTERRUPT**

Action This area is set aside for dealing with external interrupts that are generated by any extra hardware

Entry No entry conditions

Exit AF, BC, DE and HL are corrupt, and all other registers are preserved

Notes If any external hardware is going to generate interrupts, then the user must patch the area from &003B to &003F so that the computer can deal with the external interrupt; when an external interrupt occurs, the lower ROM is disabled and the code at &003B is called; the default external interrupt routine at &003B simply returns, and this will cause the computer to hang because the interrupt will continue to exist

## High Kernel Jumpblock

#### **&B900 KL U ROM ENABLE**

Action Enables the current upper ROM

Entry No entry conditions

Exit A contains the previous state of the ROM, the flags are corrupt, and all other registers are preserved

Notes After this routine has been called, all reading from addresses between &C000 and &FFFF refers to the upper ROM, and not the top 16K of RAM which is usually the screen memory; any writing to these addresses still affects the RAM as, by its nature, ROM cannot be written to

#### **&B903 KL U ROM DISABLE**

Action Disables the upper ROM

Entry No entry conditions

Exit A contains the previous state of the ROM, the flags are corrupt, and all other registers are preserved

Notes After this routine has been called, all reading from addresses between &C000 and &FFFF refers to the top 16K of RAM which is usually the screen memory



**&B906 KL L ROM ENABLE**

Action Enables the lower ROM

Entry No entry conditions

Exit A contains the previous state of the ROM, the flags are corrupt, and all other registers are preserved

Notes After this routine has been called, all reading from addresses between &0000 and &4000 refers to the lower ROM, and not the bottom 16K of RAM; any writing to these addresses still affects the RAM as a ROM cannot be written to; the lower ROM is automatically enabled when a firmware routine is called, and is then disabled when the routine returns

**&B909 KL L ROM DISABLE**

Action Disables the lower ROM

Entry No entry conditions

Exit A contains the previous state of the ROM, the flags are corrupt, and all other registers are preserved

Notes After this routine has been called, all reading from addresses between &0000 and &4000 refers to the bottom 16K of RAM; the lower ROM is automatically enabled when a firmware routine is called, and is then disabled when the routine returns

**&B90C KL ROM RESTORE**

Action Restores the ROM to its previous state

Entry A contains the previous state of the ROM

Exit AF is corrupt, and all other registers are preserved

Notes The previous four routines all return values in the A register which are suitable for use by KL ROM RESTORE

**&B90F KL ROM SELECT**

Action Selects an upper ROM and also enables it

Entry C contains the ROM select address of the required ROM

Exit C contains the ROM select address of the previous ROM, and B contains the state of the previous ROM

**&B912 KL CURR SELECTION**

Action Gets the ROM select address of the current ROM

Entry No entry conditions

Exit A contains the ROM select address of the current ROM, and all other registers are preserved

**&B915 KL PROBE ROM**

Action Gets the class and version of a specified ROM

Entry C contains the ROM select address of the required ROM

Exit A contains the class of the ROM, H holds the version number, L holds the mark number, B and the flags are corrupt, and all other registers are preserved

The ROM class may be one of the following:

Notes &00 - a foreground ROM  
&01 - a background ROM  
&02 - an extension foreground ROM  
&80 - the built in ROM (ie the BASIC ROM)

**&B918 KL ROM DESELECT**

Action Selects the previous upper ROM and sets its state

Entry C contains the ROM select address of the ROM to be reselected, and B contains the state of the required ROM

Exit C contains the ROM select address of the current ROM, B is corrupt, and all others are preserved

Notes This routine reverses the action of KL ROM SELECT, and uses the values that it returns in B and C

**&B91B KL LDIR**

Action Switches off the upper and lower ROMs, and moves a block of memory

Entry As for a standard LDIR instruction (ie DE holds the destination location, HL points to the first byte to be moved, and BC holds the length of the block to be moved)

Exit F, BC, DE and HL are set as for a normal LDIR instruction, and all other registers are preserved

#### **&B91E KL LDDR**

Action Switches off the upper and lower ROMs, and moves a block of memory

Entry As for a standard LDDR instruction (ie DE holds the first destination location, HL points to the highest byte in memory to be moved, and BC holds the number of bytes to be moved)

Exit F, BC, DE and HL, are set as for a normal LDDR instruction, and all other registers are preserved

#### **&B921 KL POLL SYNCHRONOUS**

Action Tests whether an event with a higher priority than the current event is waiting to be dealt with

Entry No entry conditions

Exit If there is a higher priority event, then Carry is false; if there is no higher priority event, then Carry is true; in either case, A and the other flags are corrupt, and all other registers are preserved

#### **&B92A KL SCAN NEEDED**

Action Ensures that the keyboard is scanned when the next ticker interrupt occurs

Entry No entry conditions

Exit AF and HL are corrupt, and all other registers are preserved

Notes This routine is useful for scanning the keyboard when interrupts are disabled and normal key scanning is not occurring

# The Key Manager

## **&BB00 KM INITIALISE**

Action Initialises the Key Manager and sets up everything as it is when the computer is first switched on; the key buffer is emptied, Shift and Caps lock are turned off and all the expansion and translation tables are reset to normal; also see the routine KM RESET below

Entry No entry conditions

Exit AF, BC, DE and HL corrupt, and all other registers are preserved

## **&BB03 KM RESET**

Action Resets the Key Manager; the key buffer is emptied and all current keys/characters are ignored

Entry No entry conditions

Exit AF, BC, DE and HL are corrupt and all other registers are preserved

Notes See also KM INITIALISE above. On the 664 or 6128, the key buffer can also be cleared separately by calling the KM FLUSH routine

## **&BB06 KM WAIT CHAR**

Action Waits for the next character from the keyboard buffer

Entry No entry conditions

Exit Carry is true, A holds the character value, the other flags are corrupt, and all other registers are preserved

## **&BB09 KM READ CHAR**

Action Tests to see if a character is available from the keyboard buffer, but doesn't wait for one to become available

Entry No entry conditions

Exit If a character was available, then Carry is true, and A contains the character; otherwise Carry is false, and A is corrupt; in both cases, the other registers are preserved

## **&BB0C KM CHAR RETURN**

Action Saves a character for the next use of KM WAIT CHAR or KM READ CHAR

Entry A contains the ASCII code of the character to be put back

Exit All registers are preserved

## **&BB0F KM SET EXPAND**

Action Assigns a string to a key code

Entry B holds the key code; C holds the length of the string; HL contains the address of the string (must be in RAM)

Exit If it is OK, then Carry is true; otherwise Carry is false; in either case, A, BC, DE and HL are corrupt, and all other registers are preserved

## **&BB12 KM GET EXPAND**

Action Reads a character from an expanded string of characters

Entry A holds an expansion token (ie a key code) and L holds the character position number (starts from 0)

Exit If it is OK, then Carry is true, and A holds the character; otherwise Carry is false, and A is corrupt; in either case, DE and flags are corrupt, and the other registers are preserved

## **&BB15 KM EXP BUFFER**

Action Sets aside a buffer area for character expansion strings

Entry DE holds the address of the buffer and HL holds the length of the buffer

Exit If it is OK, then Carry is true; otherwise Carry is false; in either case, A, BC, DE and HL are corrupt

Notes The buffer must be in the central 32K of RAM and must be at least 49 bytes long

**&BB18 KM WAIT KEY**

Action Waits for a key to be pressed - this routine does not expand any expansion tokens

Entry No entry conditions

Exit Carry is true, A holds the character or expansion token, and all other registers are preserved

**&BB1B KM READ KEY**

Action Tests whether a key is available from the keyboard

Entry No entry conditions

Exit If a key is available, then Carry is true, and A contains the character; otherwise Carry is false, and A is corrupt; in either case, the other registers are preserved

Notes Any expansion tokens are not expanded

**&BB1E KM TEST KEY**

Action Tests if a particular key (or joystick direction or button) is pressed

Entry A contains the key/joystick number

Exit If the requested key is pressed, then Zero is false; otherwise Zero is true for both, Carry is false A and HL are corrupt. C holds the Shift and Control status and others are preserved

Notes After calling this, C will hold the state of shift and control - if bit 7 is set then Control was pressed, and if bit 5 is set then Shift was pressed

**&BB21 KM GET STATE**

Action Gets the state of the Shift and Caps locks

Entry No entry conditions

Exit If L holds &FF then the shift lock is on, but if L holds &00 then the Shift lock is off; if H holds &FF then the caps lock is on, and if H holds &00 then the Caps lock is off; whatever the outcome, all the other registers are preserved

**&BB24 KM GET JOYSTICK**

Action Reads the present state of any joysticks attached

Entry No entry conditions

Exit H and A contains the state of joystick 0, L holds that state of joystick 1, and all others are preserved

Notes The joystick states are bit significant and are as follows  
 Bit 0 - Up Bit  
 1 - Down Bit  
 2 - Left Bit  
 3 - Right Bit  
 4 - Fire2 Bit  
 5 - Fire1 Bit  
 6 - Spare Bit  
 7 - Always zero  
 The bits are set when the corresponding buttons or directions are operated

**&BB27 KM SET TRANSLATE**

Action Sets the token or character that is assigned to a key when neither Shift nor Control are pressed

Entry A contains the key number and B contains the new token or character

Exit AF and HL are corrupt, and all other registers are preserved

Notes Special values for B are as follows  
 &80 to &9F - these values correspond to the expansion tokens  
 &FD - this causes the caps lock to toggle on and off  
 &FE - this causes the shift lock to toggle on and off  
 &FF - causes this key to be ignored

**&BB2A KM GET TRANSLATE**

Action Finds out what token or character will be assigned to a key when neither Shift nor Control are pressed

Entry A contains the key number

Exit A contains the token/character that is assigned, HL and flags are corrupt, and all others are preserved

Notes See KM SET TRANSLATE for special values that can be returned

#### **&BB2D KM SET SHIFT**

Action Sets the token or character that will be assigned to a key when Shift is pressed as well

Entry A contains the key number and B contains the new token or character

Exit AF and HL are corrupt, and all others are preserved

Notes See KM SET TRANSLATE for special values that can be set

#### **&BB30 KM GET SHIFT**

Action Finds out what token/character will be assigned to a key when Shift is pressed as well

Entry A contains the key number

Exit A contains the token/character that is assigned, HL and flags are corrupt, and all others are preserved

Notes See KM SET TRANSLATE for special values that can be returned

#### **&BB33 KM SET CONTROL**

Action Sets the token or character that will be assigned to a key when Control is pressed as well

Entry A contains the key number and B contains the new token/character

Exit AF and HL are corrupt, and all others are preserved

Notes See KM SET TRANSLATE for special values that can be set

#### **&BB36 KM GET CONTROL**

Action Finds out what token or character will be assigned to a key when Control is pressed as well

Entry A contains the key number

Exit A contains the token/character that is assigned, HL and flags are corrupt and all others are preserved

Notes See KM SET TRANSLATE for special values that can be set

#### **&BB39 KM SET REPEAT**

Action Sets whether a key may repeat or not

Entry A contains the key number B contains &00 if there is no repeat and &FF if it is to repeat

Exit AF, BC and HL are corrupt, and all others are preserved

#### **&BB3C KM GET REPEAT**

Action Finds out whether a key is set to repeat or not

Entry A contains a key number

Exit If the key repeats, then Zero is false; if the key does not repeat, then Zero is true; in either case, A, HL and flags are corrupt, Carry is false, and all other registers are preserved

#### **&BB3F KM SET DELAY**

Action Sets the time that elapses before the first repeat, and also set the repeat speed

Entry H contains the time before the first repeat, and L holds the time between repeats (repeat speed)

Exit AF is corrupt, and all others are preserved

Notes The values for the times are given in 1/50th seconds, and a value of 0 counts as 256

#### **&BB42 KM GET DELAY**

Action Finds out the time that elapses before the first repeat and also the repeat speed

Entry No entry conditions

Exit H contains the time before the first repeat, and L holds the time between repeats, and all others are preserved

#### **&BB45 KM ARM BREAK**

Action Arms the Break mechanism

Entry DE holds the address of the Break handling routine, C holds the ROM select address for this routine

Exit AF, BC, DE and HL are corrupt, and all the other registers are preserved

**&BB48 KM DISARM BREAK**

Action Disables the Break mechanism

Entry No entry conditions

Exit AF and HL are corrupt, and all the other registers are preserved

**&BB4B KM BREAK EVENT**

Action Generates a Break interrupt if a Break routine has been specified by KM ARM BREAK

Entry No entry conditions

Exit AF and HL are corrupt, and all other registers are preserved

# The Text VDU

## **&BB4E** TXT INITIALISE

Action Initialise the text VDU to its settings when the computer is switched on, includes resetting all the text VDU indirections, selecting Stream 0, resetting the text paper to pen 0 and the text pen to pen 1, moving the cursor to the top left corner of the screen and setting the writing mode to be opaque

Entry No entry conditions

Exit AF, BC, DE and HL are corrupt, and all others are preserved

## **&BB51** TXT RESET

Action Resets the text VDU indirections and the control code table

Entry No entry conditions

Exit AF, BC, DE and HL are corrupt, and all the other registers are preserved

## **&BB54** TXT VDU ENABLE

Action Allows characters to be printed on the screen in the current stream

Entry No entry conditions

Exit AF is corrupt, and all other registers are preserved

## **&BB57** TXT VDU DISABLE

Action Prevents characters from being printed to the current stream

Entry No entry conditions

Exit AF is corrupt, and all the other registers are preserved

## **&BB5A** TXT OUTPUT

Action Output a character or control code (&00 to &1F) to the screen

Entry A contains the character to output

Exit All registers are preserved

Notes Any control codes are obeyed and nothing is printed if the VDU is disabled; characters are printed using the TXT OUT ACTION routine; if using graphics printing mode, then control codes are printed and not obeyed

## **&BB5D** TXT WR CHAR

Action Print a character at the current cursor position - control codes are printed and not obeyed

Entry A contains the character to be printed

Exit AF, BC, DE and HL are corrupt, and all others are preserved

Notes This routine uses the TXT WRITE CHAR indirection to put the character on the screen

## **&BB60** TXT RD CHAR

Action Read a character from the screen at the current cursor position

Entry No entry conditions

Exit If it was successful then A contains the character that was read from the screen and Carry is true; otherwise Carry is false, and A holds 0; in either case, the other flags are corrupt, and all registers are preserved

Notes This routine uses the TXT UNWRITE indirection

## **&BB63** TXT SET GRAPHIC

Action Enables or disables graphics print character mode

Entry To switch graphics printing mode on, A must be non-zero; to turn it off, A must contain zero

Exit AF corrupt, and all other registers are preserved

Notes When turned on, control codes are printed and not obeyed; characters are printed by GRA WR CHAR

**&BB66 TXT WIN ENABLE**

Action Sets the boundaries of the current text window - uses physical coordinates

Entry H holds the column number of one edge, D holds the column number of the other edge, L holds the line number of one edge, and E holds the line number of the other edge

Exit AF, BC, DE and HL are corrupt

Notes The window is not cleared but the cursor is moved to the top left corner of the window

**&BB69 TXT GET WINDOW**

Action Returns the size of the current window - returns physical coordinates

Entry No entry conditions

Exit H holds the column number of the left edge, D holds the column number of the right edge, L holds the line number of the top edge, E holds the line number of the bottom edge, A is corrupt, Carry is false if the window covers the entire screen, and the other registers are always preserved

**&BB6C TXT CLEAR WINDOW**

Action Clears the window (of the current stream) and moves the cursor to the top left corner of the window

Entry No entry conditions

Exit AF, BC, DE and HL are corrupt, and all others are preserved

**&BB6F TXT SET COLUMN**

Action Sets the cursor's horizontal position

Entry A contains the logical column number to move the cursor to

Exit AF and HL are corrupt, and all the other registers are preserved

Notes See also TXT SET CURSOR

**&BB72 TXT SET ROW**

Action Sets the cursor's vertical position

Entry A contains the logical line number to move the cursor to

Exit AF and HL are corrupt, and all others are preserved

Notes See also TXT SET CURSOR

**&BB75 TXT SET CURSOR**

Action Sets the cursor's vertical and horizontal position

Entry H contains the logical column number and L contains the logical line number

Exit AF and HL are corrupt, and all the others are preserved

Notes See also TXT SET COLUMN and TXT SET ROW

**&BB78 TXT GET CURSOR**

Action Gets the cursor's current position

Entry No entry conditions

Exit H holds the logical column number, L holds the logical line number, and A contains the roll count, the flags are corrupt, and all the other registers are preserved

Notes The roll count is increased when the screen is scrolled down, and is decreased when it is scrolled up

**&BB7B TXT CUR ENABLE**

Action Allows the text cursor to be displayed (if it is allowed by TXT CUR ON) - intended for use by the user

Entry No entry conditions

Exit AF is corrupt, and all other registers are preserved

**&BB7E TXT CUR DISABLE**

Action Prevents the text cursor from being displayed -intended for use by the user



Entry No entry conditions  
Exit AF is corrupt, and all others are preserved

**&BB81 TXT CUR ON**

Action Allows the text cursor to be displayed - intended for use by the operating system

Entry No entry conditions  
Exit All registers and flags are preserved

**&BB84 TXT CUR OFF**

Action Prevents the text cursor from being displayed -intended for use by the operating system

Entry No entry conditions  
Exit All registers and flags are preserved

**&BB87 TXT VALIDATE**

Action Checks whether a cursor position is within the current window

Entry H contains the logical column number to check, and L holds the logical line number  
H holds the logical column number where the next character will be printed, L holds the logical line number; if printing at this position would make the window scroll up, then Carry is false and B holds &FF; if printing at this position would make the window scroll down, then Carry is false and B contains &00; if printing at the specified cursor position would not scroll the window, then Carry is true and B is corrupt; always, A and the other flags are corrupt, and all others are preserved

**&BB8A TXT PLACE CURSOR**

Action Puts a `cursor blob' on the screen at the current cursor position

Entry No entry conditions  
Exit AF is corrupt, and all other registers are preserved

Notes It is possible to have more than one cursor in a window (see also TXT DRAW CURSOR); do not use this routine twice without using TXT REMOVE CURSOR between

**&BB8D TXT REMOVE CURSOR**

Action Removes a `cursor blob' from the current cursor position

Entry No entry conditions  
Exit AF is corrupt, and all the others are preserved

Notes This should be used only to remove cursors created by TXT PLACE CURSOR, but see also TXT UNDRAW CURSOR

**&BB90 TXT SET PEN**

Action Sets the foreground PEN for the current stream  
Entry A contains the PEN number to use  
Exit AF and HL are corrupt, and all other registers are preserved

**&BB93 TXT GET PEN**

Action Gets the foreground PEN for the current stream  
Entry No entry conditions  
Exit A contains the PEN number, the flags are corrupt, and all other registers are preserved

**&BB96 TXT SET PAPER**

Action Sets the background PAPER for the current stream  
Entry A contains the PEN number to use  
Exit AF and HL are corrupt, and all other registers are preserved

**&BB99 TXT GET PAPER**

Action Gets the background PAPER for the current stream  
Entry No entry conditions

Exit A contains the PEN number, the flags are corrupt, and all other registers are preserved

#### **&BB9C TXT INVERSE**

Action Swaps the current PEN and PAPER colours over for the current stream

Entry No entry conditions

Exit AF and HL are corrupt, and all others are preserved

#### **&BB9F TXT SET BACK**

Action Sets the character write mode to either opaque or transparent

Entry For transparent mode, A must be non-zero; for opaque mode, A has to hold zero

Exit AF and HL are corrupt, and all other registers are preserved

Notes Setting the character write mode has no effects on the graphics VDU

#### **&BBA2 TXT GET BACK**

Action Gets the character write mode for the current stream

Entry No entry conditions

Exit If in transparent mode, A is non-zero; in opaque mode, A is zero; in either case DE, HL and flags are corrupt, and the other registers are preserved

#### **&BBA5 TXT GET MATRIX**

Action Gets the address of a character matrix

Entry A contains the character whose matrix is to be found

Exit If it is a user-defined matrix, then Carry is true; if it is in the lower ROM then Carry is false; in either event, HL contains the address of the matrix, A and other flags are corrupt, and others are preserved

Notes The character matrix is stored in 8 bytes; the first byte is for the top row of the character, and the last byte refers to the bottom row of the character; bit 7 of a byte refers to the leftmost pixel of a line, and bit 0 refers to the rightmost pixel in Mode 2.

#### **&BBA8 TXT SET MATRIX**

Action Installs a matrix for a user-defined character

Entry A contains the character which is being defined and HL contains the address of the matrix to be used

Exit If the character is user-definable then Carry is true; otherwise Carry is false, and no action is taken; in both cases AF, BC, DE and HL are corrupt, and all other registers are preserved

#### **&BBAB TXT SET M TABLE**

Action Sets the address of a user-defined matrix table

Entry DE is the first character in the table and HL is the table's address (in the central 32K of RAM)

Exit If there are no existing tables then Carry is false, and A and HL are both corrupt; otherwise Carry is true, A is the first character and HL is the table's address; in both cases BC, DE and the other flags are corrupt

#### **&BBAE TXT GET M TABLE**

Action Gets the address of a user-defined matrix table

Entry No entry conditions

Exit See TXT SET M TABLE above for details of the values that can be returned

#### **&BBB1 TXT GET CONTROLS**

Action Gets the address of the control code table

Entry No entry conditions

Exit HL contains the address of the table, and all others are preserved

Notes The table has 32 entries, and each entry has three bytes

byte 1 is the number of parameters needed by the control code  
bytes 2 and 3 are the address of the routine, in the Lower ROM, to execute the control code

#### **&BBB4 TXT STR SELECT**

Action Selects a new VDU text stream

Entry A contains the value of the stream to change to

Exit A contains the previously selected stream, HL and the flags are corrupt, and all others are preserved

**&BBB7 TXT SWAP STREAMS**

Action Swaps the states of two stream attribute tables

Entry B contains a stream number, and C contains the other stream number

Exit AF, BC, DE and HL are corrupt, and all other registers are preserved

Notes The foreground pen and paper, the window size, the cursor position, the character write mode and graphic character mode are all exchanged between the two streams



# The Graphics VDU

## **&BBBA GRA INITIALISE**

Action	Initialises the graphics VDU to its default set-up (ie its set-up when the computer is switched on)
Entry	No entry conditions
Exit	AF, BC, DE and HL are corrupt, and all other registers are preserved
Notes	Sets the graphics indirections to their defaults, sets the graphic paper to text pen 0 and the graphic pen to text pen 1, reset the graphics origin and move the graphics cursor to the bottom left of the screen, reset the graphics window and write mode to their defaults

## **&BBBD GRA RESET**

Action	Resets the graphics VDU
Entry	No entry conditions
Exit	AF, BC, DE and HL are corrupt, and all others are preserved
Notes	Resets the graphics indirections and the graphics write mode to their defaults

## **&BBC0 GRA MOVE ABSOLUTE**

Action	Moves the graphics cursor to an absolute screen position
Entry	DE contains the user X-coordinate and HL holds the user Y-coordinate
Exit	AF, BC, DE and HL are corrupt, and all other registers are preserved

## **&BBC3 GRA MOVE RELATIVE**

Action	Moves the graphics cursor to a point relative to its present screen position
Entry	DE contains the X-distance to move and HL holds the Y-distance
Exit	AF, BC, DE and HL are corrupt, and all others are preserved

## **&BBC6 GRA ASK CURSOR**

Action	Gets the graphics cursor's current position
Entry	No entry conditions
Exit	DE holds the user X-coordinate, HL holds the user Y-coordinate, AF is corrupt, and all others are preserved

## **&BBC9 GRA SET ORIGIN**

Action	Sets the graphics user origin's screen position
Entry	DE contains the standard X-coordinate and HL holds the standard Y-coordinate
Exit	AF, BC, DE and HL are corrupt, and all other registers are preserved

## **&BBCC GRA GET ORIGIN**

Action	Gets the graphics user origin's screen position
Entry	No entry conditions
Exit	DE contains the standard X-coordinate and HL holds the standard Y-coordinate, and all others are preserved

## **&BBCF GRA WIN WIDTH**

Action	Sets the left and right edges of the graphics window
Entry	DE contains the standard X-coordinate of one edge and HL holds the standard X-coordinate of the other side
Exit	AF, BC, DE and HL are corrupt, and all the other registers are preserved
Notes	The default window covers the entire screen and is restored to its default when the mode is changed; used in conjunction with GRA WIN HEIGHT

## **&BBD2 GRA WIN HEIGHT**

Action Sets the top and bottom edges of the graphics window  
Entry DE contains the standard Y-coordinate of one side and HL holds the standard Y-coordinate of the other side  
Exit AF, BC, DE and HL are corrupt, and all others are preserved  
Notes See GRA WIN WIDTH for further details

#### **&BBD5 GRA GET W WIDTH**

Action Gets the left and right edges of the graphics window  
Entry No entry conditions  
Exit DE contains the standard X-coordinate of the left edge and HL contains the standard Y-coordinate of the right edge, AF is corrupt, and all other registers are preserved

#### **&BBD8 GRA GET W HEIGHT**

Action Gets the top and bottom edges of the graphics window  
Entry No entry conditions  
Exit DE contains the standard Y-coordinate of the top edge and HL contains the standard Y-coordinate of the bottom edge, AF is corrupt, and all other registers are preserved

#### **&BBD8 GRA CLEAR WINDOW**

Action Clears the graphics window to the graphics paper colour and moves the cursor back to the user origin  
Entry No entry conditions  
Exit AF, BC, DE and HL are corrupt, and all other registers are preserved

#### **&BBDE GRA SET PEN**

Action Sets the graphics PEN  
Entry A contains the required text PEN number  
Exit AF is corrupt, and all other registers are preserved

#### **&BBE1 GRA GET PEN**

Action Gets the graphics PEN  
Entry No entry conditions  
Exit A contains the text PEN number, the flags are corrupt, and all other registers are preserved

#### **&BBE4 GRA SET PAPER**

Action Sets the graphics PAPER  
Entry A contains the required text PEN number  
Exit AF corrupt, and all others are preserved

#### **&BBE7 GRA GET PAPER**

Action Gets the graphics PAPER  
Entry No entry conditions  
Exit A contains the text PEN number, the flags are corrupt, and all others are preserved

#### **&BBEA GRA PLOT ABSOLUTE**

Action Plots a point at an absolute user coordinate, using the GRA PLOT indirection  
Entry DE contains the user X-coordinate and HL holds the user Y-coordinate  
Exit AF, BC, DE and HL are corrupt, and all others are preserved

#### **&BBED GRA PLOT RELATIVE**

Action Plots a point at a position relative to the current graphics cursor, using the GRA PLOT indirection  
Entry DE contains the relative X-coordinate and HL contains the relative Y-coordinate  
Exit AF, BC, DE and HL are corrupt, and all other registers are preserved

#### **&BBF0 GRA TEST ABSOLUTE**

Action Moves to an absolute position, and tests the point there using the GRA TEST indirection  
Entry DE contains the user X-coordinate and HL holds the user Y-coordinate for the point you wish to test  
Exit A contains the pen at the point, and BC, DE, HL and flags are corrupt, and all others are preserved

**&BBF3 GRA TEST RELATIVE**

Action Moves to a position relative to the current position, and tests the point there using the GRA TEST indirection  
Entry DE contains the relative X-coordinate and HL contains the relative Y-coordinate  
Exit A contains the pen at the point, and BC, DE, HL and flags are corrupt, and all others are preserved

**&BBF6 GRA LINE ABSOLUTE**

Action Draws a line from the current graphics position to an absolute position, using GRA LINE  
Entry DE contains the user X-coordinate and HL holds the user Y-coordinate of the end point  
Exit AF, BC, DE and HL are corrupt, and all others are preserved  
Notes The line will be plotted in the current graphics pen colour (may be masked to produce a dotted line on a 6128)

**&BBF9 GRA LINE RELATIVE**

Action Draws a line from the current graphics position to a relative screen position, using GRA LINE  
Entry DE contains the relative X-coordinate and HL contains the relative Y-coordinate  
Exit AF, BC, DE and HL are corrupt, and all other registers are preserved  
Notes See GRA LINE ABSOLUTE above for details of how the line is plotted

**&BBFC GRA WR CHAR**

Action Writes a character onto the screen at the current graphics position  
Entry A contains the character to be put onto the screen  
Exit AF, BC, DE and HL are corrupt, and all the other registers are preserved  
Notes As in BASIC, all characters including control codes are printed; the character is printed with its top left corner at the current graphics position; the graphics position is moved one character width to the right so that it is ready for another character to be printed





# The Screen Pack

## **&BBFF SCR INITIALISE**

Action	Initialises the Screen Pack to the default values used when the computer is first switched on
Entry	No entry conditions
Exit	AF, BC, DE and HL are corrupt, and all others are preserved
Notes	All screen indirections are restored to their default settings, as are inks and flashing speeds; the mode is switched to MODE 1 and the screen is cleared with PEN 0; the screen address is moved to &C000 and the screen offset is set to zero

## **&BC02 SCR RESET**

Action	Resets the Screen Pack's indirections, flashing speeds and inks to their default values
Entry	No entry conditions
Exit	AF, BC, DE and HL are corrupt, and all other registers are preserved

## **&BC05 SCR SET OFFSET**

Action	Sets the screen offset to the specified values - this can cause the screen to scroll
Entry	HL contains the required offset, which should be even
Exit	AF and HL are corrupt, and all others are preserved
Notes	The screen offset is reset to 0 whenever its mode is set, or it is cleared by SCR CLEAR (but not BASIC's CLS)

## **&BC08 SCR SET BASE**

Action	Sets the location in memory of the screen - effectively can only be &C000 or &4000
Entry	A contains the most significant byte of the screen address required
Exit	AF and HL are corrupt, and all other registers are preserved
Notes	The screen memory can only be set at 16K intervals (ie &0000, &4000, &8000, &C000) and when the computer is first switched on the 16K of screen memory is located at &C000)

## **&BC0B SCR GET LOCATION**

Action	Gets the location of the screen memory and also the screen offset
Entry	No entry conditions
Exit	A holds the most significant byte of the screen address, HL holds the current offset, and all others are preserved

## **&BC0E SCR SET MODE**

Action	Sets the screen mode
Entry	A contains the mode number - it has the same value and characteristics as in BASIC
Exit	AF, BC, DE and HL are corrupt, and all others are preserved
Notes	The windows are set to cover the whole screen and the graphics origin is set to the bottom left corner of the screen; in addition, the current stream is set to zero, and the screen offset is zeroed

## **&BC11 SCR GET MODE**

Action	Gets the current screen mode
Entry	No entry conditions
Exit	If the mode is 0, then Carry is true, Zero is false, and A contains 0; if the mode is 1, then Carry is false, Zero is true, and A contains 1; if the mode is 2, then Carry is false, Zero is false, and A contains 2; in all cases the other flags are corrupt and all the other registers are preserved

## **&BC14 SCR CLEAR**

Action	Clears the whole of the screen
Entry	No entry conditions

Exit AF, BC, DE and HL are corrupt, and all others are preserved

#### **&BC17 SCR CHAR LIMITS**

Action Gets the size of the whole screen in terms of the numbers of characters that can be displayed

Entry No entry conditions

Exit B contains the number of characters across the screen, C contains the number of characters down the screen, AF is corrupt, and all other registers are preserved

#### **&BC1A SCR CHAR POSITION**

Action Gets the memory address of the top left corner of a specified character position

Entry H contains the character physical column and L contains the character physical row

Exit HL contains the memory address of the top left corner of the character, B holds the width in bytes of a character in the present mode, AF is corrupt, and all other registers are preserved

#### **&BC1D SCR DOT POSITION**

Action Gets the memory address of a pixel at a specified screen position

Entry DE contains the base X-coordinate of the pixel, and HL contains the base Y-coordinate

Exit HL contains the memory address of the pixel, C contains the bit mask for this pixel, B contains the number of pixels stored in a byte minus 1, AF and DE are corrupt, and all others are preserved

#### **&BC20 SCR NEXT BYTE**

Action Calculates the screen address of the byte to the right of the specified screen address (may be on the next line)

Entry HL contains the screen address

Exit HL holds the screen address of the byte to the right of the original screen address, AF is corrupt, all others are preserved

#### **&BC23 SCR PREV BYTE**

Action Calculates the screen address of the byte to the left of the specified screen address (this address may actually be on the previous line)

Entry HL contains the screen address

Exit HL holds the screen address of the byte to the left of the original address, AF is corrupt, all others are preserved

#### **&BC26 SCR NEXT LINE**

Action Calculates the screen address of the byte below the specified screen address

Entry HL contains the screen address

Exit HL contains the screen address of the byte below the original screen address, AF is corrupt, and all the other registers are preserved

#### **&BC29 SCR PREV LINE**

Action Calculates the screen address of the byte above the specified screen address

Entry HL contains the screen address

Exit HL holds the screen address of the byte above the original address, AF is corrupt, and all others are preserved

#### **&BC2C SCR INK ENCODE**

Action Converts a PEN to provide a mask which, if applied to a screen byte, will convert all of the pixels in the byte to the appropriate PEN

Entry A contains a PEN number

Exit A contains the encoded value of the PEN, the flags are corrupt, and all other registers are preserved

Notes The mask returned is different in each of the screen modes

#### **&BC2F SCR INK DECODE**

Action Converts a PEN mask into the PEN number (see SCR INK ENCODE for the reverse process)

Entry A contains the encoded value of the PEN

- Exit A contains the PEN number, the flags are corrupt, and all others are preserved
- &BC32 SCR SET INK**
- Action Sets the colours of a PEN - if the two values supplied are different then the colours will alternate (flash)
- Entry contains the PEN number, B contains the first colour, and C holds the second colour
- Exit AF, BC, DE and HL are corrupt, and all others are preserved
- &BC35 SCR GET INK**
- Action Gets the colours of a PEN
- Entry A contains the PEN number
- Exit B contains the first colour, C holds the second colour, and AF, DE and HL are corrupt, and all others are preserved
- &BC38 SCR SET BORDER**
- Action Sets the colours of the border - again if two different values are supplied, the border will flash
- Entry B contains the first colour, and C contains the second colour
- Exit AF, BC, DE and HL are corrupt, and all others are preserved
- &BC3B SCR GET BORDER**
- Action Gets the colours of the border
- Entry No entry conditions
- Exit B contains the first colour, C holds the second colour, and AF, DE and HL are corrupt, and all others are preserved
- &BC3E SCR SET FLASHING**
- Action Sets the speed with which the border's and PENs' colours flash
- Entry H holds the time that the first colour is displayed, L holds the time the second colour is displayed for
- Exit AF and HL are corrupt, and all other registers are preserved
- Notes The length of time that each colour is shown is measured in 1/50ths of a second, and a value of 0 is taken to mean 256 \* 1/50 seconds - the default value is 10 \* 1/50 seconds
- &BC41 SCR GET FLASHING**
- Action Gets the periods with which the colours of the border and PENs flash
- Entry No entry conditions
- Exit H holds the duration of the first colour, L holds the duration of the second colour, AF is corrupt, and all other registers are preserved - see SCR SET FLASHING for the units of time used
- &BC44 SCR FILL BOX**
- Action Fills an area of the screen with an ink - this only works for 'character-sized' blocks of screen
- Entry A contains the mask for the ink that is to be used, H contains the left hand column of the area to fill, D contains the right hand column, L holds the top line, and E holds the bottom line of the area (using physical coordinates)
- Exit AF, BC, DE and HL are corrupt, and all others are preserved
- &BC17 SCR FLOOD BOX**
- Action Fills an area of the screen with an ink - this only works for 'byte-sized' blocks of screen
- Entry C contains the encoded PEN that is to be used, HL contains the screen address of the top left hand corner of the area to fill, D contains the width of the area to be filled in bytes, and E contains the height of the area to be filled in screen lines
- Exit AF, BC, DE and HL are corrupt, and all other registers are preserved
- Notes The whole of the area to be filled must lie on the screen otherwise unpredictable results may occur
- &BC4A SCR CHAR INVERT**
- Action Inverts a character's colours; all pixels in one PEN's colour are printed in another PEN's colour, and vice versa

Entry B contains one encoded PEN, C contains the other encoded PEN, H contains the physical column number, and L contains the physical line number of the character that is to be inverted

Exit AF, BC, DE and HL are corrupt, and all the other registers are preserved

#### **&BC4D SCR HW ROLL**

Action Scrolls the entire screen up or down by eight pixel rows (ie one character line)

Entry B holds the direction that the screen will roll, A holds the encoded PAPER which the new line will appear in

Exit AF, BC, DE and HL are corrupt, and all others are preserved

Notes This alters the screen offset; to roll down, B must hold zero, and to roll upwards B must be non-zero

#### **&BC50 SCR SW ROLL**

Action Scrolls part of the screen up or down by eight pixel lines - only for 'character-sized' blocks of the screen

Entry B holds the direction to roll the screen, A holds the encoded PAPER which the new line will appear in, H holds the left column of the area to scroll, D holds the right column, L holds the top line, E holds the bottom line

Exit AF, BC, DE and HL are corrupt, and all other registers are preserved

Notes The area of the screen is moved by copying it; to roll down, B must hold zero, and to roll upwards B must be non-zero; this routine uses physical coordinates

#### **&BC53 SCR UNPACK**

Action Changes a character matrix from its eight byte standard form into a set of pixel masks which are suitable for the current mode - four \*8 bytes are needed in mode 0, two \*8 bytes in mode 1, and 8 bytes in mode 2

Entry HL contains the address of the matrix, and DE contains the address where the masks are to be stored

Exit AF, BC, DE and HL are corrupt, and all other registers are preserved

#### **&BC56 SCR REPACK**

Action Changes a set of pixel masks (for the current mode) into a standard eight byte character matrix

Entry A contains the encoded foreground PEN to be matched against (ie the PEN that is to be regarded as being set in the character), H holds the physical column of the character to be 'repacked', L holds the physical line of the character, and DE contains the address of the area where the character matrix will be built

Exit AF, BC, DE and HL are corrupt, and all the others are preserved

#### **&BC59 SCR ACCESS**

Action Sets the screen write mode for graphics

Entry A contains the write mode (0=Fill, 1=XOR, 2=AND, 3=OR)

Exit AF, BC, DE and HL are corrupt, and all other registers are preserved

Notes The fill mode means that the ink that plotting was requested in is the ink that appears on the screen; in XOR mode, the specified ink is XORed with ink that is at that point on the screen already before plotting; a similar situation occurs with the AND and OR modes

#### **&BC5C SCR PIXELS**

Action Puts a pixel or pixels on the screen regardless of the write mode specified by SCR ACCESS above

Entry B contains the mask of the PEN to be drawn with, C contains the pixel mask, and HL holds the screen address of the pixel

Exit AF is corrupt, and all others are preserved

#### **&BC5F SCR HORIZONTAL**

Action Draws a horizontal line on the screen using the current graphics write mode

Entry A contains the encoded PEN to be drawn with, DE contains the base X-coordinate of the start of the line, BC contains the end base X-coordinate, and HL contains the base Y-coordinate

Exit AF, BC, DE and HL are corrupt, and all other registers are preserved

Notes The start X-coordinate must be less than the end X-coordinate

## **&BC62 SCR VERTICAL**

Action Draws a vertical line on the screen using the current graphics write mode

Entry A contains the encoded PEN to be drawn with, DE contains the base X-coordinate of the line, HL holds the start base Y-coordinate, and BC contains the end base Y-coordinate - the start coordinate must be less than the end coordinate

Exit AF, BC, DE and HL are corrupt, and all the other registers are preserved



# The Cassette/AMSDOS manager

**NOTE:** Some of these routines are only applicable to the cassette manager; where a disc version exists it is indicated by an asterisk (\*) next to the command name. These disc version jumpblocks are automatically installed by the Operating System on switch on.

## **&BC65 CAS INITIALISE**

Action Initialises the cassette manager

Entry No entry conditions

Exit AF, BC, DE and HL are corrupt, and all the other registers are preserved

Notes Both read and write streams are closed; tape messages are switched on; the default speed is reselected

## **&BC68 CAS SET SPEED**

Action Sets the speed at which the cassette manager saves programs

Entry HL holds the length of 'half a zero' bit, and A contains the amount of precompensation

Exit AF and HL are corrupt

Notes The value in HL is the length of time that half a zero bit is written as; a one bit is twice the length of a zero bit; the default values (ie SPEED WRITE 0) are 333 microseconds (HL) and 25 microseconds (A) for SPEED WRITE 1, the values are given as 107 microseconds and 50 microseconds respectively

## **&BC6B CAS NOISY**

Action Enables or disables the display of cassette handling messages

Entry To enable the messages then A must be 0, otherwise the messages are disabled

Exit AF is corrupt, and all other registers are preserved

## **&BC6E CAS START MOTOR**

Action Switches on the tape motor

Entry No entry conditions

Exit If the motor operates properly then Carry is true; if ESC was pressed then Carry is false; in either case, A contains the motor's previous state, the flags are corrupt, and all others are preserved

## **&BC71 CAS STOP MOTOR**

Action Switches off the tape motor

Entry No entry conditions

Exit If the motor turns off then Carry is true; if ESC was pressed then Carry is false; in both cases, A holds the motor's previous state, the other flags are corrupt, all others are preserved

## **&BC74 CAS RESTORE MOTOR**

Action Resets the tape motor to its previous state

Entry A contains the previous state of the motor (eg from CAS START MOTOR or CAS STOP MOTOR)

Exit If the motor operates properly then Carry is true; if ESC was pressed then Carry is false; in all cases, A and the other flags are corrupt and all others are preserved

## **&BC77 \*CAS IN OPEN**

Action Opens an input buffer and reads the first block of the file

Entry B contains the length of the filename, HL contains the filename's address, and DE contains the address of the 2K buffer to use for reading the file

Exit If the file was opened successfully, then Carry is true, Zero is false, HL holds the address of a buffer containing the file header data, DE holds the address of the destination for the file, BC holds the file length, and A holds the file type; if the read stream is already open then Carry and Zero are false, A contains an error number (664/6128 only) and BC, DE and HL are corrupt; if ESC was pressed by the user, then Carry is false, Zero is true, A holds an error number (664/6128 only) and BC, DE and HL are corrupt; in all cases, IX and the other flags are corrupt, and the others are preserved

Notes A filename of zero length means `read the neXt file on the tape'; the stream remains open until it is closed by either CAS IN CLOSE or CAS IN ABANDON

Disc Similar to tape except that if there is no header on the file, then a fake header is put into memory by this routine

#### **&BC7A \*CAS IN CLOSE**

Action Closes an input file

Entry No entry conditions

Exit If the file was closed successfully, then Carry is true and A is corrupt; if the read stream was not open, then Carry is false, and A holds an error code (664/6128 only); in both cases, BC, DE, HL and the other flags are all corrupt

Disc All the above applies, but also if the file failed to close for any other reason, then Carry is false, Zero is true and A contains an error number; in all cases the drive motor is turned off immediately

#### **&BC7D \*CAS IN ABANDON**

Action Abandons an input file

Entry No entry conditions

Exit AF, BC, DE and HL are corrupt, and all others are preserved

Disc All the above applies for the disc routine

#### **&BC80 \*CAS IN CHAR**

Action Reads in a single byte from a file

Entry No entry conditions

Exit If a byte was read, then Carry is true, Zero is false, and A contains the byte read from the file; if the end of file was reached, then Carry and Zero are false, A contains an error number (664/6128 only) or is corrupt (for the 464); if ESC was pressed, then Carry is false, Zero is true, and A holds an error number (664/6128 only) or is corrupt (for the 464); in all cases, IX and the other flags are corrupt, and all others are preserved

Disc All the above applies for the disc routine

#### **&BC83 \*CAS IN DIRECT**

Action Reads an entire file directly into memory

Entry HL contains the address where the file is to be placed in RAM

Exit If the operation was successful, then Carry is true, Zero is false, HL contains the entry address and A is corrupt; if it was not open, then Carry and Zero are both false, HL is corrupt, and A holds an error code (664/6128) or is corrupt (464); if ESC was pressed, Carry is false, Zero is true, HL is corrupt, and A holds an error code (664/6128 only); in all cases, BC, DE and IX and the other flags are corrupt, and the others are preserved

Notes This routine cannot be used once CAS IN CHAR has been used

Disc All the above applies to the disc routine

#### **&BC86 \*CAS RETURN**

Action Puts the last byte read back into the input buffer so that it can be read again at a later time

Entry No entry conditions

Exit All registers are preserved

Notes The routine can only return the last byte read and at least one byte must have been read

Disc All the above applies to the disc routine

#### **&BC89 \*CAS TEST EOF**

Action Tests whether the end of file has been encountered

Entry No entry conditions

Exit If the end of file has been reached, then Carry and Zero are false, and A is corrupt; if the end of file has not been encountered, then Carry is true, Zero is false, and A is corrupt; if ESC was pressed then Carry is false, Zero is true and A contains an error number (664/6128 only); in all cases, IX and the other flags



are corrupt, and all others are preserved

Disc All the above applies to the disc routine

**&BC8C \*CAS OUT OPEN**

Action Opens an output file

Entry B contains the length of the filename, HL contains the address of the filename, and DE holds the address of the 2K buffer to be used

Exit If the file was opened correctly, then Carry is true, Zero is false, HL holds the address of the buffer containing the file header data that will be written to each block, and A is corrupt; if the write stream is already open, then Carry and Zero are false, A holds an error number (66~/6128) and HL is corrupt; if ESC was pressed then Carry is false, Zero is true, A holds an error number (664/6128) and HL is corrupt; in all cases, BC, DE, IX and the other flags are corrupt, and the others are preserved

Notes The buffer is used to store the contents of a file block before it is actually written to tape

Disc The same as for tape except that the filename must be present in its usual AMSDOS format

**&BC8F \*CAS OUT CLOSE**

Action Closes an output file

Entry No entry conditions

Exit If the file was closed successfully, then Carry is true, Zero is false, and A is corrupt; if the write stream was not open, then Carry and Zero are false and A holds an error code (664/6128 only); if ESC was pressed then Carry is false, Zero is true, and A contains an error code (664/6128 only); in all cases, BC, DE, HL, IX and the other flags are all corrupt

Notes The last block of a file is written only when this routine is called; if writing the file is to be abandoned, then CAS OUT ABANDON should be used instead

Disc All the above applies to the disc routine

**&BC92 \*CAS OUT ABANDON**

Action Abandons an output file

Entry No entry conditions

Exit AF, BC, DE and HL are corrupt, and all others are preserved

Notes When using this routine, the current last block of the file is not written to the tape

Disc Similar to the tape routine; if more than 16K of a file has been written to the disc, then the first 16K of the file will exist on the disc with a file extension of .\$\$\$ because each 16K section of the file requires a separate directory entry

**&BC95 \*CAS OUT CHAR**

Action Writes a single byte to a file

Entry A contains the byte to be written to the file output buffer

Exit If a byte was written to the buffer, then Carry is true, Zero is false, and A is corrupt; if the file was not open, then Carry and Zero are false, and A contains an error number (664/6128 only) or is corrupt (on the 464); if ESC was pressed, then Carry is false, Zero is true, and A contains an error number (664/6128 only) or it is corrupt (on the 464); in all cases, IX and the other flags are corrupt, and all others are preserved

Notes If the 2K buffer is full of data then it is written to the tape before the new character is placed in the buffer; it is important to call CAS OUT CLOSE when all the data has been sent to the file so that the last block is written to the tape

Disc All the above applies to the disc routine

**&BC98 \*CAS OUT DIRECT**

Action Writes an entire file directly to tape

Entry HL contains the address of the data which is to be written to tape, DE contains the length of this data, BC contains the execution address, and A contains the file type

Exit If the operation was successful, then Carry is true, Zero is false, and A is corrupt; if the file was not open, Carry and Zero are false, A holds an error number (664/6128) or is corrupt (464); if ESC was pressed, then Carry is false, Zero is true, and A holds an error code (664/6128 only); in all cases BC, DE, HL, IX and the other flags are corrupt, and the others are preserved

Notes This routine cannot be used once CAS OUT CHAR has been used

Disc All the above applies to the disc routine

#### **&BC9B \*CAS CATALOG**

Action Creates a catalogue of all the files on the tape

Entry DE contains the address of the 2K buffer to be used to store the information

Exit If the operation was successful, then Carry is true, Zero is false, and A is corrupt; if the read stream is already being used, then Carry and Zero are false, and A holds an error code (664/6128 or is corrupt (for the 464); in all cases, BC, DE, HL, IX and the other flags are corrupt and all others are preserved

Notes This routine is only left when the ESC key is pressed (cassette only) and is identical to BASIC's CAT command

Disc All the above applies, except that a sorted list of files is displayed; system files are not listed by this routine

#### **&BC9E CAS WRITE**

Action Writes data to the tape in one long file (ie not in 2K blocks)

Entry HL contains the address of the data to be written to tape, DE contains the length of the data to be written, and A contains the sync character

Exit If the operation was successful, then Carry is true and A is corrupt; if an error occurred then Carry is false and A contains an error code; in both cases, BC, DE, HL and IX are corrupt, and all other registers are preserved

Notes For header records the sync character is &2C, and for data it is &16; this routine starts and stops the cassette motor and also turns off interrupts whilst writing data

#### **&BCA1 CAS READ**

Action Reads data from the tape in one long file (ie as originally written by CAS WRITE only)

Entry HL holds the address to place the file, DE holds the length of the data, and A holds the expected sync character

Exit If the operation was successful, then Carry is true and A is corrupt; if an error occurred then Carry is false and A contains an error code; in both cases, BC, DE, HL and IX are corrupt, and all other registers are preserved

Notes For header records the sync character is &2C, and for data it is &16; this routine starts and stops the cassette motor and turns off interrupts whilst reading data

#### **&BCA4 CAS CHECK**

Action Compares the contents of memory with a file record (ie header or data) on tape

Entry HL contains the address of the data to check, DE contains the length of the data and A holds the sync character that was used when the file was originally written to the tape

Exit If the two are identical, then Carry is true and A is corrupt; if an error occurred then Carry is false and A holds an error code; in all cases, BC, DE, HL, IX and other flags are corrupt, and all other registers are preserved

Notes For header records the sync character is &2C, and for data it is &16; this routine starts and stops the cassette motor and turns off interrupts whilst reading data; does not have to read the whole of a record, but must start at the beginning

## **AMSDOS and BIOS Firmware**

#### **&C033 BIOS SET MESSAGE**

Action Enables or disables disc error messages

Entry To enable messages, A holds &00; to disable messages, A holds &FF

Exit A holds the previous state, HL and the flags are corrupt, and all others are preserved

Notes Enabling and disabling the messages can also be achieved by poking &BE78 with &00 or &FF

#### **&C036 BIOS SETUP DISC**

**Action** Sets the parameters which effect the disc speed

**Entry** HL holds the address of the nine bytes which make up the parameter block

**Exit** AF, BC, DE and HL are corrupt, and all other registers are preserved

The parameter block is arranged as follows

bytes 0&1 - the motor on time in 20ms units; the default is &0032; the fastest is &0023

bytes 2&3 - the motor off time in 20ms units; the default is &00FA; the fastest is &00C8

**Notes** byte 4 - the write off time in 10æœs units; the default is &AF; should not be changed

byte 5 - the head settle time in 1ms units; the default is &0F; should not be changed

byte 6 - the step rate time in 1ms units; the default is &0C; the fastest is &0A

byte 7 - the head unload delay; the default is &01; should not be changed

byte 8 - a byte of &03 and this should be left unaltered

#### **&C039 BIOS SELECT FORMAT**

**Action** Sets a format for a disc

**Entry** A holds the type of format that is to be selected

**Exit** AF, BC, DE and HL are corrupt, and all the other registers are preserved

To select one of the normal disc formats, the following values should be put into the A register

Data format - &C1

**Notes** System format - &41 - Used by CP/M

IBM format - &01 - compatible with CP/M-86

This routine sets the extended disc parameter block (XDPB) at &A890 to &A8A8 - to set other formats, the XDPB must be altered directly

#### **&C03C BIOS READ SECTOR**

**Action** Reads a sector from a disc into memory

**Entry** HL holds the address in memory where the sector will be read to, E holds the drive number (&00 for drive A, and &01 for drive B), D holds the track number, and C holds the sector number

**Exit** If the sector was read properly, then Carry is true, A holds 0, and HL is preserved; if the read failed, then Carry is false, A holds an error number, and HL is corrupt; in either case, the other flags are corrupt, and all other registers are preserved

#### **&C03F BIOS WRITE SECTOR**

**Action** Writes a sector from memory onto disc

**Entry** HL holds the address of memory which will be written to the disc, E holds the drive number (&00 for drive A, and &01 for drive B), D holds the track number, and C holds the sector number

**Exit** If the sector was written properly, then Carry is true, A holds 0, and HL is preserved; if the write failed, then Carry is false, A holds an error number, and HL is corrupt; in either case, the other flags are corrupt, and all other registers are preserved

#### **&C042 BIOS FORMAT TRACK**

**Action** Formats a complete track, inserts sectors, and fills the track with bytes of &E5

**Entry** HL contains the address of the header information buffer which holds the header information blocks, E contains the drive number (&00 for drive A, and &01 for drive B), and D holds the track number

**Exit** if the formatting process was successful, then Carry is true, A holds 0, and HL is preserved; if the formatting process failed, then Carry is false, A holds an error number, and HL is corrupt; in either case, the other flags are corrupt, and all the other registers are preserved

The header information block is laid out as follows

byte 0 - holds the track number

byte 1 - holds the head number (set to zero)

**Notes** byte 2 - holds the sector number

byte 3 - holds  $\log_2(\text{sector size}) - 7$  (usually either &02=512 bytes, or &03=1024 bytes).

Header information blocks must be set up contiguously for every sector on the track, and in the same sequence that they are to be laid down (eg &C1, &C6, &C2, &C7, &C3, &C8, &C4, &C9, &C5)

#### **&C045 BIOS MOVE TRACK**

**Action** Moves the disc drive head to the specified track

**Entry** E holds the drive number (&00 for drive A, and &01 for drive B), and D holds the track number

**Exit** If the head was moved successfully, then Carry is true, A holds 0, and HL is preserved; if the move failed, then Carry is false, A holds an error number, and HL is corrupt; in both cases, the other flags are

corrupt, and all other registers are preserved

Notes There is normally no need to call this routine as READ SECTOR, WRITE SECTOR and FORMAT TRACK automatically move the head to the correct position

#### **&C048 BIOS GET STATUS**

Action Returns the status of the specified drive

Entry A holds the drive number (&00 for drive A, and &01 for drive B)

Exit If Carry is true, then A holds the status byte, and HL is preserved; if Carry is false, then A is corrupt, and HL holds the address of the byte before the status byte; in either case, the other flags are preserved, and all other registers are preserved

Notes The status byte indicates the drive's status as follows  
if bit 6 is set, then either the write protect is set or the disc is missing  
if bit 5 is set, then the drive is ready and the disc is fitted (whether the disc is formatted or not)  
if bit 4 is set, then the head is at track 0

#### **&C04B BIOS SET RETRY COUNT**

Action Sets the number of times the operation is retried in the event of disc error

Entry A holds the number of retries required

Exit A holds the previous number of retries, HL and the flags are corrupt, and all others are preserved

Notes The default setting is &10, and the minimum setting is &01; the number of retries can also be altered by poking &BE66 with the required value

#### **&C56C GET SECTOR DATA**

Action Gets the data of a sector on the current track

Entry E holds the drive number

Exit If a formatted disc is present, then Carry is true, and HL is preserved; if an unformatted disc is present or the disc is missing, then Carry is false, and HL holds the address of the byte before the status byte; in either case, A and the other flags are corrupt, and all other registers are preserved

Notes The track number is held at &BE4F, the head number is held at &BE50, the sector number is held at &BE51, and the  $\log_2(\text{sector size})-7$  is held at &BE52; disc parameters do not need to be set to the format of the disc; this routine is best used with the disc error messages turned off

# The Sound Manager

## **&BCA7 SOUND RESET**

Action Resets the sound manager by clearing the sound queues and abandoning any current sounds

Entry No entry conditions

Exit AF, BC, DE and HL are corrupt, and all others are preserved

## **&BCAA SOUND QUEUE**

Action Adds a sound to the sound queue of a channel

Entry HL contains the address of a series of bytes which define the sound and are stored in the central 32K of RAM

Exit If the sound was successfully added to the queue, then Carry is true and HL is corrupt; if one of the sound queues was full, then Carry is false and HL is preserved; in either case, A, BC, DE, IX and the other flags are corrupt, and all others are preserved

Notes The bytes required to define the sound are as follows  
byte 0 - channel status byte  
byte 1 - volume envelope to use  
byte 2 - tone envelope to use  
bytes 3&4 - tone period  
byte 5 - noise period  
byte 6 - start volume  
bytes 7&8 - duration of the sound, or envelope repeat count

## **&BCAD SOUND CHECK**

Action Gets the status of a sound channel

Entry A contains the channel to test - for channel A, bit 0 set; for channel B, bit 1 set; for channel C, bit 2 set

Exit A contains the channel status, BC, DE, HL and flags are corrupt, and all others are preserved

Notes The channel status returned is bit significant, as follows  
bits 0 to 2 - the number of free spaces in the sound queue  
bit 3 - trying to rendezvous with channel A  
bit 4 - trying to rendezvous with channel B  
bit 5 - trying to rendezvous with channel C  
bit 6 - holding the channel  
bit 7 - producing a sound

## **&BCB0 SOUND ARM EVENT**

Action Sets up an event which will be activated when a space occurs in a sound queue

Entry A contains the channel to set the event up for (see SOUND CHECK for the bit values this can take), and HL holds the address of the event block

Exit AF, BC, DE and HL are corrupt, and all other registers are preserved

Notes The event block must be initialised by KL INIT EVENT and is disarmed when the event itself is run

## **&BCB3 SOUND RELEASE**

Action Allows the playing of sounds on specific channels that had been stopped by SOUND HOLD

Entry A contains the sound channels to be released (see SOUND CHECK for the bit values this can take)

Exit AF, BC, DE, HL and IX are corrupt, and all others are preserved

## **&BCB6 SOUND HOLD**

Action Immediately stops all sound output (on all channels)

Entry No entry conditions

Exit If a sound was being made, then Carry is true; if no sound was being made, then Carry is false; in all cases, A, BC, HL and other flags are corrupt, and all others are preserved

Notes When the sounds are restarted, they will begin from exactly the same place that they were stopped

## **&BCB9 SOUND CONTINUE**

Action Restarts all sound output (on all channels)  
Entry No entry conditions  
Exit AF, BC, DE and IX are corrupt, and all others are preserved

#### **&BCBC SOUND AMPL ENVELOPE**

Action Sets up avolume envelope  
Entry A holds an envelope number (from 1 to 15), HL holds the address of a block of data for the envelope  
Exit If it was set up properly, Carry is true, HL holds the data block address + 16, A and BC are corrupt; if the envelope number is invalid, then Carry is false, and A, B and HL are preserved; in either case, DE and the other flags are corrupt, and all other registers are preserved

All the rules of envelopes in BASIC also apply; the block of the data for the envelope is set up as follows

Notes byte 0 - number of sections in the envelope  
bytes 1 to 3 - first section of the envelope  
bytes 4 to 6 - second section of the envelope  
bytes 7 to 9 - third section of the envelope  
bytes 10 to 12 - fourth section of the envelope  
bytes 13 to 15 - fifth section of the envelope  
Each section of the envelope has three bytes set out as follows  
byte 0 - step count (with bit 7 set)  
byte 1 - step size  
byte 2 - pause time or if it is a hardware envelope, then each section takes the following form  
byte 0 - envelope shape (with bit 7 not set)  
bytes 1 and 2 - envelope period  
See also SOUND TONE ENVELOPE below

#### **&BCBF SOUND TONE ENVELOPE**

Action Sets up a tone envelope  
Entry A holds an envelope number (from 1 to 15), HL holds the address of a block of data for the envelope  
Exit If it was set up properly, Carry is true, HL holds the data block address + 16, A and BC are corrupt; if the envelope number is invalid, then Carry is false, and A, B and HL are preserved; in either case, DE and the other flags are corrupt, and all other registers are preserved

All the rules of envelopes in BASIC also apply; the block of the data for the envelope is set up as follows

Notes byte 0 - number of sections in the envelope  
bytes 1 to 3 - first section of the envelope  
bytes 4 to 6 - second section of the envelope  
bytes 7 to 9 - third section of the envelope  
bytes 10 to 12 - fourth section of the envelope  
bytes 13 to 15 - fifth section of the envelope  
Each section of the envelope has three bytes set out as follows  
byte 0 - step count  
byte 1 - step size  
byte 2 - pause time  
See also SOUND AMPL ENVELOPE above

#### **&BCC2 SOUND A ADDRESS**

Action Gets the address of the data block associated with a volume envelope  
Entry A contains an envelope number (from 1 to 15)  
Exit If it was found, then Carry is true, HL holds the data block's address, and BC holds its length; if the envelope number is invalid, then Carry is false, HL is corrupt and BC is preserved; in both cases, A and the other flags are corrupt, and all others are preserved

#### **&BCC5 SOUND T ADDRESS**

Action Gets the address of the data block associated with a tone envelope  
Entry A contains an envelope number (from 1 to 15)  
Exit If it was found, then Carry is true, HL holds the data block's address, and BC holds its length; if the envelope number is invalid, then Carry is false, HL is corrupt and BC is preserved; in both cases, A and the other flags are corrupt, and all others are preserved

# The Machine Pack

## **&BD13 MC BOOT PROGRAM**

Action Loads a program into RAM and then executes it

Entry HL contains the address of the routine which is used to load the program

Exit Control is handed over to the program and so the routine is not returned from

Notes All events, sounds and interrupts are turned off, the firmware indirections are returned to their default settings, and the stack is reset; the routine to run the program should be in the central block of memory, and should obey the following exit conditions:  
if the program was loaded successfully, then Carry is true, and HL contains the program entry point; if the program failed to load, then Carry is false, and HL is corrupt; in either case, A, BC, DE, IX, IY and the other flags are all corrupt. Should the program fail to load, control is returned to the previous foreground program.

## **&BD16 MC START PROGRAM**

Action Runs a foreground program

Entry HL contains the entry point for the program, and C contains the ROM selection number

Exit Control is handed over to the program and so the routine is not returned from

## **&BD19 MC WAIT FLYBACK**

Action Waits until a frame flyback occurs

Entry No entry conditions

Exit All registers are preserved

Notes When the frame flyback occurs the screen is not being written to and so the screen can be manipulated during this period without any flickering or ghosting on the screen.

## **&BD1C MC SET MODE**

Action Sets the screen mode

Entry A contains the required mode

Exit AF is corrupt, and all other registers are preserved

Notes Although this routine changes the screen mode it does not inform the routines which write to the screen that the mode has been changed; therefore these routines will write to the screen as if the mode had not been changed; however as the hardware is now interpreting these signals differently, unusual effects may occur.

## **&BD1F MC SCREEN OFFSET**

Action Sets the screen offset

Entry A contains the screen base, and HL contains the screen offset

Exit AF is corrupt, and all other registers are preserved

Notes As with MC SET MODE, this routine changes the hardware setting without telling the routines that write to the screen; therefore these routines may cause unpredictable effects if called; the default screen base is &C0.

## **&BD22 MC CLEAR INKS**

Action Sets all the PENs and the border to one colour, so making it seem as if the screen has been cleared

Entry DE contains the address of the ink vector

Exit AF is corrupt, and all other registers are preserved

Notes The ink vector takes the following form:  
byte 0 - holds the colour for the border  
byte 1 - holds the colour for all of the PENs  
The values for the colours are all given as hardware values.

## **&BD25 MC SET INKS**

Action Sets the colours of all the PENs and the border

Entry DE contains the address of the ink vector

Exit AF is corrupt, and all other registers are preserved

Notes The ink vector takes the following form:  
byte 0 - holds the colour for the border  
byte 1 - holds the colour for PEN 0... byte 16 - holds the colour for PEN 15. The values for the colours are all given as hardware values; the routine sets all sixteen PEN's

#### **&BD28 MC RESET PRINTER**

Action Sets the MC WAIT PRINTER indirection to its original routine

Entry No entry conditions

Exit AF, BC, DE and HL are corrupt, and all others are preserved

#### **&BD2B MC PRINT CHAR**

Action Sends a character to the printer and detects if it is busy for too long (more than 0.4 seconds)

Entry A contains the character to be printed - only characters upto ASCII 127 can be printed

Exit If the character was sent properly, then Carry is true; if the printer was busy, then Carry is false; in either case, A and the other flags are corrupt, and all other registers are preserved

Notes This routine uses the MC WAIT PRINTER indirection

#### **&BD2E MC BUSY PRINTER**

Action Tests to see if the printer is busy

Entry No entry conditions

Exit If the printer is busy, then Carry is true; if the printer is not busy, then Carry is false; in both cases, the other flags are corrupt, and all other registers are preserved

#### **&BD31 MC SEND PRINTER**

Action Sends a character to the printer, which must not be busy

Entry A contains the character to be printed - only characters up to ASCII 127 can be printed

Exit Carry is true, A and the other flags are corrupt, and all other registers are preserved

#### **&BD34 MC SOUND REGISTER**

Action Sends data to a sound chip register

Entry A contains the register number, and C contains the data to be sent

Exit AF and BC are corrupt, and all other registers are preserved

#### **&BD37 JUMP RESTORE**

Action Restores the jumpblock to its default state

Entry No entry conditions

Exit AF, BC, DE and HL are corrupt, and all other registers are preserved

Notes This routine does not affect the indirections jumpblock, but restores all entries in the main jumpblock



# 664 and 6128 only

## **&BD3A KM SET LOCKS**

Action Turns the shift and caps locks on and off  
Entry H contains the caps lock state, and L contains the shift lock state  
Exit AF is corrupt, and all others are preserved  
Notes In this routine, &00 means turned off, and &FF means turned on

## **&BD3D KM FLUSH**

Action Empties the key buffer  
Entry No entry conditions  
Exit AF is corrupt, and all other registers are preserved  
Notes This routine also discards any current expansion string

## **&BD40 TXT ASK STATE**

Action Gets the VDU and cursor state  
Entry No entry conditions  
Exit A contains the VDU and cursor state, the flags are corrupt, and all others are preserved  
Notes The value in the A register is bit significant, as follows:  
if bit 0 is set, then the cursor is disabled, otherwise it is enabled  
if bit 1 is set, then the cursor is turned off, otherwise it is on  
if bit 7 is set, then the VDU is enabled, otherwise it is disabled

## **&BD43 GRA DEFAULT**

Action Sets the graphics VDU to its default mode  
Entry No entry conditions  
Exit AF, BC, DE and HL are corrupt, and all other registers are preserved  
Notes Sets the background to opaque, the first point of line is plotted, lines aren't dotted, and the write mode is force

## **&BD46 GRA SET BACK**

Action Sets the graphics background mode to either opaque or transparent  
Entry A holds zero if opaque mode is wanted, or holds &FF to select transparent mode  
Exit All registers are preserved

## **&BD49 GRA SET FIRST**

Action Sets whether the first point of a line is plotted or not  
Entry A holds zero if the first point is not to be plotted, or holds &FF if it is to be plotted  
Exit All registers are preserved

## **&BD4C GRA SET LINE MASK**

Action Sets how the points in a line are plotted - ie defines whether a line is dotted or not  
Entry A contains the line mask that will be used when drawing lines  
Exit All registers are preserved  
Notes The first point in the line corresponds to bit 7 of the line mask and after bit 0 the mask repeats; if a bit is set then that point will be plotted; the mask is always applied from left to right, or from bottom to top

## **&BD4F GRA FROM USER**

Action Converts user coordinates into base coordinates  
Entry DE contains the user X coordinate, and HL contains the user Y coordinate  
Exit DE holds the base X coordinate, and HL holds the base Y coordinate, AF is corrupt, and all others are

preserved

#### **&BD52 GRA FILL**

- Action Fills an area of the screen starting from the current graphics position and extending until it reaches either the edge of the window or a pixel set to the PEN
- Entry A holds a PEN to fill with, HL holds the address of the buffer, and DE holds the length of the buffer
- Exit If the area was filled properly, then Carry is true; if the area was not filled, then Carry is false; in either case, A, BC, DE, HL and the other flags are corrupt, and all others are preserved
- Notes The buffer is used to store complex areas to fill, which are remembered and filled when the basic shape has been done; each entry in the buffer uses seven bytes and so the more complex the shape the larger the buffer; if it runs out of space to store these complex areas, it will fill what it can and then return with Carry false

#### **&BD55 SCR SET POSITION**

- Action Sets the screen base and offset without telling the hardware
- Entry A contains the screen base, and HL contains the screen offset
- Exit A contains the masked screen base, and HL contains the masked screen offset, the flags are corrupt, and all other registers are preserved

#### **&BD58 MC PRINT TRANSLATION**

- Action Sets how ASCII characters will be translated before being sent to the printer
- Entry HL contains the address of the table
- Exit If the table is too long, then Carry is false (ie more than 20 entries); if the table is correctly set out, then Carry is true; in either case, A, BC, DE, HL and the other flags are corrupt, and all others are preserved
- Notes The first byte in the table is the number of entries; each entry requires two bytes, as follows:  
byte 0 - the character to be translated  
byte 1 - the character that is to be sent to the printer  
If the character to be sent to the printer is &FF, then the character is ignored and nothing is sent

#### **&BD5B KL BANK SWITCH (6128 only)**

- Action Sets which RAM banks are being accessed by the Z80
- Entry A contains the organisation that is to be used
- Exit A contains the previous organisation, the flags are corrupt, and all other registers are preserved

# The Firmware Indirections

## **&BDCD TXT DRAW CURSOR**

- Action Places the cursor on the screen, if the cursor is enabled
- Entry No entry conditions
- Exit AF is corrupt, and all other registers are preserved
- Notes The cursor is an inverse blob which appears at the current text position

## **&BDD0 TXT UNDRAW CURSOR**

- Action Removes the cursor from the screen, if the cursor is enabled
- Entry No entry conditions
- Exit AF is corrupt, and all the other registers are preserved

## **&BDD3 TXT WRITE CHAR**

- Action Writes a character onto the screen
- Entry A holds the character to be written, H holds the physical column number, and L holds the physical line number
- Exit AF, BC, DE and HL are corrupt, and all other registers are preserved

## **&BDD6 TXT UNWRITE**

- Action Reads a character from the screen
- Entry H contains the physical column number, and L contains the physical line number to read from
- Exit If a character was found, then Carry is true, and A contains the character; if no character was found, then Carry is false, and A contains zero; in either case, BC, DE, HL and the other nags are corrupt, and all other registers are preserved
- Notes This routine works by comparing the image on the screen with the character matrices; therefore if the character matrices have been altered the routine may not find a readable a character

## **&BDD9 TXT OUT ACTION**

- Action Writes a character to the screen or obeys a control code (&00 to &1F)
- Entry A contains the character or code
- Exit AF, BC, DE and HL are corrupt, and all other registers are preserved
- Notes Control codes may take a maximum of nine parameters; when a control code is found, the required number of parameters is read into the control code buffer, and then the control code is acted upon; if the graphics character write mode is enabled, then characters and codes are printed using the graphics VDU; when using the graphics VDU control codes are printed and not obeyed

## **&BDDC GRA PLOT**

- Action Plots a point in the current graphics PEN
- Entry DE contains the user X coordinate, and HL contains the user Y coordinate of the point
- Exit AF, BC, DE and HL are corrupt, and all other registers are preserved
- Notes This routine uses the SCR WRITE indirection to write the point to the screen

## **&BDDF GRA TEST**

- Action Tests a point and finds out what PEN it is set to
- Entry DE contains the user X coordinate, and HL contains the user Y coordinate of the point
- Exit A contains the PEN that the point is written in, BC, DE and HL are corrupt, and all others are preserved
- Notes This routine uses the SCR READ indirection to test a point on the screen

## **&BDE2 GRA LINE**

- Action Draws a line in the current graphics PEN, from the current graphics position to the specified point

Entry DE contains the user X coordinate, and HL contains the user Y coordinate for the endpoint  
Exit AF, BC, DE and HL are corrupt, and all others are preserved  
Notes This routine uses the SCR WRITE indirection to write the points of the line on the screen

#### **&BDE5 SCR READ**

Action Reads a pixel from the screen and returns its decode a PEN  
Entry HL contains the screen address of the pixel, and C contains the mask for the pixel  
Exit A contains the decoded PEN of the pixel, the flags are corrupt, and all others are preserved  
Notes The mask should be for a single pixel, and is dependent on the screen mode

#### **&BDE8 SCR WRITE**

Action Writes one or more pixels to the screen  
Entry HL contains the screen address of the pixel, C contains the mask, and B contains the encoded PEN  
Exit AF is corrupt, and all other registers are preserved  
Notes The mask should determine which pixels in the screen byte are to be plotted

#### **&BDEB SCR MODE CLEAR**

Action Fills the entire screen memory with &00, which clears the screen to PEN 0  
Entry No entry conditions  
Exit AF, BC, DE and HL are corrupt, and all the other registers are preserved

#### **&BDEE KM TEST BREAK**

Action Tests if the ESC key has been pressed, and acts accordingly  
Entry C contains the Shift and Control key states, and interrupts must be disabled  
Exit AF and HL are corrupt, and all other registers are preserved  
Notes If bit 7 of C is set, then the Control key is pressed; if bit 5 of C is set, then the Shift key is pressed; if ESC, Shift and Control are pressed at the same time, then it initiates a system reset; otherwise it reports a break event

#### **&BDF1 MC WAIT PRINTER**

Action Sends a character to the printer if it is not busy  
Entry A contains the character to be sent to the printer  
Exit If the character was printed successfully, then Carry is true; if the printer was busy for too long (more than 0.4 seconds), then Carry is false; in either case, A and BC are corrupt, and all other registers are preserved

#### **&BDF4 KM SCAN KEYS**

Action Scans the keyboard every 1/50th of a second, and updates the status of all keys  
Entry All interrupts must be disabled  
Exit AF, BC, DE and HL are corrupt, and all other registers are preserved

# The Maths Firmware

## **&BDC1 MOVE REAL (&BD3D for the 464)**

- Action Copies the five bytes that are pointed to by DE to the location held in HL
- Entry DE points to the source real value, and HL points to the destination
- Exit HL points to the real value in the destination, Carry is true if the move went properly, F is corrupt, and all other registers are preserved
- Notes For the 464 only, A holds the exponent byte of the real value when the routine is exited

## **&BD64 INTEGER TO REAL (&BD40 for the 464)**

- Action Converts an integer value into a real value
- Entry HL holds the integer value, DE points to the destination for the real value, bit 7 of A holds the sign of the integer value - it is taken to be negative if bit 7 is set
- Exit HL points to the real value in the destination, AF and DE are corrupt, and all others are preserved

## **&BD67 BINARY TO REAL (&BD43 for the 464)**

- Action Converts a four byte binary value into a real value at the same location
- Entry HL points to the binary value, bit 7 of A holds the sign of the binary value - negative if it is set
- Exit HL points to the real value in lieu of the four byte binary value, AF is corrupt, and all others are preserved
- Notes A four byte binary value is an unsigned integer up to &FFFFFFF and is stored with the least significant byte first, and with the most significant byte last

## **&BD6A REAL TO INTEGER (&BD46 for the 464)**

- Action Converts a real value, rounding it into an unsigned integer value held in HL
- Entry HL points to the real value
- Exit HL holds the integer value, Carry is true if the conversion worked successfully, the Sign flag holds the sign of the integer (negative if it is set). A, IX and the other flags are corrupt, and all other registers are preserved
- Notes This rounds the decimal part down if it is less than 0.5, but rounds up if it is greater than, or equal to 0.5

## **&BD6D REAL TO BINARY (&BD49 for the 464)**

- Action Converts a real value, rounding it into a four byte binary value at the same location
- Entry HL points to the real value
- Exit HL points to the binary value in lieu of the real value, bit 7 of B holds the sign for the binary value (it is negative if bit 7 is set), AF, B and IX are corrupt, and all other registers are preserved
- Notes See REAL TO INTEGER for details of how the values are rounded up or down

## **&BD70 REAL FIX (&BD4C for the 464)**

- Action Performs an equivalent of BASIC's FIX function on a real value, leaving the result as a four byte binary value at the same location
- Entry HL points to the real value
- Exit HL points to the binary value in lieu of the real value, bit 7 of B has the sign of the binary value (it is negative if bit 7 is set), AF, B and IX are corrupt, and all others are preserved
- Notes FIX removes any decimal part of the value, rounding down whether positive or negative - see the BASIC handbook for more details on the FIX command

## **&BD73 REAL INT (&BD4F for the 464)**

- Action Performs an equivalent of BASIC's INT function on a real value, leaving the result as a four byte binary value at the same location
- Entry HL points to the real value
- Exit HL points to the binary value in lieu of the real value, bit 7 of B has the sign of the binary value (it is

negative if bit 7 is set), AF, B and IX are corrupt, and all others are preserved

Notes INT removes any decimal part of the value, rounding down if the number is positive, but rounding up if it is negative

**&BD76 INTERNAL SUBROUTINE - not useful (&BD52 for the 464)**

**&BD79 REAL \*10^A (&BD55 for the 464)**

Action Multiplies a real value by 10 to the power of the value in the A register, leaving the result at the same location

Entry HL points to the real value, and A holds the power of 10

Exit HL points to the result, AF, BC, DE, IX and IY are corrupt

**&BD7C REAL ADDITION (&BD58 for the 464)**

Action Adds two real values, and leaves the result in lieu of the first real number

Entry HL points to the first real value, and DE points to the second real value

Exit HL points to the result, AF, BC, DE, IX and IY are corrupt

**&BD82 REAL REVERSE SUBTRACTION (&BD5E for the 464)**

Action Subtracts the first real value from the second real value, and leaves the result in lieu of the first number

Entry HL points to the first real value, and DE points to the second real value

Exit HL points to the result in place of the first real value, AF, BC, DE, IX and IY are corrupt

**&BD85 REAL MULTIPLICATION (&BD61 for the 464)**

Action Multiplies two real values together, and leaves the result in lieu of the first number

Entry HL points to the first real value, and DE points to the second real value

Exit HL points to the result in place of the first real value, AF, BC, DE, IX and IY are corrupt

**&BD88 REAL DIVISION (&BD64 for the 464)**

Action Divides the first real value by the second real value, and leaves the result in lieu of the first number

Entry HL points to the first real value, and DE points to the second real value

Exit HL points to the result in place of the first real value, AF, BC, DE, IX and IY are corrupt

**&BD8E REAL COMPARISON (&BD6A for the 464)**

Action Compares two real values

Entry HL points to the first real value, and DE points to the second real value

Exit A holds the result of the comparison process, IX, IY, and the other flags are corrupt, and all others are preserved

Notes After this routine has been called, the value in A depends on the result of the comparison as follows  
if the first real number is greater than the second real number, then A holds &01  
if the first real number is the same as the second real number, then A holds &00  
if the second real number is greater than the first real number, then A holds &FF

**&BD91 REAL UNARY MINUS (&BD6D for the 464)**

Action Reverses the sign of a real value

Entry HL points to the real value

Exit HL points to the new value of the real number (which is stored in place of the original number), bit 7 of A holds the sign of the result (it is negative if bit 7 is set), AF and IX are corrupt, and all other registers are preserved

**&BD94 REAL SIGNUM/SGN (&BD70 for the 464)**

Action Tests a real value, and compares it with zero

Entry HL points to the real value

Exit A holds the result of this comparison process, IX and the other flags are corrupt, and all others are preserved

Notes After this routine has been called, the value in A depends on the result of the comparison as follows  
if the real number is greater than 0, then A holds &01, Carry is false, and Zero is false

if the real number is the same as 0, then A holds &00, Carry is false, and Zero is true  
if the real number is smaller than 0, then A holds &FF, Carry is true, and Zero is false

**&BD97 SET ANGLE MODE (&BD73 for the 464)**

Action Sets the angular calculation mode to either degrees (DEG) or radians (RAD)

Entry A holds the mode setting - 0 for RAD, and any other value for DEG

Exit All registers are preserved

**&BD9A REAL PI (&BD76 for the 464)**

Action Places the real value of pi at a given memory location

Entry HL holds the address at which the value of pi is to be placed

Exit AF and DE are corrupt, and all other registers are preserved

**&BD9D REAL SQR (&BD79 for the 464)**

Action Calculates the square root of a real value, leaving the result in lieu of the real value

Entry HL points to the real value

Exit HL points to the result of the calculation, AF, BC, DE, IX and IY are corrupt

**&BDA0 REAL POWER (&BD7C for the 464)**

Action Raises the first real value to the power of the second real value, leaving the result in lieu of the first real value

Entry HL points to the first real value, and DE points to the second real value

Exit HL points to the result of the calculation, AF, BC, DE, IX and IY are corrupt

**&BDA3 REAL LOG (&BD7F for the 464)**

Action Returns the naperian logarithm (to base e) of a real value, leaving the result in lieu of the real value

Entry HL points to the real value

Exit HL points to the logarithm that has been calculated, AF, BC, DE, LY and IY are corrupt

**&BDA6 REAL LOG 10 (&BD82 for the 464)**

Action Returns the logarithm (to base 10) of a real value, leaving the result in lieu of the real value

Entry HL points to the real value

Exit HL points to the logarithm that has been calculated, AF, BC, DE, IX and IY are corrupt

**&BDA9 REAL EXP (&BD85 for the 464)**

Action Returns the antilogarithm (base e) of a real value, leaving the result in lieu of the real value

Entry HL points to the real value

Exit HL points to the antilogarithm that has been calculated, AF, BC, DE, IX and IY are corrupt

Notes See the BASIC handbook for details of EXP

**&BDAC REAL SINE (&BD88 for the 464)**

Action Returns the sine of a real value, leaving the result in lieu of the real value

Entry HL points to the real value (ie all angle)

Exit HL points to the sine value that has been calculated, AF, BC, DE, IX and IY are corrupt

**&BDAF REAL COSINE (&BD8B for the 464)**

Action Returns the cosine of a real value, leaving a the result in lieu of the real value

Entry HL points to the real value (ie an angle)

Exit HL points to the cosine value that has been calculated, AF, BC, DE, IX and IY are corrupt

**&BDB2 REAL TANGENT (&BD8E for the 464)**

Action Returns the tangent of a real value, leaving the result in lieu of the real value

Entry HL points to the real value (ie an angle)

Exit HL points to the tangent value that has been calculated, AF, BC, DE, IX and IY are corrupt

#### **&BDB5 REAL ARCTANGENT (&BD91 for the 464)**

Action Returns the arctangent of a real value, leaving the result in lieu of the real value

Entry HL points to the real value (ie an angle)

Exit HL points to the arctangent value that has been calculated, AF, BC, DE, IX and IY are corrupt All of the above routines to calculate sine, cosine, tangent and arctangent are slightly inaccurate

#### **&BDB8 INTERNAL SUBROUTINE - not useful (&BD94 for the 464)**

#### **&BDBB INTERNAL SUBROUTINE - not useful (&BD97 for the 464)**

#### **&BDBE INTERNAL SUBROUTINE - not useful (&BD9A for the 464)**

## Maths Subroutines for the 464 only

#### **&BD5B REAL SUBTRACTION**

Action Subtracts the second real value from the first real value, and leaves the result in lieu of the first number

Entry HL points to the first real value, and DE points to the second real value

Exit HL points to the result in place of the first real value, AF, BC, DE, IX and IY are corrupt

#### **&BD67 REAL EXPONENT ADDITION**

Action Adds the value of the A register to the exponent byte of a real number

Entry HL points to the real value, and A holds the value to be added

Exit HL points to the result in place of the first real value, AF and IX are corrupt, and all others are preserved

#### **&BD9D INTERNAL SUBROUTINE - not useful**

#### **&BDA0 INTERNAL SUBROUTINE - not useful**

#### **&BDA3 INTERNAL SUBROUTINE - not useful**

#### **&BDA6 INTERNAL SUBROUTINE - not useful**

#### **&BDA9 INTERNAL SUBROUTINE - not useful**

#### **&BDAC INTEGER ADDITION**

Action Adds two signed integer values

Entry HL holds the first integer value, and DE holds the second integer value

Exit HL holds the result of the addition, A holds &FF if there is an overflow but is preserved otherwise, the flags Z are corrupt, and all other registers are preserved

#### **&BDAF INTEGER SUBTRACTION**

Action Subtracts the second signed integer value from the first signed integer value

Entry HL holds the first integer value, and DE holds the second integer value

Exit HL holds the result of the subtraction, A holds &FF if there is an overflow but is preserved otherwise, the flags are corrupt, and all the other registers are preserved

#### **&BDB2 INTEGER REVERSE SUBTRACTION**

Action Subtracts the first signed integer value from the second signed integer value

Entry HL holds the first integer value, and DE holds the second integer value

Exit HL holds the result of the subtraction, AF and DE are corrupt, and all others are preserved

#### **&BDB5 INTEGER MULTIPLICATION**

Action Multiplies two signed integer values together, and leaves the result in lieu of the first number

Entry HL holds the first integer value, and DE holds the second integer value

Exit HL holds the result of the multiplication, A holds &FF if there is an overflow but is corrupted otherwise,



the flags, BC and DE are corrupt, and the other registers are preserved

Notes Multiplication of signed integers does not produce the same result as with unsigned integers

#### **&BDB8 INTEGER DIVISION**

Action Divides the first signed integer value by the second signed integer value

Entry HL holds the first integer value, and DE holds the second integer value

Exit HL holds the result of the division, DE holds the remainder, AF and BC are corrupt, and all others are preserved

Notes Division of signed integers does not produce the same result as with unsigned integers

#### **&BDBB INTEGER DIVISION 2**

Action Divides the first signed integer value by the second signed integer value

Entry HL holds the first integer value, and DE holds the second integer value

Exit DE holds the result of the division, HL holds the remainder, AF and BC are corrupt, and all others are preserved

Notes Division of signed integers does not produce the same result as with unsigned integers

#### **&BDBE INTERNAL SUBROUTINE - not useful**

#### **&BDC1 INTERNAL SUBROUTINE - not useful**

#### **&BDC4 INTEGER COMPARISON**

Action Compares two signed integer values

Entry HL holds the first integer value, and DE holds the second integer value

Exit A holds the result of the comparison process, the flags are corrupt, and all others are preserved

Notes After this routine has been called, the value in A depends on the result of the comparison as follows  
if the first real number is greater than the second real number, then A holds &01  
if the first real number is the same as the second real number, then A holds &00  
if the second real number is greater than the first real number, then A holds &FF  
With signed integers, the range of values runs from &8000 (-32768) via zero to &7FFF (+32767) and so any value which is greater than &8000 is considered as being less than a value of &7FFF or less

#### **&BDC7 INTEGER UNARY MINUS**

Action Reverses the sign of an integer value (by subtracting it from &10000)

Entry HL holds the integer value

Exit HL holds the new value of the integer number, AF is corrupt, cmd all other registers are preserved

#### **&BDCA INTEGER SIGNUM/SGN**

Action Tests a signed integer value

Entry HL holds the integer value

Exit A holds the result of this comparison process, the flags are corrupt, and all others are preserved

Notes After this routine has been called, the value in A depends on the result of the comparison as follows  
if the integer number is greater than 0 and is less than &8000, then A holds &01  
if the integer number is the same as 0, then A holds &00  
if the integer number is greater than &7FFF and less than or equal to &FFFF, then A holds &FF  
See INTEGER COMPARISON for more details on the way that signed integers are laid out

## **Maths Subroutines for the 664 and 6128 only**

#### **&BD5E TEXT INPUT**

Action Allows upto 255 characters to be input from the keyboard into a buffer (hmmm ... not really a maths routine ...)

Entry HL points to the start of the buffer - a NUL character must be placed after any characters already present, or at the start of the buffer if there is no text

Exit A has the last key pressed, HL points to the start of the buffer, the flags are corrupt, and all others are preserved

Notes This routine prints any existing contents of the buffer (upto the NUL character) and then echoes any keys used; it allows full line editing with the cursor keys and DEL, etc; it is exited only by use of ENTER or ESC

#### **&BD7F REAL RND**

Action Creates a new RND real value at a location pointed to by HL

Entry HL points to the destination for the result

Exit HL points to the RND value, AF, BC, DE and IX registers are corrupt; and all others are preserved

#### **&BD8B REAL RND(0)**

Action Returns the last RND value created, and puts it in a location pointed to by HL

Entry HL points to the place where the value is to be returned to

Exit HL points to the value created, AF, DE and IX are corrupt, and all other registers are preserved

Notes: See the BASIC handbook for more details on RND(0)

# The Z80 Instruction Set

The lists contains all the normal machine code instructions for the microprocessor, plus a number of undocumented ones. The latter comprise those which operate on the high or low bytes of the Index registers (IX and IY) which are notated here as HIX, LIX, HIY and LIY - some assemblers may use the form IXH, etc - and a set of rotation instructions complementary to SRL, which are designated SLL.

## The Opcodes and T states

Within the tables of instructions, a number of abbreviations are used:

d	displacement (a value from -128 (&80) to +127 (&7F))
n	a single byte value (from 0 (&00) to 255 (&FF))
hilo	a double byte value (from -32768 (&8000) via 0 to 32767 (&7FFF))
addr	an address value (from 0 (&0000) to 65535 (&FFFF))

(in the sequence of opcode bytes, 'addr' and 'hilo' are entered low byte first)

The next two columns detail the number of bytes applicable to each instruction, and the number of T states (clock pulses) that each requires - some have two figures which are distinguished as follows:

- f means 'the number of T states required when the condition is false'
- t means 'the number of T states needed when the condition is true'
- = means 'the number of T states needed when either BC=0 and/or A matches the contents of HL'
- # means 'the number of T states required when both the above conditions are false'
- z means 'the number of T states needed when B=0'
- nz means 'the number of T states required when B<>0'

## The Flag Register

The last columns give the effect on the flag bits which each instruction causes:

- ? means the setting of the bit is unpredictable
- means the setting of the bit is unchanged
- 0 means that the flag bit is reset to zero
- 1 means that the flag bit is set to one.

**In addition, the Sign flag (bit 7) is also set:**

- 7 if bit 7 of the A register is set
- 15 if bit 15 of the HL register pair (ie bit 7 of the H register) is set
- =7 if bit 7 of the A register would be set by subtraction in lieu of CP

**The Zero flag (bit 6) is also set:**

- z if the A register or the HL register pair equals zero
- = if the A register matches the compared register or value
- =A if the A register matches the contents of the address pointed to by HL

<>B if the B register holds zero

<>b if the bit tested is zero

**The Parity/Overflow flag (bit 2) is also set:**

p if the register concerned contains an even number of set bits

v if an overflow has occurred in Two's Complement arithmetic

BC if BC is not zero

A80 if the A register was &80 before this instruction was performed

i to the contents of the microprocessor's internal interrupt register

**The Carry flag (bit 0) is also set:**

c if an addition resulted in a carry out of bit 7 (for a register) or bit 15 (for a register pair)

b if a subtraction required a borrow from bit 7 (for a register) or bit 15 (for a register pair)

< if the A register is less than the value or register that is being compared

r0 by the bit rotated in from bit 0 of the register concerned

r7 by the bit rotated in from bit 7 of the register concerned

x if the Carry was reset (ie zero) before this instruction was performed

A0 if the A register was &00 before this instruction was performed

The flag register is bit significant, and the bits are defined as follows:

- 7 - Sign
- 6 - Zero
- 5 - unused
- 4 - Half Carry (cannot test)
- 3 - unused
- 2 - Parity/Overflow
- 1 - Add/Subtract (cannot test)
- 0 - Carry

Instruction	Opcode	B	Ts	S	Z	P	C
BIT 0,(HL)	CB 46	2	12	?	<>b	?	-
BIT 0,(IX+d)	CB DD 46 d	4	20	?	<>b	?	-
BIT 0,(IY+d)	CB FD 46 d	4	20	?	<>b	?	-
BIT 0,A	CB 47	2	8	?	<>b	?	-
BIT 0,B	CB 40	2	8	?	<>b	?	-
BIT 0,C	CB 41	2	8	?	<>b	?	-
BIT 0,D	CB 42	2	8	?	<>b	?	-
BIT 0,E	CB 43	2	8	?	<>b	?	-
BIT 0,H	CB 44	2	8	?	<>b	?	-

Instruction	Opcode	B	Ts	S	Z	P	C
BIT 0,L	CB 45	2	8	?	<>b ?	-	-
BIT 1,(HL)	CB 4E	2	12	?	<>b ?	-	-
BIT 1,(IX+d)	CB DD 4E d	4	20	?	<>b ?	-	-
BIT 1,(IY+d)	CB FD 4E d	4	20	?	<>b ?	-	-
BIT 1,A	CB 1F	2	8	?	<>b ?	-	-
BIT 1,B	CB 48	2	8	?	<>b ?	-	-
BIT 1,C	CB 49	2	8	?	<>b ?	-	-
BIT 1,D	CB 4A	2	8	?	<>b ?	-	-
BIT 1,E	CB 4B	2	8	?	<>b ?	-	-
BIT 1,H	CB 4C	2	8	?	<>b ?	-	-
BIT 1,L	CB 4D	2	8	?	<>b ?	-	-
BIT 2,(HL)	CB 56	2	12	?	<>b ?	-	-
BIT 2,(IY+d)	CB FD 56 d	4	20	?	<>b ?	-	-
BIT 2,(LY+d)	CB DD 56 d	4	20	?	<>b ?	-	-
BIT 2,A	CB 57	2	8	?	<>b ?	-	-
BIT 2,B	CB 50	2	8	?	<>b ?	-	-
BIT 2,C	CB 51	2	8	?	<>b ?	-	-
BIT 2,D	CB 52	2	8	?	<>b ?	-	-
BIT 2,E	CB 53	2	8	?	<>b ?	-	-
BIT 2,H	CB 54	2	8	?	<>b ?	-	-
BIT 2,L	CB 55	2	8	?	<>b ?	-	-
BIT 3,(HL)	CB 5E	2	12	?	<>b ?	-	-
BIT 3,(IX+d)	CB DD 5E d	4	20	?	<>b ?	-	-
BIT 3,(IY+d)	CB FD 5E d	4	20	?	<>b ?	-	-
BIT 3,A	CB 5F	2	8	?	<>b ?	-	-
BIT 3,B	CB 58	2	8	?	<>b ?	-	-
BIT 3,C	CB 59	2	8	?	<>b ?	-	-
BIT 3,D	CB 5A	2	8	?	<>b ?	-	-
BIT 3,E	CB 5B	2	8	?	<>b ?	-	-
BIT 3,H	CB 5C	2	8	?	<>b ?	-	-
BIT 3,L	CB 5D	2	8	?	<>b ?	-	-
BIT 4,(HL)	CB 66	2	12	?	<>b ?	-	-
BIT 4,(IY+d)	CB FD 66 d	4	20	?	<>b ?	-	-
BIT 4,(LY+d)	CB DD 66 d	4	20	?	<>b ?	-	-
BIT 4,A	CB 67	2	8	?	<>b ?	-	-
BIT 4,B	CB 60	2	8	?	<>b ?	-	-
BIT 4,C	CB 61	2	8	?	<>b ?	-	-
BIT 4,D	CB 62	2	8	?	<>b ?	-	-

Instruction	Opcode	B	Ts	S	Z	P	C
BIT 4,E	CB 63	2	8	?	<>b ?	-	-
BIT 4,H	CB 64	2	8	?	<>b ?	-	-
BIT 4,L	CB 65	2	8	?	<>b ?	-	-
BIT 5,(HL)	CB 6E	2	12	?	<>b ?	-	-
BIT 5,(IX+d)	CB DD 6E d	4	20	?	<>b ?	-	-
BIT 5,(IY+d)	CB FD 6E d	4	20	?	<>b ?	-	-
BIT 5,A	CB 6F	2	8	?	<>b ?	-	-
BIT 5,B	CB 68	2	8	?	<>b ?	-	-
BIT 5,C	CB 69	2	8	?	<>b ?	-	-
BIT 5,D	CB 6A	2	8	?	<>b ?	-	-
BIT 5,E	CB 6B	2	8	?	<>b ?	-	-
BIT 5,H	CB 6C	2	8	?	<>b ?	-	-
BIT 5,L	CB 6D	2	8	?	<>b ?	-	-
BIT 6,(HL)	CB 76	2	12	?	<>b ?	-	-
BIT 6,(IX+d)	CB DD 76 d	4	20	?	<>b ?	-	-
BIT 6,(IY+d)	CB FD 76 d	4	20	?	<>b ?	-	-
BIT 6,A	CB 77	2	8	?	<>b ?	-	-
BIT 6,B	CB 70	2	8	?	<>b ?	-	-
BIT 6,C	CB 71	2	8	?	<>b ?	-	-
BIT 6,D	CB 72	2	8	?	<>b ?	-	-
BIT 6,E	CB 73	2	8	?	<>b ?	-	-
BIT 6,H	CB 74	2	8	?	<>b ?	-	-
BIT 6,L	CB 75	2	8	?	<>b ?	-	-
BIT 7,(HL)	CB 7E	2	12	?	<>b ?	-	-
BIT 7,(IX+d)	CB DD 7E d	4	20	?	<>b ?	-	-
BIT 7,(IY+d)	CB FD 7E d	4	20	?	<>b ?	-	-
BIT 7,A	CB 7F	2	8	?	<>b ?	-	-
BIT 7,B	CB 78	2	8	?	<>b ?	-	-
BIT 7,C	CB 79	2	8	?	<>b ?	-	-
BIT 7,D	CB 7A	2	8	?	<>b ?	-	-
BIT 7,E	CB 7B	2	8	?	<>b ?	-	-
BIT 7,H	CB 7C	2	8	?	<>b ?	-	-
BIT 7,L	CB 7D	2	8	?	<>b ?	-	-
CALL addr	CD dr ad	3	17	-	-	-	-
CALL c,addr	DC dr ad	3	t17f10	-	-	-	-
CALL m,addr	FC dr ad	3	t17f10	-	-	-	-
CALL nc,addr	D4 dr ad	3	t17f10	-	-	-	-
CALL nz,addr	C4 dr ad	3	t17f10	-	-	-	-

Instruction	Opcode	B	Ts	S	Z	P	C
CALL p,addr	F4 dr ad	3	t17f10	-	-	-	-
CALL po,addr	E4 dr ad	3	t17f10	-	-	-	-
CALL pe,addr	EC dr ad	3	t17f10	-	-	-	-
CALL z,addr	CC dr ad	3	t17f10	-	-	-	-
CCF	3F	1	4	-	-	-	x
CP (HL)	BE	1	7	=7	=	v	<
CP (IX+d)	DD BE d	3	19	=7	=	v	<
CP (IY+d)	FD BE d	3	19	=7	=	v	<
CP A	BF	1	4	=7	=	v	<
CP B	B8	1	4	=7	=	v	<
CP C	B9	1	4	=7	=	v	<
CP D	BA	1	4	=7	=	v	<
CP E	BB	1	4	=7	=	v	<
CP H	BC	1	4	=7	=	v	<
CP HIX	DD BC	2	8	=7	=	v	<
CP HIY	FD BC	2	8	=7	=	v	<
CP L	BD	1	4	=7	=	v	c
CP LIX	DD BD	2	8	=7	=	v	<
CP LIY	FD BD	2	8	=7	=	v	<
CP n	FE n	2	7	=7	=	v	<
CPD	ED A9	2	16	?	=A	BC	-
CPDR	ED B9	2	=16#21	?	=A	BC	-
CPI	ED A1	2	16	?	=A	BC	-
CPIR	ED B2	2	=16#21	?	=A	BC	-
CPL	2F	1	4	-	-	-	-
DAA	27	1	4	7	z	p	c
DEC (HL)	35	1	11	7	z	v	-
DEC (IX+d)	DD 35 d	3	23	7	z	v	-
DEC (IY+d)	FD 35 d	3	23	7	z	v	-
DEC A	3D	1	4	7	z	v	-
DEC B	05	1	4	7	z	v	-
DEC BC	0B	1	6	-	-	-	-
DEC C	0D	1	4	7	z	v	-
DEC D	15	1	4	7	z	v	-
DEC DE	1B	1	6	-	-	-	-
DEC E	1D	1	4	7	z	v	-
DEC H	25	1	4	7	z	v	-
DEC HIX	DD 25	2	8	7	z	v	-

Instruction	Opcode	B	Ts	S	Z	P	C
DEC HIY	FD 25	2	8	7	z	v	-
DEC HL	2B	1	6	-	-	-	-
DEC IX	DD 2B	2	10	-	-	-	-
DEC IY	FD 2B	2	10	-	-	-	-
DEC L	2D	1	4	7	z	v	-
DEC LIX	DD 2D	2	8	7	z	v	-
DEC LIY	FD 2D	2	8	7	z	v	-
DEC SP	3B	1	6	-	-	-	-
DI	F3	1	4	-	-	-	-
DJNZ d	10 d	2	t13f8	-	-	-	-
EI	FB	1	4	-	-	-	-
EX (SP),HL	E3	1	19	-	-	-	-
EX (SP),IX	DD E3	2	23	-	-	-	-
EX (SP),IY	FD E3	2	23	-	-	-	-
EX AF,AF'	08	1	4	s'	z'	p'	c'
EX DE,HL	EB	1	4	-	-	-	-
EXX	D9	1	4	-	-	-	-
HALT	76	1	min 4	-	-	-	-
IM 0	ED 46	2	8	-	-	-	-
IM 1	ED 56	2	8	-	-	-	-
IM 2	ED 5E	2	8	-	-	-	-
IN A,(C)	ED 78	2	12	7	z	p	0
IN A,(n)	DB n	2	11	-	-	-	-
IN B,(C)	ED 40	2	12	7	z	p	0
IN C,(C)	ED 48	2	12	7	z	p	0
IN D,(C)	ED 50	2	12	7	z	p	0
IN E,(C)	ED 58	2	12	7	z	p	0
IN H,(C)	ED 60	2	12	7	z	p	0
IN L,(C)	ED 68	2	12	7	z	p	0
INC (HL)	34	1	11	7	z	v	-
INC (IX+d)	DD 34 d	3	23	7	z	v	-
INC (IY+d)	FD 34 d	3	23	7	z	v	-
INC A	3C	1	4	7	z	v	-
INC B	04	1	4	7	z	v	-
INC BC	03	1	6	-	-	-	-
INC C	0C	1	4	7	z	v	-
INC D	14	1	4	7	z	v	-
INC DE	13	1	6	-	-	-	-



Instruction	Opcode	B	Ts	S	Z	P	C
INC E	1C	1	4	7	z	v	-
INC H	24	1	4	7	z	v	-
INC HIX	DD 24	2	8	7	z	v	-
INC HIY	FD 24	2	8	7	z	v	-
INC HL	23	1	6	-	-	-	-
INC IX	DD 23	2	10	-	-	-	-
INC IY	FD 23	2	10	-	-	-	-
INC L	2C	1	4	7	z	v	-
INC LIX	DD 2C	2	8	7	z	v	-
INC LIY	FD 2C	2	8	7	z	v	-
INC SP	33	1	6	-	-	-	-
IND	ED AA	2	16	?	<>B	?	-
INDR	ED BA	2	z16nz21	?	1	?	-
INI	ED A2	2	16	?	<>B	?	-
INIR	ED B2	2	z16nz21	?	1	?	-
JP (HL)	E9	1	4	-	-	-	-
JP (IX)	DD E9	2	8	-	-	-	-
JP (IY)	FD E9	2	8	-	-	-	-
JP addr	C3 dr ad	3	10	-	-	-	-
JP c,addr	DA dr ad	3	10	-	-	-	-
JP m,addr	FA dr ad	3	10	-	-	-	-
JP nc,addr	D2 dr ad	3	10	-	-	-	-
JP nz,addr	C2 dr ad	3	10	-	-	-	-
JP p,addr	F2 dr ad	3	10	-	-	-	-
JP po,addr	E2 dr ad	3	10	-	-	-	-
JP pe,addr	EA dr ad	3	10	-	-	-	-
JP z,addr	CA dr ad	3	10	-	-	-	-
JR c,d	38 d	2	t12f7	-	-	-	-
JR d	18 d	2	12	-	-	-	-
JR nc,d	30 d	2	t12f7	-	-	-	-
JR nz,d	20 d	2	t12f7	-	-	-	-
JR z,d	28 d	2	t12f7	-	-	-	-
LD (addr),A	32 dr ad	3	13	-	-	-	-
LD (addr),BC	ED 43 dr ad	4	20	-	-	-	-
LD (addr),DE	ED 53 dr ad	4	20	-	-	-	-
LD (addr),HL	22 dr ad	3	16	-	-	-	-
LD (addr),HL	ED 63 dr ad	4	20	-	-	-	-
LD (addr),IX	DD 22 dr ad	4	20	-	-	-	-

Instruction	Opcode	B	Ts	S	Z	P	C
LD (addr),IY	FD 22 dr ad	4	20	-	-	-	-
LD (addr),SP	ED 73 dr ad	4	20	-	-	-	-
LD (BC),A	02	1	7	-	-	-	-
LD (DE),A	12	1	7	-	-	-	-
LD (HL),A	77	1	7	-	-	-	-
LD (HL),A	77	1	7	-	-	-	-
LD (HL),B	70	1	7	-	-	-	-
LD (HL),C	71	1	7	-	-	-	-
LD (HL),D	72	1	7	-	-	-	-
LD (HL),E	73	1	7	-	-	-	-
LD (HL),H	74	1	7	-	-	-	-
LD (HL),L	75	1	7	-	-	-	-
LD (HL),n	36 n	2	10	-	-	-	-
LD (IX+d),A	DD 77 d	3	19	-	-	-	-
LD (IX+d),B	DD 70 d	3	19	-	-	-	-
LD (IX+d),C	DD 71 d	3	19	-	-	-	-
LD (IX+d),D	DD 72 d	3	19	-	-	-	-
LD (IX+d),E	DD 73 d	3	19	-	-	-	-
LD (IX+d),H	DD 71 d	3	19	-	-	-	-
LD (IX+d),L	DD 75 d	3	19	-	-	-	-
LD (IX+d),n	DD 36 d n	4	19	-	-	-	-
LD (IY+d),A	FD 77 d	3	19	-	-	-	-
LD (IY+d),B	FD 70 d	3	19	-	-	-	-
LD (IY+d),C	FD 71 d	3	19	-	-	-	-
LD (IY+d),D	FD 72 d	3	19	-	-	-	-
LD (IY+d),E	FD 73 d	3	19	-	-	-	-
LD (IY+d),H	FD 74 d	3	19	-	-	-	-
LD (IY+d),L	FD 75 d	3	19	-	-	-	-
LD (IY+d),n	FD 36 d n	4	19	-	-	-	-
LD A,(addr)	3A dr ad	3	13	-	-	-	-
LD A,(BC)	0A	1	7	-	-	-	-
LD A,(DE)	1A	1	7	-	-	-	-
LD A,(HL)	7E	1	7	-	-	-	-
LD A,(HL)	7E	1	7	-	-	-	-
LD A,(IX+d)	DD 7E d	3	19	-	-	-	-
LD A,(IY+d)	FD 7E d	3	19	-	-	-	-
LD A,A	7F	1	4	-	-	-	-
LD A,B	78	1	4	-	-	-	-

Instruction	Opcode	B	Ts	S	Z	P	C
LD A,C	79	1	4	-	-	-	-
LD A,D	7A	1	4	-	-	-	-
LD A,E	7B	1	4	-	-	-	-
LD A,H	7C	1	4	-	-	-	-
LD A,HIX	DD 7C	2	8	-	-	-	-
LD A,HIY	FD 7C	2	8	-	-	-	-
LD A,I	ED 57	2	9	7	z	i	0
LD A,L	7D	1	4	-	-	-	-
LD A,LIX	DD 7D	2	8	-	-	-	-
LD A,LIY	FD 7D	2	8	-	-	-	-
LD A,n	3E n	2	7	-	-	-	-
LD A,R	ED 5F	2	9	7	z	i	0
LD B,(HL)	46	1	7	-	-	-	-
LD B,(IX+d)	DD 46 d	3	19	-	-	-	-
LD B,(IY+d)	FD 46 d	3	19	-	-	-	-
LD B,A	47	1	4	-	-	-	-
LD B,B	40	1	4	-	-	-	-
LD B,C	41	1	4	-	-	-	-
LD B,D	42	1	4	-	-	-	-
LD B,E	43	1	4	-	-	-	-
LD B,H	44	1	4	-	-	-	-
LD B,HIX	DD 44	2	8	-	-	-	-
LD B,HIY	FD 44	2	8	-	-	-	-
LD B,L	45	1	4	-	-	-	-
LD B,LIX	DD 45	2	8	-	-	-	-
LD B,LIY	FD 45	2	8	-	-	-	-
LD B,n	06 n	2	7	-	-	-	-
LD BC,(addr)	ED 4B dr ad	4	20	-	-	-	-
LD BC,hilo	01 lo hi	3	10	-	-	-	-
LD C,(HL)	4E	1	7	-	-	-	-
LD C,(IX+d)	DD 4E d	3	19	-	-	-	-
LD C,(IY+d)	DD 4E d	3	19	-	-	-	-
LD C,A	4F	1	4	-	-	-	-
LD C,B	48	1	4	-	-	-	-
LD C,C	49	1	1	-	-	-	-
LD C,D	4A	1	1	-	-	-	-
LD C,E	4B	1	4	-	-	-	-
LD C,H	4C	1	4	-	-	-	-

Instruction	Opcode	B	Ts	S	Z	P	C
LD C,HIX	DD 4C	2	8	-	-	-	-
LD C,HIY	FD 4C	2	8	-	-	-	-
LD C,L	4D	1	4	-	-	-	-
LD C,LIX	DD 4D	2	8	-	-	-	-
LD C,LIY	FD 4D	2	8	-	-	-	-
LD C,n	0E n	2	7	-	-	-	-
LD D,(HL)	56	1	7	-	-	-	-
LD D,(IX+d)	DD 56 d	3	19	-	-	-	-
LD D,(IY+d)	FD 56 d	3	19	-	-	-	-
LD D,A	57	1	4	-	-	-	-
LD D,B	50	1	4	-	-	-	-
LD D,C	51	1	4	-	-	-	-
LD D,D	52	1	4	-	-	-	-
LD D,E	53	1	4	-	-	-	-
LD D,H	54	1	4	-	-	-	-
LD D,HIX	DD 54	2	8	-	-	-	-
LD D,HIY	FD 54	2	8	-	-	-	-
LD D,L	55	1	4	-	-	-	-
LD D,LIX	DD 55	2	8	-	-	-	-
LD D,LIY	FD 55	2	8	-	-	-	-
LD D,n	16 n	2	7	-	-	-	-
LD DE,(addr)	ED 5B dr ad	4	20	-	-	-	-
LD DE,hilo	11 lo hi	3	10	-	-	-	-
LD E,(HL)	5E	1	7	-	-	-	-
LD E,(IX+d)	DD 5E d	3	19	-	-	-	-
LD E,(IY+d)	FD 5E d	3	19	-	-	-	-
LD E,A	5F	1	4	-	-	-	-
LD E,B	58	1	4	-	-	-	-
LD E,C	59	1	4	-	-	-	-
LD E,D	5A	1	4	-	-	-	-
LD E,E	5B	1	4	-	-	-	-
LD E,H	5C	1	4	-	-	-	-
LD E,HIX	DD 5C	2	8	-	-	-	-
LD E,HIY	FD 5C	2	8	-	-	-	-
LD E,L	5D	1	4	-	-	-	-
LD E,LIX	DD 5D	2	8	-	-	-	-
LD E,LIY	FD 5D	2	8	-	-	-	-
LD E,n	1E n	2	7	-	-	-	-

Instruction	Opcode	B	Ts	S	Z	P	C
LD H,(HL)	66	1	7	-	-	-	-
LD H,(IX+d)	DD 66 d	3	19	-	-	-	-
LD H,(IY+d)	FD 66 d	3	19	-	-	-	-
LD H,A	67	1	4	-	-	-	-
LD H,B	60	1	4	-	-	-	-
LD H,C	61	1	4	-	-	-	-
LD H,D	62	1	4	-	-	-	-
LD H,E	63	1	4	-	-	-	-
LD H,H	64	1	4	-	-	-	-
LD H,L	65	1	4	-	-	-	-
LD H,n	26 n	2	7	-	-	-	-
LD HIX,A	DD 67	2	8	-	-	-	-
LD HIX,B	DD 60	2	8	-	-	-	-
LD HIX,C	DD 61	2	8	-	-	-	-
LD HIX,D	DD 62	2	8	-	-	-	-
LD HIX,E	DD 63	2	8	-	-	-	-
LD HIX,HIX	DD 64	2	8	-	-	-	-
LD HIX,LIX	DD 65	2	8	-	-	-	-
LD HIX,n	DD 26 n	3	11	-	-	-	-
LD HIY,A	FD 67	2	8	-	-	-	-
LD HIY,B	FD 60	2	8	-	-	-	-
LD HIY,C	FD 61	2	8	-	-	-	-
LD HIY,D	FD 62	2	8	-	-	-	-
LD HIY,E	FD 63	2	8	-	-	-	-
LD HIY,HIY	FD 64	2	8	-	-	-	-
LD HIY,LIY	FD 65	2	8	-	-	-	-
LD HIY,n	FD 26 n	3	11	-	-	-	-
LD HL,(addr)	2A dr ad	3	16	-	-	-	-
LD HL,(addr)	ED 6B dr ad	4	20	-	-	-	-
LD HL,hilo	21 lo hi	3	10	-	-	-	-
LD I,A	ED 47	2	9	-	-	-	-
LD IX,(addr)	DD 2A dr ad	4	20	-	-	-	-
LD IX,hilo	DD 2A lo hi	4	14	-	-	-	-
LD IY,(addr)	FD 2A dr ad	4	20	-	-	-	-
LD IY,hilo	FD 21 lo hi	4	14	-	-	-	-
LD L,(HL)	6E	1	7	-	-	-	-
LD L,(IX+d)	DD 6E d	3	19	-	-	-	-
LD L,(IY+d)	FD 6E d	3	19	-	-	-	-

Instruction	Opcode	B	Ts	S	Z	P	C
LD L,A	6F	1 4		-	-	-	-
LD L,B	68	1 4		-	-	-	-
LD L,C	69	1 4		-	-	-	-
LD L,D	6A	1 4		-	-	-	-
LD L,E	6B	1 4		-	-	-	-
LD L,H	6C	1 4		-	-	-	-
LD L,L	6D	1 4		-	-	-	-
LD L,n	2E n	2 7		-	-	-	-
LD LIX,A	DD 6F	2 8		-	-	-	-
LD LIX,B	DD 68	2 8		-	-	-	-
LD LIX,C	DD 69	2 8		-	-	-	-
LD LIX,D	DD 6A	2 8		-	-	-	-
LD LIX,E	DD 6B	2 8		-	-	-	-
LD LIX,HIX	DD 6C	2 8		-	-	-	-
LD LIX,LIX	DD 6D	2 8		-	-	-	-
LD LIX,n	DD 2E n	3 11		-	-	-	-
LD LIY,A	FD 6F	2 8		-	-	-	-
LD LIY,B	FD 68	2 8		-	-	-	-
LD LIY,C	FD 69	2 8		-	-	-	-
LD LIY,D	FD 6A	2 8		-	-	-	-
LD LIY,E	FD 6B	2 8		-	-	-	-
LD LIY,HIY	FD 6C	2 8		-	-	-	-
LD LIY,LIY	FD 6D	2 8		-	-	-	-
LD LIY,n	FD 2E n	3 11		-	-	-	-
LD R,A	ED 4F	2 9		-	-	-	-
LD SP,(addr)	ED 7B dr ad	4 20		-	-	-	-
LD SP,hilo	31 lo hi	3 10		-	-	-	-
LD SP,HL	F9	1 6		-	-	-	-
LD SP,IX	DD F9	2 10		-	-	-	-
LD SP,IY	FD F9	2 10		-	-	-	-
LDD	ED A8	2 16		-	-	BC	-
LDDR	ED B8	2 z16nz21		-	-	0	-
LDI	ED A0	2 16		-	-	BC	-
LDIR	ED B0	2 z16nz21		-	-	0	-
NEG	ED 44	2 8		7	z	A80	A0
NOP	00	1 4		-	-	-	-
OR (HL)	B6	1 7		7	z	P	0
OR (IX+d)	DD B6 d	3 19		7	z	p	0

Instruction	Opcode	B	Ts	S	Z	P	C
OR (IY+d)	FD B6 d	3	19	7	z	p	0
OR A	B7	1	4	7	z	p	0
OR B	B0	1	4	7	z	p	0
OR C	B1	1	4	7	z	p	0
OR D	B2	1	4	7	z	p	0
OR E	B3	1	4	7	z	p	0
OR H	B4	1	4	7	z	p	0
OR HIX	DD B4	2	8	7	z	p	0
OR HIY	FD B4	2	8	7	z	p	0
OR L	B5	1	4	7	z	p	0
OR LIX	DD B5	2	8	7	z	p	0
OR LIY	FD B5	2	8	7	z	p	0
OR n	F6 n	2	7	7	z	p	0
OTDR	ED BB	2	z16nz21	?	1	?	-
OTIR	ED B3	2	z16nz21	?	l	?	-
OUT (C),A	ED 79	2	12	-	-	-	-
OUT (C),B	ED 41	2	12	-	-	-	-
OUT (C),C	ED 49	2	12	-	-	-	-
OUT (C),D	ED 51	2	12	-	-	-	-
OUT (C),E	ED 59	2	12	-	-	-	-
OUT (C),H	ED 61	2	12	-	-	-	-
OUT (C),L	ED 69	2	12	-	-	-	-
OUT (n),A	D3 n	2	11	-	-	-	-
OUTD	ED AB	2	16	?	<>B	?	-
OUTI	ED A3	2	16	?	<>B	?	-
POP AF	F1	1	10	POP	POP	POP	POP
POP BC	C1	1	10	-	-	-	-
POP DE	D1	1	10	-	-	-	-
POP HL	E1	1	10	-	-	-	-
POP IX	DD E1	2	14	-	-	-	-
POP IY	FD E1	2	14	-	-	-	-
PUSH AF	F5	1	11	-	-	-	-
PUSH BC	C5	1	11	-	-	-	-
PUSH DE	D5	1	11	-	-	-	-
PUSH HL	E5	1	11	-	-	-	-
PUSH IX	DD E5	2	15	-	-	-	-
PUSH IY	FD E5	2	15	-	-	-	-
RES 0,(HL)	CB 86	2	15	-	-	-	-

<b>Instruction</b>	<b>Opcode</b>	<b>B</b>	<b>Ts</b>	<b>S</b>	<b>Z</b>	<b>P</b>	<b>C</b>
RES 0,(IX+d)	DD CB d 86	4	23	-	-	-	-
RES 0,(IY+d)	FD CB d 86	4	23	-	-	-	-
RES 0,A	CB 87	2	8	-	-	-	-
RES 0,B	CB 80	2	8	-	-	-	-
RES 0,C	CB 81	2	8	-	-	-	-
RES 0,D	CB 82	2	8	-	-	-	-
RES 0,E	CB 83	2	8	-	-	-	-
RES 0,H	CB 81	2	8	-	-	-	-
RES 0,L	CB 85	2	8	-	-	-	-
RES 1,(HL)	CB 8E	2	15	-	-	-	-
RES 1,(IX+d)	DD CB d 8E	4	23	-	-	-	-
RES 1,(IY+d)	FD CB d 8E	4	23	-	-	-	-
RES 1,A	CB 8F	2	8	-	-	-	-
RES 1,B	CB 88	2	8	-	-	-	-
RES 1,C	CB 89	2	8	-	-	-	-
RES 1,D	CB 8A	2	8	-	-	-	-
RES 1,E	CB 8B	2	8	-	-	-	-
RES 1,H	CB 8C	2	8	-	-	-	-
RES 1,L	CB 8D	2	8	-	-	-	-
RES 2,(HL)	CB 96	2	15	-	-	-	-
RES 2,(IX+d)	DD CB d 96	4	23	-	-	-	-
RES 2,(IY+d)	FD CB d 96	4	23	-	-	-	-
RES 2,A	CB 97	2	8	-	-	-	-
RES 2,B	CB 90	2	8	-	-	-	-
RES 2,C	CB 91	2	8	-	-	-	-
RES 2,D	CB 92	2	8	-	-	-	-
RES 2,E	CB 93	2	8	-	-	-	-
RES 2,H	CB 94	2	8	-	-	-	-
RES 2,L	CB 95	2	8	-	-	-	-
RES 3,(HL)	CB 9E	2	15	-	-	-	-
RES 3,(IX+d)	DD CB d 9E	4	23	-	-	-	-
RES 3,(IY+d)	FD CB d 9E	4	23	-	-	-	-
RES 3,A	CB 9F	2	8	-	-	-	-
RES 3,B	CB 98	2	8	-	-	-	-
RES 3,C	CB 99	2	8	-	-	-	-
RES 3,D	CB 9A	2	8	-	-	-	-
RES 3,E	CB 9B	2	8	-	-	-	-
RES 3,H	CB 9C	2	8	-	-	-	-



Instruction	Opcode	B	Ts	S	Z	P	C
RES 3,L	CB 9D	2	8	-	-	-	-
RES 4,(HL)	CB A6	2	15	-	-	-	-
RES 4,(IX+d)	DD CB d A6	4	23	-	-	-	-
RES 4,(IY+d)	FD CB d A6	4	23	-	-	-	-
RES 4,A	CB A7	2	8	-	-	-	-
RES 4,B	CB A0	2	8	-	-	-	-
RES 4,C	CB A1	2	8	-	-	-	-
RES 4,D	CB A2	2	8	-	-	-	-
RES 4,E	CB A3	2	8	-	-	-	-
RES 4,H	CB A4	2	8	-	-	-	-
RES 4,L	CB A5	2	8	-	-	-	-
RES 5,(HL)	CB AE	2	15	-	-	-	-
RES 5,(IX+d)	DD CB d AE	4	23	-	-	-	-
RES 5,(IY+d)	FD CB d AE	4	23	-	-	-	-
RES 5,A	CB AF	2	8	-	-	-	-
RES 5,B	CB A8	2	8	-	-	-	-
RES 5,C	CB A9	2	8	-	-	-	-
RES 5,D	CB AA	2	8	-	-	-	-
RES 5,E	CB AB	2	8	-	-	-	-
RES 5,H	CB AC	2	8	-	-	-	-
RES 5,L	CB AD	2	8	-	-	-	-
RES 6,(HL)	CB B6	2	15	-	-	-	-
RES 6,(IX+d)	DD CB d B6	4	23	-	-	-	-
RES 6,(IY+d)	FD CB d B6	4	23	-	-	-	-
RES 6,A	CB B7	2	8	-	-	-	-
RES 6,B	CB B0	2	8	-	-	-	-
RES 6,C	CB B1	2	8	-	-	-	-
RES 6,D	CB B2	2	8	-	-	-	-
RES 6,E	CB B3	2	8	-	-	-	-
RES 6,H	CB B4	2	8	-	-	-	-
RES 6,L	CB B5	2	8	-	-	-	-
RES 7,(HL)	CB BE	2	15	-	-	-	-
RES 7,(IX+d)	DD CB d BE	4	23	-	-	-	-
RES 7,(IY+d)	FD CB d BE	4	23	-	-	-	-
RES 7,A	CB BF	2	8	-	-	-	-
RES 7,B	CB B8	2	8	-	-	-	-
RES 7,C	CB B9	2	8	-	-	-	-
RES 7,D	CB BA	2	8	-	-	-	-

Instruction	Opcode	B	Ts	S	Z	P	C
RES 7,E	CB BB	2	8	-	-	-	-
RES 7,H	CB BC	2	8	-	-	-	-
RES 7,L	CB BD	2	8	-	-	-	-
RET	C9	1	10	-	-	-	-
RET C	D8	1	t11f8	-	-	-	-
RET M	F8	1	t11f8	-	-	-	-
RET NC	D0	1	t11f8	-	-	-	-
RET NZ	C0	1	t11f8	-	-	-	-
RET P	F0	1	t11f8	-	-	-	-
RET PE	E8	1	t11f8	-	-	-	-
RET PO	E0	1	t11f8	-	-	-	-
RET Z	C8	1	t11f8	-	-	-	-
RETI	ED 4D	2	14	-	-	-	-
RETN	ED 45	2	14	-	-	-	-
RL (HL)	CB 16	2	15	7	z	p	r7
RL (IX+d)	DD CB d 16	4	23	7	z	p	r7
RL (IY+d)	FD CB d 16	4	23	7	z	p	r7
RL A	CB 17	2	8	7	z	p	r7
RL B	CB 10	2	8	7	z	p	r7
RL C	CB 11	2	8	7	z	p	r7
RL D	CB 12	2	8	7	z	p	r7
RL E	CB 13	2	8	7	z	p	r7
RL H	CB 14	2	8	7	z	p	r7
RL L	CB 15	2	8	7	z	p	r7
RLA	17	1	4	-	-	-	r7
RLC (HL)	CB 06	2	15	7	z	p	r7
RLC (IX+d)	DD CB d 06	4	23	7	z	p	r7
RLC (IY+d)	FD CB d 06	4	23	7	z	p	r7
RLC A	CB 07	2	8	7	z	p	r7
RLC B	CB 00	2	8	7	z	p	r7
RLC C	CB 01	2	8	7	z	p	r7
RLC D	CB 02	2	8	7	z	p	r7
RLC E	CB 03	2	8	7	z	p	r7
RLC H	CB 04	2	8	7	z	p	r7
RLC L	CB 05	2	8	7	z	p	r7
RLCA	07	1	4	-	-	-	r7
RLD	ED 6F	2	18	7	z	p	-
RR (HL)	CB 1E	2	15	7	z	p	r0

Instruction	Opcode	B	Ts	S	Z	P	C
RR (IX+d)	DD CB d 1E	4	23	7	z	p	r0
RR (IY+d)	FD CB d 1E	4	23	7	z	p	r0
RR A	CB 1F	2	8	7	z	p	r0
RR B	CB 18	2	8	7	z	p	r0
RR C	CB 19	2	8	7	z	p	r0
RR D	CB 1A	2	8	7	z	p	r0
RR E	CB 1B	2	8	7	z	p	r0
RR H	CB 1C	2	8	7	z	p	r0
RR L	CB 1D	2	8	7	z	p	r0
RRA	1F	1	4	-	-	-	r0
RRC (HL)	CB 0E	2	15	7	z	p	r0
RRC (IX+d)	DD CB d 0E	4	23	7	z	p	r0
RRC (IY+d)	FD CB d 0E	4	23	7	z	p	r0
RRC A	CB 0F	2	8	7	z	p	r0
RRC B	CB 08	2	8	7	z	p	r0
RRC C	CB 09	2	8	7	z	p	r0
RRC D	CB 0A	2	8	7	z	p	r0
RRC E	CB 0B	2	8	7	z	p	r0
RRC H	CB 0C	2	8	7	z	p	r0
RRC L	CB 0D	2	8	7	z	p	r0
RRCA	0F	1	4	-	-	-	r0
RRD	ED 67	2	18	7	z	p	-
RST 0	C7	1	11	-	-	-	-
RST 1,addr	CF dr ad	3	(11)	-	-	-	-
RST 2,addr	D7 dr ad	3	(11)	-	-	-	-
RST 3,addr	DF dr ad	3	(11)	-	-	-	-
RST 4	E7	1	11	-	-	-	-
RST 5,addr	EF dr ad	3	(11)	-	-	-	-
RST 6	F7	1	11	-	-	-	-
RST 7	FF	1	11	-	-	-	-
SBC A,(HL)	9E	1	7	7	z	v	b
SBC A,(IX+d)	DD 9E d	3	19	7	z	v	b
SBC A,(IY+d)	FD 9E d	3	19	7	z	v	b
SBC A,A	9F	1	4	7	z	v	b
SBC A,B	98	1	4	7	z	v	b
SBC A,C	99	1	4	7	z	v	b
SBC A,D	9A	1	4	7	z	v	b
SBC A,E	9B	1	4	7	z	v	b

Instruction	Opcode	B	Ts	S	Z	P	C
SBC A,H	9C	1	4	7	z	v	b
SBC A,HIX	DD 9C	2	8	7	z	v	b
SBC A,HIY	FD 9C	2	8	7	z	v	b
SBC A,L	9D	1	4	7	z	v	b
SBC A,LIX	DD 9D	2	8	7	z	v	b
SBC A,LIY	FD 9D	2	8	7	z	v	b
SBC A,n	DE n	2	7	7	z	v	b
SBC HL,BC	ED 42	2	15	15	z	v	b
SBC HL,DE	ED 52	2	15	15	z	v	b
SBC HL,HL	ED 62	2	15	15	z	v	b
SBC HL,SP	ED 72	2	15	15	z	v	b
SCF	37	1	4	-	-	-	1
SET 0,(HL)	CB C6	2	15	-	-	-	-
SET 0,(IX+d)	DD CB d C6	4	23	-	-	-	-
SET 0,(IY+d)	FD CB d C6	4	23	-	-	-	-
SET 0,A	CB C7	2	8	-	-	-	-
SET 0,B	CB C0	2	8	-	-	-	-
SET 0,C	CB C1	2	8	-	-	-	-
SET 0,D	CB C2	2	8	-	-	-	-
SET 0,E	CB C3	2	8	-	-	-	-
SET 0,H	CB C4	2	8	-	-	-	-
SET 0,L	CB C5	2	8	-	-	-	-
SET 1,(HL)	CB CE	2	15	-	-	-	-
SET 1,(IX+d)	DD CB d CE	4	23	-	-	-	-
SET 1,(IY+d)	FD CB d CE	4	23	-	-	-	-
SET 1,A	CB CF	2	8	-	-	-	-
SET 1,B	CB C8	2	8	-	-	-	-
SET 1,C	CB C9	2	8	-	-	-	-
SET 1,D	CB CA	2	8	-	-	-	-
SET 1,E	CB CB	2	8	-	-	-	-
SET 1,H	CB CC	2	8	-	-	-	-
SET 1,L	CB CD	2	8	-	-	-	-
SET 2,(HL)	CB D6	2	15	-	-	-	-
SET 2,(IX+d)	DD CB d D6	4	23	-	-	-	-
SET 2,(IY+d)	FD CB d D6	4	23	-	-	-	-
SET 2,A	CB D7	2	8	-	-	-	-
SET 2,B	CB D0	2	8	-	-	-	-
SET 2,C	CB D1	2	8	-	-	-	-

Instruction	Opcode	B	Ts	S	Z	P	C
SET 2,D	CB D2	2	8	-	-	-	-
SET 2,E	CB D3	2	8	-	-	-	-
SET 2,H	CB D4	2	8	-	-	-	-
SET 2,L	CB D5	2	8	-	-	-	-
SET 3,(HL)	CB DE	2	15	-	-	-	-
SET 3,(IX+d)	DD CB d DE	4	23	-	-	-	-
SET 3,(IY+d)	FD CB d DE	4	23	-	-	-	-
SET 3,A	CB DF	2	8	-	-	-	-
SET 3,B	CB D8	2	8	-	-	-	-
SET 3,C	CB D9	2	8	-	-	-	-
SET 3,D	CB DA	2	8	-	-	-	-
SET 3,E	CB DB	2	8	-	-	-	-
SET 3,H	CB DC	2	8	-	-	-	-
SET 3,L	CB DD	2	8	-	-	-	-
SET 4,(HL)	CB E6	2	15	-	-	-	-
SET 4,(IX+d)	DD CB d E6	4	23	-	-	-	-
SET 4,(IY+d)	FD CB d E6	4	23	-	-	-	-
SET 4,A	CB E7	2	8	-	-	-	-
SET 4,B	CB E0	2	8	-	-	-	-
SET 4,C	CB E1	2	8	-	-	-	-
SET 4,D	CB E2	2	8	-	-	-	-
SET 4,E	CB E3	2	8	-	-	-	-
SET 4,H	CB E4	2	8	-	-	-	-
SET 4,L	CB E5	2	8	-	-	-	-
SET 5,(HL)	CB EE	2	15	-	-	-	-
SET 5,(IX+d)	DD CB d EE	4	23	-	-	-	-
SET 5,(IY+d)	FD CB d EE	4	23	-	-	-	-
SET 5,A	CB EF	2	8	-	-	-	-
SET 5,B	CB E8	2	8	-	-	-	-
SET 5,C	CB E9	2	8	-	-	-	-
SET 5,D	CB EA	2	8	-	-	-	-
SET 5,E	CB EB	2	8	-	-	-	-
SET 5,H	CB EC	2	8	-	-	-	-
SET 5,L	CB ED	2	8	-	-	-	-
SET 6,(HL)	CB F6	2	15	-	-	-	-
SET 6,(IX+d)	DD CB d F6	4	23	-	-	-	-
SET 6,(IY+d)	FD CB d F6	4	23	-	-	-	-
SET 6,A	CB F7	2	8	-	-	-	-

Instruction	Opcode	B	Ts	S	Z	P	C
SET 6,B	CB F0	2	8	-	-	-	-
SET 6,C	CB F1	2	8	-	-	-	-
SET 6,D	CB F2	2	8	-	-	-	-
SET 6,E	CB F3	2	8	-	-	-	-
SET 6,H	CB F4	2	8	-	-	-	-
SET 6,L	CB F5	2	8	-	-	-	-
SET 7,(HL)	CB FE	2	15	-	-	-	-
SET 7,(IX+d)	DD CB d FE	4	23	-	-	-	-
SET 7,(IY+d)	FD CB d FE	4	23	-	-	-	-
SET 7,A	CB FF	2	8	-	-	-	-
SET 7,B	CB F8	2	8	-	-	-	-
SET 7,C	CB F9	2	8	-	-	-	-
SET 7,D	CB FA	2	8	-	-	-	-
SET 7,E	CB FB	2	8	-	-	-	-
SET 7,H	CB FC	2	8	-	-	-	-
SET 7,L	CB FD	2	8	-	-	-	-
SLA (HL)	CB 26	2	15	7	z	p	r7
SLA (IX+d)	DD CB d 26	4	23	7	z	p	r7
SLA (IY+d)	FD CB d 26	4	23	7	z	p	r7
SLA A	CB 27	2	8	7	z	p	r7
SLA B	CB 20	2	8	7	z	p	r7
SLA C	CB 21	2	8	7	z	p	r7
SLA D	CB 22	2	8	7	z	p	r7
SLA E	CB 23	2	8	7	z	p	r7
SLA H	CB 24	2	8	7	z	p	r7
SLA L	CB 25	2	8	7	z	p	r7
SLL (HL)	CB 36	2	15	7	z	p	r7
SLL (IX+d)	DD CB d 36	4	23	7	z	p	r7
SLL (IY+d)	FD CB d 36	4	23	7	z	p	r7
SLL A	CB 37	2	8	7	z	p	r7
SLL B	CB 30	2	8	7	z	p	r7
SLL C	CB 31	2	8	7	z	p	r7
SLL D	CB 32	2	8	7	z	p	r7
SLL E	CB 33	2	8	7	z	p	r7
SLL H	CB 34	2	8	7	z	p	r7
SLL L	CB 35	2	8	7	z	p	r7
SRA (HL)	CB 2E	2	15	7	z	p	r0
SRA (IX+d)	DD CB d 2E	4	23	7	z	p	r0

Instruction	Opcode	B	Ts	S	Z	P	C
SRA (IY+d)	FD CB d 2E	4	23	7	z	p	r0
SRA A	CB 2F	2	8	7	z	p	r0
SRA B	CB 28	2	8	7	z	p	r0
SRA C	CB 29	2	8	7	z	p	r0
SRA D	CB 2A	2	8	7	z	p	r0
SRA E	CB 2B	2	8	7	z	p	r0
SRA H	CB 2C	2	8	7	z	p	r0
SRA L	CB 2D	2	8	7	z	p	r0
SRL (HL)	CB 3E	2	15	7	z	p	r0
SRL (IX+d)	DD CB d 3E	4	23	7	z	p	r0
SRL (IY+d)	FD CB d 3E	4	23	7	z	p	r0
SRL A	CB 3F	2	8	7	z	p	r0
SRL B	CB 38	2	8	7	z	p	r0
SRL C	CB 39	2	8	7	z	p	r0
SRL D	CB 3A	2	8	7	z	p	r0
SRL E	CB 3B	2	8	7	z	p	r0
SRL H	CB 3C	2	8	7	z	p	r0
SRL L	CB 3D	2	8	7	z	p	r0
SUB (HL)	96	1	7	7	z	v	b
SUB (IX+d)	DD 96 d	3	19	7	z	v	b
SUB (IY+d)	FD 96 d	3	19	7	z	v	b
SUB A	97	1	4	7	z	v	b
SUB B	90	1	4	7	z	v	b
SUB C	91	1	4	7	z	v	b
SUB D	92	1	4	7	z	v	b
SUB E	93	1	4	7	z	v	b
SUB H	94	1	4	7	z	v	b
SUB HIX	DD AC	2	8	7	z	v	b
SUB HIY	FD AC	2	8	7	z	v	b
SUB L	95	1	4	7	z	v	b
SUB LIX	DD AD	2	8	7	z	v	b
SUB LIY	FD AD	2	8	7	z	v	b
SUB n	D6 n	2	7	7	z	v	b
XOR (HL)	AE	1	7	7	z	p	0
XOR (IX+d)	DD AC d	3	19	7	z	p	0
XOR (IY+d)	FD AC d	3	19	7	z	p	0
XOR A	AF	1	4	7	z	p	0
XOR B	A8	1	4	7	z	p	0

<b>Instruction</b>	<b>Opcode</b>	<b>B</b>	<b>Ts</b>	<b>S</b>	<b>Z</b>	<b>P</b>	<b>C</b>
XOR C	A9	1	4	7	z	p	0
XOR D	AA	1	4	7	z	p	0
XOR E	AB	1	4	7	z	p	0
XOR H	AC	1	4	7	z	p	0
XOR HIX	DD AC	2	8	7	z	p	0
XOR HIY	FD AD	2	8	7	z	p	0
XOR L	AD	1	4	7	z	p	0
XOR LIX	DD AC	2	8	7	z	p	0
XOR LIY	FD AD	2	8	7	z	p	0
XOR n	EE n	2	7	7	z	p	0



# The CRTC Registers

To change the value of these registers, the register number should be output on address &BCxx and then the data output on &BDxx

<b>Reg</b>	<b>Function</b>	<b>Default Value</b>	<b>Reg</b>	<b>Function</b>	<b>Default Value</b>
R0	Horizontal Total	63	R1	Horizontal Displayed	40
R2	Horizontal Sync Pos.	46	R3	Sync Width	112
R4	Vertical Total	38	R5	Vertical Total Adjust	0
R6	Vertical Displayed	25	R7	Vertical Sync Position	30
R8	Interlace and Skew	0	R9	Maximum Raster Addr	7
R10	Cursor Start Raster	0	R11	Cursor End Raster	0
R12	Start Address (H)	48	R13	Start Address (L)	0
R14	Cursor Register (H)	192	R15	Cursor Register (L)	07